DEFENSE WORK MEASUREMENT STANDARD TIME DATA PROGRAM (DWMSTDP)

PART TWO - STRUCTURAL WORK OCCUPATIONS STANDARD TIME DATA

SECTION II - DWMSTDP ELEMENT LISTING

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|----------------|----------------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NO | 8XX | MAO | LFAIR | MCPCIXX | 236 185 | CLAMP(BAR), INSTALL AND REMOVE STAPTS-WITH REACH TO BAR CLAMP INCLUDES-ALL MOTIONS NECESSARY TO GET BAR CLAMP FROM BENCH, POSITION CLAMP TO PART AND CLOSE CLAMP ON PART; REACH TO CLAMP, UPEN CLAMP, MOVE CLAMP FROM PART AND ASIDE CLAMP TO BENCH ENDS-WITH RELEASE CLAMP CASE OI INSTALL BAR CLAMP OZ REMOVE BAR CLAMP |
| NF | 8XX | MÀF | 778 | MGMRU01 | 317 | RULE, USE TO MEASURE STARTS-WITH RULE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO STOOP AND PLACE RULE TO FIRST REFERENCE POINT, ARISE, WALK TWO PACES TO OTHER END OF RULE, STOOP AND PLACE RULE TO SECGNO REFERENCE POINT, READ RULE, PICK UP RULE, AND ARISE ENDS-WITH OPERATOR STANDING ERECT WITH RULE IN HAND CONDITIONS-APPLICABLE TO MEASUREMENTS GREATER THAN ONE BUT LESS THAN TWO FULL LENGTHS OF RULE, TIME TO UNFOLD AND FOLD RULE NOT INCLUDED |
| NF | 8XX | MAF | 3529 | 4JP0C01 | 211 | DIE, CHANGE IN STOCK, HAND THREADING DIE STARTS-WITH DIE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO RELEASE RATCHET, REMOVE AND ASIDE DIE, GET DIE, POSITION IN STOCK, AND ENGAGE RATCHET ENDS-WITH DIE IN HAND |
| NF | axx | MAF | 2398/99 | MJPGT01 | 130 | GAS.TURN ON.LIGHT.AND TURN OFF.GAS BURNER FOR HEATING SCLOERING IRON OR SIMILAR STARTS-WITH PEACH TO LIGHTER INCLUDES-ALL MOTIONS NECESSARY TO GET LIGHTER. LIGHT BURNER WHILE TURNING VALVE TO START GAS FLOW.AND ASIDE LIGHTER:AND TURN VALVE CLOSED TO EXTINGUISH FLAME ENDS-WITH RELEASE OF VALVE |
| FFE | 8XX | M&A | GTLDRA6 | SJPOIO1 | 802 | OIE, INSTALL IN AND REMOVE FROM DIE STOCK, TWO SETSCREWS SECURING STARTS-WITH GET DIE STOCK INCLUDES-ALL MOTIGNS NECESSARY TO LOOSEN TWO SETSCREWS TWO THREADS EACH BY HAND, GET DIE, PLACE DIE IN STOCK, TURN TWO SETSCREWS IN TWO THREADS EACH BY HAND, GET SCREWORIVER, TIGHTEN TWO SETSCREWS, ASIDE SCREWDRIVER; GET DIE STOCK, GET SCREWDRIVER, LOOSEN TWO SETSCREWS, ASIDE SCREWDRIVER, AND INVERT DIE STOCK TU REMOVE DIE ENDS-WITH ASIDE DIE AND DIE STOCK |
| NF | 8XX | MAF | 3897 | SJPPPOI | 363 | POUCH(TOCL), PUT AROUND WAIST WITH STRAP AND REMOVE STARTS-WITH REACH TO POUCH INCLUDES-ALL MOTIONS NECESSARY TO GET POUCH, MOVE POUCH TO HIP, MOVE STRAP AROUND WAIST, FASTEN BUCKLE, AND PASS END OF STRAP THROUGH GUARD; AND REACH TO STRAP, UNBUCKLE, REMOVE FROM WAIST, WRAP STRAP AROUND POUCH, AND ASIDE POUCH ENDS-WITH RELEASE OF POUCH |
| AE | 8XX | MAW | SDCEAXX | MLOLMX | 103 | |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP FLEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|-------------|----------------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | SXX | MAA | AMRGSXX | TLOLIXX | TABLE | LINE, INSCRIBE, CIRCULAR, USING FINGER AS A GUIDE STARTS—WITH GET MARKING DEVICE INCLUDES—ADLL MOTIONS NECESSARY TO GET PART AND POSITION FOR MAKKING, POSITION FINGER TO EDGE OF PART, AND ORAW CIRCLE USING THE FINGER RESTING ON EDGE OF PART AS GUIDE ENOS—WITH ASIDE PART, MARKING DEVICE IN MANU |
| | | | | | | DIAMETER OF CIRCLE (INCHES) 2=6 6=12 A 8 |
| | | | | | | FIRST CIRCLE A 659 1157 ADDITIONAL B 527 1025 CIRCLE |
| NF | 8XX | M≜ ₽ | 2372 | MOHL MO1 | 347 | LADDER(EXTENSION), MOVE, WEIGHT TO 60 POUNDS STARTS—WITH REACH TO LADDER INCLUDES—ALL MOTIONS NECESSARY TO TILT LAUDER FORWARD, LIFT LADDER, SIDESTEP WITH LADDER FIVE FEET, SET LADDER DOWN, LEAN LADDER AGAINST SUPPORTING SURFACE, AND MOVE LADDER TO ADJUST ANGLE ENDS—WITH RELEASE OF LADDER |
| NF | 8xx | MAF. | 4106 | MOHĖWOS | 440 | LADDER(EXTENSION), MOVE, LADDER 20 FEET LONG STARTS-WITH REACH TO LADDER INCLUDES-ALL MOTIONS NECESSARY TO STAND LADDER UPRIGHT, LIFT LADDER, CARRY ONE PACE TO NEW LOCATION, SET LADDER DOWN, AND POSITION AT |
| | | | • | | | LOCATION SNOS-WITH RELEASE OF LADDER CONDITIONS-LACDER WEIGHS TO 75 POUNDS.FOR EACH ADDITIONAL PACE LADDER IS CARRIED ADD ONE OCCURENCE OF U BBM WJ 01 |
| ΔF | SXX | МДД | 5144R4D | MTLHPXX | YARIABLE | HOLE.PJNCH WITH PORTABLE PUNCH STARTS-WITH PUNCH IN HAND INCLUDES-ALL THE MOTIONS NECESSARY TO GET THE . MATERIAL TO BE PUNCHED, MOVE PUNCH TO MATERIAL, RELEASE MATERIAL WITH LEFT HANDLE HOLDING PUNCH), GRASP PUNCH WITH LEFT HAND, MOVE PUNCH HANDLE TO PUNCH HOLE, OPEN PUNCH, RELEASE PUNCH WITH LEFT HAND ENDS-WITH PUNCH HELD BY RIGHT HAND CASE OI PUNCH FIRST OR DNLY HOLE |
| · NF | 8XX | MAF | 3530 | MTLRR01 | 54 | OZ PUNCH EACH ADDITIONAL HOLE RATCHET.REVERSE ON THREADING TOOL STARTS-WITH REACH TO RATCHET.RELEASE PIN INCLUDES-ALL MOTIONS NECESSARY TO DISENGAGE PIN AND TURN TO REVERSE RATCHET ON HAND THREADING TOOL ENDS-WITH RELEASE OF PIN |
| • | 8XX | MAF | 1315 | STPCC01 | 243 | CHISEL, CHANGE IN PNEUMATIC HAND CHIPPER STARTS-WITH REACH TO CHIPPER TO HOLD INCLUDES-ALL MOTIONS NECESSARY TO GET CHISEL WITH OTHER HAND, REMOVE AND ASIDE CHISEL, GET CHISEL, AND INSERT IN CHIPPER ENDS-WITH CHIPPER IN HAND CONDITIONS-APPLICABLE TO PNEUMATIC HAND CHIPPER, ELECTRIC HAND HAMMER, OR SIMILAR |
| FFD | 80X | MAA | KSMGH01 | MGMHG01 | 178 | HOLE, GAUGE TO DETERMINE RIVET LENGTH STARTS-WITH GET GAUGE INCLUDES-ALL MOTIONS NECESSARY TO POSITION GAUGE TO HOLE, SLIDE GAUGE BAR TO SURFACE, AND READ GAUGE ENDS-WITH ASIDE GAUGE |

| DATA Source | OCCUP- ATION | QUALITY | SOURCE | DWMSTDP ELEMENT | TMU: VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----------------|---------|---------|--------------------|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA - | SOX | MAA | AMRQN43 | 102TqL2 | 1638 | TOOL(AIRLOC), SET UP FOR INSTALLATION OR REMOVAL OF PIN IN AIRLOC STUD STARTS-WITH GET AIRLOC TOOL INCLUDES-ALL MOTIONS NECESSARY TO PLACE TOOL IN VISE. OPEN HANDLE, GET SCREHORIVER, REMOVE SCREW-ASIDE SCREW AND SCREWORIVER, REMOVE THREADED SPACER, LIFT TURN BAR FROM HANDLE, LIFT BAR AND GUIDE PIN FROM SPRING-REVERSE BAR. POSITION BAR IN HANDLE, ENGAGE GUIDE PIN TO SPRING-INSTALL THREADED SPACER, GET SCREW- DRIVER, INSTALL SCREW, ASIDE SCREWORIVER AND REMOVE TOOL FROM VISE ENOS-WITH ASIDE TOOL |
| AAM | 80X | MAA | AMRQN44 | SUPTSOZ | 353 | TOOL (PNEUMATIC SQUEEZE), SET UP AND ASIDE, FOR INSTALLATION OF PIN IN AIRLOC STUD STARTS—WITH GET PNEUMATIC SQUUEZE INCLUDES—ALL MOTIONS NECESSARY TO GET FLUSH SQUEEZE SET, INSTALL SLOTTED SQUEEZE SET, INSTALL SLOTTED SQUEEZE SET, INSTALL FLUSH SQUEEZE SET; AND REMOVE FLUSH SQUEEZE SET, REMOVE SLOTTED. SQUEEZE SET, AND ASIDE BOTH SETS ENDS—WITH ASIDE PNEUMATIC SQUEEZE |
| NAA | 80X | MAA | OTFCHXX | MNFFLXX | 402 | FASTENER (CAMLOC), LOOSEN STARTS-WITH GET SCREWORIVER INCLUDES-ALL MOTIGNS NECESSARY TO POSITION SCREWORIVER TO FASTENER STUD. TURN STUD 90 DEGREES TO UNLOCK, AND TURN STUD 1.5-3 REVOLUTIONS TO UNFASTEN ENDS-WITH ASIDE SCREWORIVER CONDITIONS-APPLICABLE TO CAMLOC HIGH STRESS PANEL FASTENER CASE O1 FIRST OR SINGLE FASTENER O2 EACH ADDITIONAL FASTENER IN A SERIES |
| * NAA | . 80X | MAA | OTFCHXX | MNFFTXX | 320 VARIABLE 435 366 | FASTENER (CAMLOC), TIGHTEN STARTS-WITH GET SCREWORIVER INCLUDES-ALL MOTICNS NECESSARY TO POSITION SCREWORIVER TO FASTENER STUD, TURN STUD COUNTERCLOCKWISE TO ALIGN, PUSH IN TO SEAT STUD, TURN STUD 90 DEGREES TO LOCK, AND TURN STUD 1.5-3 REVOLUTIONS TO TIGHTEN TO RECEPTACLE ENDS-WITH ASIDE SCREWORIVER CONDITIONS-APPLICABLE TO CAMLOC HIGH STRESS PANEL FASTENER CASE OI FIRST OR SINGLE FASTENER OZ EACH ADDITIONAL FASTENER IN A SEXIES |

| DATA SOURCE | | QUAL ITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|---------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 80X | MBA | AHRHNXX | SNFFIXX | VARIABLE | FASTENER(HIGH STRENGTH), INSTALL STARTS-WITH GET TOOLS TO DRILL HOLE INCLUDES-ALL MOTIONS NECESSARY TO LOCATE HOLE, DRILL HOLE, RECESS HOLE, DEBURR HOLE, CHAMFER |
| | | | | | | HOLE FOR PROPER FIT, AND INSTALL FASTENER ENDS-WITH FASTENER INSTALLED CONDITIONS-APPLICABLE TO ALL SIZE HUCK STUMP TYPE SHEAR PINS, HIGH SHEAR RIVETS, OR SIMILAR, |
| | | | | | | IN HOLES WITH INTERFERENCE FIT(CASES DI-08). APPLICABLE TO HUCK PULL TYPE SHEAR PINS OR SIMILAR TO 3/8 INCH DIAMETER, ALL LENGTHS, AND TO HUCK GUN MODELS 200,352,OR SIMILAR(CASES |
| | | | | - | ζ. | O9-121-APPLICABLE TO HI-LOK FASTENERS TO 9/16 INCH DIAMETERICASES 13-161.ALL CASES APPLICABLE TO ALUMINUM .020-250 INCH |
| | | • | | | | THICKNESS OR STAINLESS STEEL .020050 INCH THICKNESS.INCLUDES SETUP OF TOOLS. |
| • | | | | | 8900 | CASE OL FIRST HI-SHEAR FLUSH RIVET, 1-MAN OPERATION |
| | | | | | 1770 | 02 EACH ADDITIONAL HI-SHEAR FLUSH RIVET, 1-MAN OPERATION |
| | | | | | 10330 | 03 FIRST HI-SHEAR FLUSH RIVET, 2-MAN |
| | | | | | 2320 | 04 EACH ADDITIONAL HI-SHEAR FLUSH RIVET. |
| | | | | _ | 5510 | 2-MAN OPERATION 05 FIRST HI-SHEAR FLAT HEAD RIVET, 1-MAN |
| | | | | : | 1530 | OPERATION OF EACH ADDITIONAL HI-SHEAR FLAT HEAD |
| | | | | | 6940 | RIVET,1-MAN OPERATION O7 FIRST HI-SHEAR FLAT HEAD RIVET,2-MAN |
| • | | | | | 2080 | OPERATION OB EACH ADDITIONAL HI-SHEAR FLAT HEAD |
| | | | | | 7140 | RIVET, 2-MAN OPERATION . |
| | • | | | | 7160 1510 | 09 FIRST FLUSH HUCK LOCK FASTENER 10 EACH ADDITIONAL FLUSH HUCK LOCK |
| | | | | | | FASTENER |
| | | | | | 4270 | 11 FIRST UNIVERSAL HUCK LOCK FASTENER |
| | | | | | 1340 | 12 TACH ADDITIONAL UNIVERSAL HUCK LUCK FASTENER |
| | | | | | 8020 | 13 FIRST FLUSH HI-LOK FASTENER |
| | | | | | 2070 | 14 EACH ADDITIONAL FLUSH HI-LOK FASTENER |
| | | | | | 5130 | 15 FIRST UNIVERSAL HI-LOK FASTENER |
| | | | | | 1900 | 16 EACH ADDITIONAL UNIVERSAL HI-LOK |
| | | | | | | FASTENER |

| DATA Source | | QUAL ITY | | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-------|----------|----------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 80X | MBA | AHRHRXX | SNFFRXX | VARIABLE | FASTENERS(HIGH STRENGTH), REPLACE STARTS-WITH REACH TO TOOL OR AIR HOSE INCLUDES-ALL MOTIONS NECESSARY TO REMOVE AND INSTALL HIGH STRENGTH FASTENER AS DESCRIBED IN EACH CASE ENDS-WITH ASIDE TOOL OR AIR HOSE |
| | | | | | | CONDITIONS—CASES OF THRU OR APPLY TO ALL SIZES HUCK STUMP TYPE SHEAR PINS.HI—SHEAR RIVETS OR SIMILAR IN INTERFERENCE FIT HOLES. CASES OF AND 10 APPLY TO HUCK PULL TYPE SHEAR PINS OR SIMILAR TO 3/8 INCH DIAMETER.ALL |
| | | | | | | LENGTHS AND HUCK GUN MODEL 352,200 OR SIMILAR.FASTENER INSTALLED IN EXISTING HOLE. CASE OI REMOVE AND INSTALL HI-SHEAR FLUSH HEAD |
| | | | | | 3580 | RIVET 1-MAN OPERATION.FIRST PASIENCE |
| | | | | | 1070 | OZ REMOVE AND INSTALL HI-SHEAR FLUSH HEAD RIVET, L-MAN OPERATION, ADDITIONAL EASTENER |
| | | | | | 3080 | O3 REMOVE AND INSTALL HI-SHEAR FLAT HEAD RIVET, 1-MAN OPERATION, FIRST FASTENER |
| | | | | | 1000 | O4 REMOVE AND INSTALL HI-SHEAR FLAT HEAD RIVET, 1-MAN OPERATION, ADDITIONAL |
| | | | | | 5010 | FASTENER 05 REMOVE AND INSTALL HI-SHEAR FLUSH HEAD RIVET, 2-MAN OPERATION, FIRST |
| • | | | | | 1620 | FASTENER 06 REMOVE AND INSTALL HI-SHEAR FLUSH HEAD RIVET.2-MAN OPERATION.ADDITIONAL |
| | | | • | | 4510 | FASTENER O7 REMOVE AND INSTALL HI-SHEAR FLAT HEAD |
| | | | | | 1550 | RIVET. 2-MAN OPERATION. FIRST FASTENER US REMOVE AND INSTALL HI-SHEAR FLAT HEAD |
| | • | | | | 1,5,0 | RIVET, 2-MAN OPERATION, ADDITIONAL |
| | | | | | 1410 | OP REMOVE AND INSTALL HUCK LOCK PIN AND COLLAR, FLUSH OR UNIVERSAL, FIRST FASTENER |
| | | | | | 900 | 10 REMOVE AND INSTALL HUCK LOCK PIN AND COLLAR, FLUSH OR UNIVERSAL, ADDITIONAL FASTENER |
| NAA | . 80X | HAA | ONFFTXX | SNFFSX | X VARIABLE | FASTENER(TURNLOCK), SEAT AND TIGHTEN STARTS-WITH GET TOOL INCLUDES-ALL MOTIONS NECESSARY TO POSITION |
| | | | | | | TOOL TO SLOT IN FASTENER, ALIGN FASTENER, SEAT FASTENER, AND TURN FASTENER TO LOCK ENDS-WITH ASIDE TOOL |
| | | | | | | CONDITIONS-APPLICABLE TO DZUS, CAMLOC, AIRLOC OR SIMILAR FASTENERS TO 3/8 INCH DIAMETER TURNED APPROXIMATELY 90 DEGREES TO LUCK |
| | | | | | 140 87 | CASE OI FIRST FASTENER OZ EACH ADDITIONAL FASTENER |
| | | | ONEETYY | CHESIIV | X VARIABLE | FASTENER (TURNLOCK) + UNLOCK |
| NA. | A 80X | MAA | UNFFIAA | 3147 7 02 | , vaniable | STARTS-WITH GET TOOL INCLUDES-ALL MOTIONS NECESSARY TO POSITION TOOL TO SLOT AND TURN FASTENER TO UNLOCK |
| | | | | | | ENDS-WITH ASIDE TOOL CONDITIONS-APPLICABLE TO DZUS, CAMLOC, A IRLOC, |
| | | | | | | OR CIMILAD EACTENERS TO 3/8 INCH DIAMEICK |
| | | | | | 114 | TURNED APPROXIMATELY 90 DEGREES TO UNLOCK CASE 01 FIRST FASTENER |
| | | | | | 114 61 | AA CACU ADDITIONAL EASTENER |
| FF | O 80X | MAA | KAL SAXX | SNFLI | XX VARTABLE | STARTS-WITH GET WEDGE COCK |
| | | | | | | DOWN.PLACE LOCK IN HOLE, GET TOOL AND PLACE ON LOCK, AND SECURE LOCK ENDS-WITH ASIDE TOOL |
| | | | | | 335 | CACE OF EIRST MEDGE LOCK |
| | | | | | 1 86 | 02 EACH ADDITIONAL WEDGE LOCKIDOES NOT INCLUDE GET LOCK OR GET/ASIDE TOOL) |
| | | | | | | |

| DATA SOURCE | OCCUP- ATION | QUAL ITY | SOURCE | DWMSTOP ELEMENT | | OPERATION/ELEMENT DESCRIPTION . |
|----------------|-----------------|----------|----------|--------------------|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FFE | BOX | MBA | KAL SDF5 | SNFLR01 | 231 | LOCK(WEDGE), REMOVE WITH PNEUMATIC TOOL STARTS-WITH GET PNEUMATIC TOOL INCLUDES-ALL MOTICNS NECESSARY TO PLACE TOOL ON WEDGE LOCK, RELEASE LOCK, ASIDE TOOL, AND REMOVE WEDGE LOCK ENOS-WITH ASIDE WEDGE LOCK CONDITIONS-DOES NOT INCLUDE TIME TO SET UP PNEUMATIC TOOL |
| FFO | SOX | MAA | KSMHFXX | MTLFUXX | VARIABLE | FINDER(HOLE).USE.LEAF TYPE STARTS-MITH GET HOLE FINDER INCLUDES-ALL MOTIONS NECESSARY TO SPREAD LEAVES.PLACE FINDER ON METAL.ENGAGE PEG IN HOLE.HOLD GUIDE FOR ORILLING.AND REMOVE FINDER FROM HOLE ENDS-MITH ASIDE HOLE FINDER. CONDITIONS-TIME FOR ORILLING NOT INCLUDED CASE 01 FIRST HOLE |
| | | | | | 172 | 02 EACH ADDITIONAL HOLE |
| NAA | 80X | HAA | SMRHMXX | MTLHRXX | 752 1139 1744 | HOLE, REAM WITH HAND REAMER STARTS-WITH REAMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE REAMER TO HOLE, POSITION, REAM HOLE, AND REMOVE REAMER FROM HOLE ENOS-WITH REAMER IN HAND CONDITIONS-003 INCH STOCK REMOVAL FROM HOLE ONE INCH DEEP IN ALUMINUM CASE 01 HOLE TO 3/8 INCH DIAMETER 02 HOLE 3/8-3/4 INCH DIAMETER |
| NAA | 80X | MUA | AMRMMXX | STLACXX | • | 03 HOLE 3/4-1 1/2 INCHES DIAMETER |
| | | | | | 166 | ALUMINUM.CUT WITH COMPOUND LEVER SNIPS.PER LINEAR INCH STARTS-WITH GET SNIPS INCLUDES-ALL MOTIONS NECESSARY TO POSITION SNIPS TO CUT POINT AND CUT ONE LINEAR INCH ENDS-WITH ASIDE SNIPS CONDITIONS-WADDITIONAL INCHWICASES DO NUT INCLUDE GET AND ASIDE SNIPS.APPLICABLE TO CURVED.CIRCULAR OR STRAIGHT CUTS IN 245.755.DR SIMILAR ALUMINUM CASE OI FIRST LINEAR INCH.ROUGH CUT, MATERIAL |
| | | | | | 106 | •UUL→•U32 INCH THICKNESS |
| | | | | | 220 | 02 EACH ADDITIONAL LINEAR INCH, ROUGH CUT, MATERIAL .001032 INCH THICKNESS |
| | | | | | 160 | 03 FIRST LINEAR INCH-ROUGH CUT, MATERIAL .033052 INCH THICKNESS 04 EACH ADDITIONAL LINEAR INCH-ROUGH CUT, |
| | ** | | | | 284 | MATERIAL .033052 INCH THICKNESS 05 FIRST LINEAR INCH, FINISH CUT, MATERIAL |
| ٠ | · | | | | 224 | -UUL032 INCH THICKNESS 06 EACH ADDITIONAL LINEAR INCH. FINISH |
| | •• | | . • | | 402 | OT FIRST LINEAR INCH-FINISH CUT-MATERIAL |
| | | | | | 342 | .033052 INCH THICKNESS 08 EACH ADDITIONAL LINEAR INCH.FINISH CUT, MATERIAL .033052 INCH THICKNESS |
| NAA | 80X | MAA S | MRSRXX | STLLRXX V | 841 132 | LAMINATION, REMOVE ONE LAYER FROM SHIMSTOCK, TO TWO INCHES MIDE AND SIX INCHES LONG STARTS-WITH GET SHIMSTOCK INCLUDES-ALL MCTICNS NECESSARY TO GET KNIFE, PULL UP CORNER OF LAMINATION, ASIGE KNIFE, GET NEEDLE NOSE PLIERS, PULL LAMINATION FROM STOCK, AND ASIDE STOCK AND LAMINATION ENDS-WITH ASIDE PLIERS CASE OI REMOVE FIRST SIX LINEAR INCHES FROM SHIMSTOCK UZ REMOVE ADDITIONAL SIX LINEAR INCHES |
| | | | | | | THE STATE STATE STATE INCHES |

| DATA OCCUP- QUALITY SOURCE DIMSTOP THU SOURCE ATION VF 80X MAF 2340 STLMCXX VARIABLE VF 80X MAF 2340 STLMCXX VARIABLE ASSTATS-WITH RECARD TO SHIPS SHAP SHAP SHAP SHAP SHAP SHAP SHAP SH | • | | | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|-----------|-----|------------|---------|---------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| STARTS-WITH REACH TO SHIPS | | | | QUAL ITY | | | - | OPERATION/ELEMENT DESCRIPTION |
| STARTS-WITH OBJECT TO BE DIRPLED IN MANU- INCLUDES-ALL THE MOTIONE RECSSARY TO WOULD GRADE TO DIE PEG. POSITION AND GRADE SEED TO PEG. POSITION AND GRADE SEED TO PEG. POSITION AND GRADE SEED TO PEG. POSITION AND GRADE SEED SEED TO PEG. POSITION AND GRADE SEED SEED SEED SEED SEED SEED SEED S | | 4F | вох | MAF | 2340 | STLMCXX | 165 | STARTS-WITH REACH TO SNIPS INCLUDES-ALL MOTIONS NECESSARY TO MOVE SNIPS TO METAL, CUT ONE LINEAR INCH, AND ASIDE SNIPS ENDS-WITH RELEASE OF SNIPS CASE OI FIRST INCH |
| # # # # # # # # # # # # # # # # # # # | | FFO | 800 | HAA | KSMDCXX | TEMHOXX | TABLE | STARTS-WITH OBJECT TO BE DIMPLED IN HAND INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE OBJECT TO DIE PEG.POSITION ON PEG.MOVE LEG TO OPEN AND CLOSE RAM.REMOVE OBJECT FROM DIE PEG ENDS-WITH OBJECT DISENGAGED FROM DIE PEG CONDITIONS-TIMES ARE PER HOLE DIMPLEDICJLD)- ADD TIME FROM ELEMENT 800 BPTMHXX TO OBTAIN |
| 2.5 TO 10 B 71 74 79 10 TO 20 C 77 80 85 20 TO 30 D 82 85 90 30 TO 40 E 88 91 96 FFE 800 MAA KSMIRO1 SITRIO1 226 RIVET, INSPECT WITH LIGHT STARTS-MITH GET LIGHT INCLUDES—ALL MOTIONS NECESSARY TO TURN LIGHT ON, INSPECT HEAD DE RIVET, MOVE LIGHT, INSPECT TAIL OF RIVET, AND TURN LIGHT OFF ENDS—MITH AS IDE LIGHT CONDITIONS—BOODY MOTIONS REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED FFE 800 MAA KSMIRO2 SITRIO2 370 RIVET, INSPECT WITH LIGHT AND HIRROR STARTS—MITH GET HIPPETTION LIGHT STARTS—MITH GET MENDER TO GET HIRROR, THE PETTION LIGHT ON, PLACE MIRROR AND ADJUST ANGLE, INSPECT HORD OF RIVET, MOVE LIGHT, INSPECT OTHER END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, MOVE LIGHT CONDITIONS—BIPPOR REQUIRED TO RESEARCH AND ASIDE AIR MOSE, ATTACH TO GUN, GET RIVET SET, HOVE SPRING ASIDE, MOWE AND ASIDE AIR MOSE ENDS—MITH AIR RIVET GUN IN MAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, MOVE SPRING ASIDE, AND ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE, AND MOVE SPRING ASIDE | | | | | | | | WEIGHT OF TO 1 1 TO 3 3 TO 9 OBJECT INCH INCHES INCHES |
| FFE 800 MAA KALSSO SJPGSO2 10 TO 20 C 77 80 85 20 TO 30 D 82 85 90 30 TO 40 E 88 91 96 RIVET, INSPECT MITH LIGHT STARTS—MITH GET LIGHT INCLODES—MITH ASIDE LIGHT CONDITIONS—MODY MOTIONS REQUIRED TO GET IN POSITION FOR INSPECTION HOT INCLUDED FFE 800 MAA KSMIROZ SITRIOZ 370 RIVET, INSPECT WITH LIGHT AND MIRROR STARTS—WITH GET INSPECTION LIGHT INSPECT ONE IND DE RIVET, MOVE LIGHT, INSPECT OTHER END OF RIVET, MOVE LIGHT CONDITIONS—MIPHOR REQUIRED TO GET MIRROR, TURN LIGHT ONP PLACE MIRROR AND ADJUST ANGLE, INSPECT ONE END OF RIVET, MOVE LIGHT, INSPECT OTHER END OF RIVET, MOVE LIGHT CONDITIONS—MIPHOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, BODY MOTIONS, REQUIRED TO GET IN POSITION FOR INSPECTION LIGHT CONDITIONS—MIPHOR REQUIRED TO INSPECT ONLY ONE END OF RIVET, BODY MOTIONS, REQUIRED TO GET IN POSITION FOR INSPECTION HOT INCLUDED. FFE 800 MAA KALSSO SJPGSO1 424 GUNIRIVET), SET UP, INITIAL STARTS—WITH GET RIVET GUN INCLUDES—ALL MOTIONS NECESSARY TO GET AIR MOSE, ATTACH TO GUN, GET RIVET SET, MOVE SPRING ASIDE, RIVET ASIDE MIR MOSE, AND ASIDE AIR MOSE ENDS—MITH ASIDE GUN MAND FFE 800 MAA KALSSO SJPGSO2 173 GUNIRIVET), SET UP, CHANGE RIVET SET STARTS—WITH ASIDE GUN IN MAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, ARRONG AND ASIDE RIVET SET, GET RIVET SET, AND SEPRING ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE RIVET SET, GET RIVET SET, SET MAND | | | | | | | | TO 2.5 A 67 70 75 |
| FFE 800 MAA KSMIROL SITRIOL 226 RIVET, INSPECT WITH LIGHT STARTS-WITH GET LIGHT INCLUDES AND TURN LIGHT CONDITIONS—BOODY MOTIONS RECESSARY TO TURN LIGHT CONDITIONS—BOODY MOTION SPECTION NOT INCLUDED POSITION FOR INSPECTION NOT INCLUDED FFE 800 MAA KSMIROL SITRIOL 370 RIVET, INSPECT WITH LIGHT AND MIRROR STARTS—WITH ASIDE LIGHT CONDITIONS—BOODY MOTIONS RECURS AND ADJUST ANGLE, THAN GET INSPECTION LIGHT CONDITIONS—BOODY MOTIONS NECESSARY TO GET MIRROR, THAN HE CONDITIONS—MIRROR RECURS AND ADJUST ANGLE, INSPECT ONE FIND OF RIVET, ASIDE MIRROR, AND THAN HE CONDITIONS—MIRROR REQUIRED TO INSPECT ONLY DIVE ENDOW MOTIONS. REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED. FFE 800 MAA KALSSO SJPGSOL 424 GUNERLYST, SET UP, INITIAL STARTS—WITH GET RIVET GET AND SERING ASIDE AND ASIDE AIR MOSE, AND ASIDE AIR MOSE ATTACH TO GUNE AND ASIDE AIR MOSE ATTACH TO GUNE AND ASIDE AIR MOSE AND ASIDE AND MOVE SPRING ASIDE AND MINAMAD INSTANCE. | | | | • | | | | 2.5 10 10 8 71 74 79 |
| FFE 800 MAA KSMIROL SITRIOL 226 RIVET, INSPECT WITH LIGHT STARTS—WITH GET LIGHT ON, INSPECT HAD OF RIVET, MOVE LIGHT, INSPECT TAIL OF RIVET, AND TURN LIGHT OFF ENDS—WITH ASIDE LIGHT COMDITIONS—BODY MOTIONS REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED FFE 800 MAA KSMIROZ SITRIOZ 370 RIVET, INSPECT HITH LIGHT AND MIRROR STARTS—WITH GET INSPECTION LIGHT INCLUDES—ALL MOTIONS NECESSARY TO GET MIRROR. TURN LIGHT ON, PLACE MIRROR AND ADJUST ANGLE. INSPECT ONE MD OF RIVET, ASIDE MIRROR, AND TURN LIGHT COMDITIONS—WITH ASIDE INSPECTION LIGHT COMDITIONS—WITH ASIDE INSPECTION NOT INCLUDED. FFE 800 MAA KALSSZO SJPGSOL 424 GUNIRIVET), SET UP, INITIAL STARTS—MITH GET RIVET GUN INCLUDES—ALL MOTIONS NECESSARY TO GET AIR MOSS—ALL MOTIONS NECESSARY TO GET AIR MOSS—ALL MOTIONS NECESSARY TO GET AIR MOSS—ALL MOTIONS NECESSARY TO GET AIR MOSS—ALT MOTIONS NECESSARY TO MOVE SPRING AS IDE, INSTALL SET IN GUN; AND AS IDE AIR MOSE ENDS—WITH AS IDE GUN FFE 800 MAA KALSSZO SJPGSOZ 173 GUNIRIVET), SET UP, CHANGE RIVET SET STARTS—WITH RIVET GUN IN MAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE SPRING AS IDE, REPORT AND AS IDE RIVET SET, GET RIVET SET, MOVE SPRING AS IDE, AND INSTALL RIVET SET | | | | | | • | | 10 TO 20 C 77 80 85 |
| FFE 800 MAA KSMIROL SITRIOL 226 RIVET, IMSPECT WITH LIGHT STARTS-MITH GET LIGHT INCLUDES-ALL MOTIONS NECESSARY TO TURN LIGHT ON, INSPECT HEAD OF RIVET, MOVE LIGHT, INSPECT TAIL OF RIVET, AND TURN LIGHT OFF ENDS-MITH ASIDE LIGHT COMDITIONS-BODY MOTIONS REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED FFE 800 MAA KSMIROZ SITRIOZ 370 RIVET, INSPECT WITH LIGHT AND MIRROR STARTS-MITH GET INSPECTION LIGHT INCLUDES-ALL MOTIONS NECESSARY TO GET MIRROR, AND ADJUST ANGLE, INSPECT ONE BED OF RIVET, MOVE LIGHT, INSPECT OTHER END OF RIVET, ASIDE MIRROR, AND TURN LIGHT COMDITIONS—MIPROR REQUIRED TO INSPECT ONLY ONE END OF RIVET, BODY MOTIONS. REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED. FFE 800 MAA KALSSZO SJPGSOL 424 GUN(RIVET), SET UP, INITIAL STARTS-MITH GET RIVET GUN INCLUDES-ALL MOTIONS NECESSARY TO GET AIR MOSE, ATTACH TO GUN, GET RIVET SET, HOVE SPRING ASIDE, INSTALL SET IN GUN; AND REMOVE AND ASIDE ENDS-MITH ASIDE GUM FFE 800 MAA KALSSZO SJPGSOZ 173 GUN(RIVET), SET UP, CHANGE RIVET SET, HOVE SPRING ASIDE, INSTALL SET UP IN MAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET, GET RIVET SET, HOVE SPRING ASIDE, AND INSTALL RIVET SET SET, HOVE SPRING ASIDE, AND INSTALL RIVET SET SET, HOVE SPRING ASIDE, AND INSTALL RIVET SET | | | | | | | • | 20 TO 30 0 82 85 90 |
| STARTS-WITH GET LIGHT INCLUDES-ALL MOTIONS NECESSARY TO TURN LIGHT ON, INSPECT HEAD OF RIVET, MOVE LIGHT, INSPECT TAIL OF RIVET, AND TURN LIGHT OFF ENDS-WITH ASIDE LIGHT CONDITIONS-BODY MOTIONS REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED FFE 800 MAA KSMIROZ SITRIOZ 370 RIVET, INSPECT WITH LIGHT AND MIRROR STARTS-WITH GET INSPECTION LIGHT INCLUDES-ALL MOTIONS NECESSARY TO GET MIRROR, TURN LIGHT ON, PLACE MIRROR AND ADJUST ANGLE, INSPECT ONE END OF RIVET, ASIDE MIRROR, AND TURN LIGHT OFF ENDS-WITH ASIDE INSPECTION LIGHT CONDITIONS-MIPROR REQUIRED TO INSPECT ONLY ONE END OF RIVET, 800Y MOTIONS, REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED. FFE 800 MAA KALSSZO SJPGSOL 424 GUN(RIVET), SET UP, INITIAL STARTS-WITH GET RIVET GUN INCLUDES-ALL MOTIONS NECESSARY TO GET AIR MOSE, ATTACH TO GUN, GET RIVET SET, MOVE SPRING ASIDE, INSTALL SET IN GUN; AND REMOVE AND ASIDE ENDS-WITH ASIDE GUN FFE 800 MAA KALSSZO SJPGSOZ 173 GUN(RIVET), SET UP, CHANGE RIVET SET STARTS-WITH RIVET GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET, GET RIVET STARTS-WITH RIVET GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE, AND INSTALL RIVET SET | | | | | | | | 30 TO 40 E 88 91 96 |
| STARTS—WITH GET INSPECTION LIGHT INCLUDES—ALL MOTIONS NECESSARY TO GET MIRROR, TURN LIGHT ON, PLACE MIRROR AND ADJUST ANGLE, INSPECT ONE END OF RIVET, MOVE LIGHT, INSPECT OTHER END OF RIVET, ASIDE MIRROR, AND TURN LIGHT OFF ENDS—WITH ASIDE INSPECTION LIGHT CONDITIONS—MIRROR REQUIRED TO INSPECT ONLY ONE END OF RIVET, BODY MOTIONS, REQUIRED TO GET IN POSITION FOR INSPECTION NOT INCLUDED. FFE 800 MAA KALSS20 SJPGS01 424 GUN(RIVET), SET UP, INITIAL STARTS—WITH GET RIVET GUN INCLUDES—ALL MOTIONS NECESSARY TO GET AIR MOSE, ATTACH TO GUN, GET RIVET SET, MOVE SPRING ASIDE, INSTALL SET IN GUN, SAND ASIDE AIR MOSE ENDS—WITH ASIDE GUN FFE 800 MAA KALSS20 SJPGS02 173 GUN(RIVET), SET UP, CHANGE RIVET SET STARTS—WITH RIVET GUN IN MAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET STARTS—WITH RIVET GUN IN MAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE, AND INSTALL RIVET SET | | | 800 | MAA | KSMTROL | SITRIOI | 226 | STARTS-WITH GET LIGHT INCLUDES-ALL MOTIONS NECESSARY TO TURN LIGHT ON, INSPECT HEAD OF RIVET, MOVE LIGHT, INSPECT TAIL OF RIVET, AND TURN LIGHT OFF ENDS-WITH ASIDE LIGHT COMDITIONS-BODY MOTIONS REQUIRED TO GET IN |
| FFE 800 MAA KALSS20 SJPGSO1 424 GUN(RIVET), SET UP, INITIAL STARTS-WITH GET RIVET GUN INCLUDES-ALL MOTIONS NECESSARY TO GET AIR HOSE, ATTACH TO GUN, GET RIVET SET, MOVE SPRING AS IDE, INSTALL SET IN GUN; AND ASIDE SET, DISCONNECT AIR HOSE, AND ASIDE AIR HOSE ENDS-WITH ASIDE GUN FFE 800 MAA KALSS20 SJPGSO2 173 GUN(RIVET), SET UP, CHANGE RIVET SET STARTS-WITH RIVET GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SPRING AS IDE, REMOVE AND ASIDE RIVET SET, GET RIVET SET, MOVE SPRING AS IDE, AND INSTALL RIVET SET | | FFE | 800 | MAA | KSMIROZ | SITRIO | 2 370 | STARTS-WITH GET INSPECTION LIGHT INCLUDES-ALL MOTIONS NECESSARY TO GET MIRROR. TURN LIGHT ON, PLACE MIRROR AND ADJUST ANGLE. INSPECT ONE END OF RIVET, MOVE LIGHT, INSPECT OTHER END OF RIVET, AS IDE MIRROR. AND TURN LIGHT OFF ENDS-WITH AS IDE INSPECTION LIGHT CONDITIONS-MIPROR REQUIRED TO INSPECT ONLY ONE END OF RIVET. BODY MOTIONS. REQUIRED TO GET IN |
| STARTS-WITH RIVET GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE, AND INSTALL RIVET SET | | | | MAA | | | 1 424 | GUNIRIVET), SET UP, INITIAL STARTS-WITH GET RIVET GUN INCLUDES-ALL MOTIONS NECESSARY TO GET AIR HOSE, ATTACH TO GUN, GET RIVET SET, MOVE SPRING ASIDE, INSTALL SET IN GUN; AND REMOVE AND ASIDE SET, DISCONNECT AIR HOSE, AND ASIDE AIR HOSE |
| | | FFE | 800 | MAA | KALSS20 | | | STARTS-WITH RIVET GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SPRING ASIDE, REMOVE AND ASIDE RIVET SET, GET RIVET SET, MOVE SPRING ASIDE, AND INSTALL RIVET SET |

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP Element | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NA A | 800 | MAA . | AMRRRXX | SNFCRXX | VARIABLE | RIVET, CUT PROTRUCTING HEAD WITH RIVET GUN AND CHISEL STARTS-WITH GET RIVET GUN INCLUDES—ALL MOTIONS NECESSARY TO GET CHISEL, INSERT IN GUN, GET AND INSTALL SPRING, POSITION CHISEL TO RIVET HEAD, CUT RIVET, AND REMOVE AND ASIDE SPRING AND CHISEL ENDS—WITH ASIDE RIVET GUN CONDITIONS—"EACH ADDITIONAL" CASES INCLUDE POSITION CHISEL AND CUT RIVET ONLY |
| | | | | | 580 | CASE OI FIRST RIVET-ALUMINUM TO 3/16 INCH DIAMETER.OR STEEL OR MONEL TO 1/d INCH DIAMETER |
| | | | | | 39 | 02 EACH ADDITIONAL RIVET-ALUMINUM TJ 3/16 INCH DIAMETER-OR STEEL OR MONEL TO 1/8 INCH DIAMETER |
| - | | | | | 613 | 03 FIRST MONEL OR STEEL RIVET 5/32-3/16 INCH DIAMETER, OR SCREW OR-BOLT TO A NO.10 |
| | | | | | 69 | 34 EACH ADDITIONAL MONEL OR STEEL RIVET 5/32-3/16 INCH DIAMETER.UR SCREW OR BOLT TO NO.10 |
| NAA | 800 | MAA | AMRRR XX | SNFORXX | VARIABLE | RIVET, DRIVE OUT WITH HAMMER AND PIN PUNCH, 2- MAN OPERATION STARTS-WITH GET HAMMER INCLUDES-ALL MOTIONS NECESSARY TO GET PIN PUNCH, POSITION TO RIVET SHANK, GET BACKUP BAR, PUSITION TO SIDE OF RIVET, AND DRIVE RIVET OUT WITH THREE HAMMER BLOWS ENDS-WITH ASIDE TOOLS CONDITIONS-TIME VALUES SHOWN ARE TOTALS FOR TWO OPERATORS APPLICABLE TO DRIVING RIVETS OUT IN ACCESSIBLE AREAS WHERE USE OF A BACKUP BAR IS AECESSARY. |
| NAA. | 800 | MILA | | CHEFRY | 528 248 | CASE OI FIRST RIVET OZ FACH ADDITIONAL RIVET |
| NAA | | MUA | ACHDRAA | . SNF FR X X | VAKIABLE | FASTENER(BLIND), REMOVE, DEUTSCH DRIVE PIN RIVEJ STARTS-WITH GET HAMMER INCLUDES-ALL MOTIONS NECESSARY TO GET CENTER PUNCH, PUNCH RIVET STEM FOR DRILLING, ASIDE HAMMER AND PUNCH, GET DRILL MOTOR, GET AND INSTALL DRILL, DRILL STEM(PARTIAL), ASIDE DRILL, GET TAP HANDLE, GET AND INSTALL TAP IN HANDLE, TAP STEM, REMOVE TAP FROM HANDLE, ASIDE TAP AND HANDLE, GET DRILL, DRILL PIN, REMOVE DRILL FROM CHUCK, ASIDE DRILL AND ORILL MOTOR, GET ALLEN HEAD SCREW WITH HEX NUT INSTALLED, TURN HEX NUT UP SCREW, GET SPACER, POSITION ON SCREW, INSTALL SCREW IN TAPPED PIN, HOLD SCREW WITH ALLEN |
| | | | | | 10400 9640 | WRENCH-TIGHTEN HEX MUT AGAINST SPACER TO REMOVE PIN.PLACE PIN IN VISE, REMOVE SCHEW FROM PIN.AND ASIDE TOOLS ENDS |
| NAA | 800 | MAA | AMRBNXX | SNFIRXX | WARIABLE 860 210 | RIVET(DEUTSCH DRIVE PINI, INSTALL, ALL SIZES STARTS-WITH GET RIVET INCLUDES-ALL MOTIONS NECESSARY TO POSITION RIVET IN HOLE, GET HAMMER, GET HOLLOW PUNCH, POSITION PUNCH OVER RIVET STEM, DRIVE RIVET HEAD FLUSH WITH SURFACE, AS IDE HAMMER AND PUNCH, GET RIVET GUN, GET AND INSTALL FLUSH RIVET SET, GET AND INSTALL SPRING, POSITION GUN TO DRIVE PIN, DRIVE PIN WITH RIVET GUN, REMOVE SPRING, REMOVE SET, AND AS IDE SPRING AND SET ENDS-WITH AS IDE RIVET GUN CASE OI FIRST RIVET OZ EACH ADDITIONAL RIVET IN A SERIES (DOES NOT INCLUDE GET, SET UP, OR AS IDE TOOLS) |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTOP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION . |
|----------------|-------|---------|----------------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FFD | 800 | MAA | KALSDXX | SNFRDXX | VARIABLE | RIVET, DRILL AND REMOVE, COUNTERSUNK OR UNIVERSAL HEAD STARTS—WITH GET DRILL, DRILL BIT PREVIOUSLY |
| | | | | | | INSTALLED INCLUDES—ALL MOTIONS NECESSARY TO PLACE DRILL TO RIVET HEAD, DRILL RIVET, ASIDE DRILL, GET PUNCH, GET HAMMER, PLACE PUNCH TO RIVET SHANK, AND DRIVE RIVET FROM HOLE |
| | | | | | 556 | ENDS-WITH ASIDE TOOLS CASE OF FIRST ALUMINUM RIVET TO 3/16 INCH DEAMETER |
| | | | | | 351 | O2 EACH ADDITIONAL ALUMINUM RIVET TO 3/16 INCH DIAMETER(NO GET/ASIDE TOOLS) |
| | | | | | 756 | O3 FIRST ALUMINUM RIVET 5/16 INCH DIAMETER OR LARGER(TIME TO DRILL PILOT HOLE ALLOMED, BUT NO TIME TO |
| | | | | | 471 | CHANGE DRILL BIT) O4 EACH ADDITIONAL ALUMINUM RIVET 5/16 INCH DIAMETER OR LARGER(NO GET/ASIDE |
| | | | • | | 1112 | TOOLS) OS FIRST STEEL RIVET 3/32-3/16 IN |
| | | | | | 907 | DIAMETER 06 EACH ADDITIONAL STEEL RIVET 3/32-3/16 INCH DIAMETER(NO GET/ASIDE TOOLS) |
| FFO. | 800 | MAA | _ | SNFRIXX | VARIABLE | RIVET, INSTALL STARTS-WITH GET RIVET GUN AND RIVET(S) INCLUDES-ALL MOTIONS NECESSARY TO PLACE RIVET IN HOLE, PLACE GUN TO RIVET, AND DRIVE RIVET ENDS-WITH ASIDE GUN COMDITIONS-TIME TO SET UP RIVET GUN NOT |
| | | | | | 219 | INCLUDED CASE OF EIRST ALUMINUM RIVET TO 1/4 INCH |
| • | | | | | 144 | OIAMETERIUNE OPERATOR—NO BUCKING BAR) OZ EACH ADDITIONAL ALUMINUM RIVET TO 1/4 |
| | | | | | 1026 | INCH DIAMETER(ONE OPERATOR) 03 FIRST ALUMINUM RIVET 5/16 INCH OR LARGER DIAMETERSTIME SHOWN IS FOR TWO OPERATORS-USE OF BUCKING BAA REQUIRED) |
| | | | | | 876 | 04 EACH ADDITIONAL ALUMINUM RIVET 5/16 INCH OR LARGER DIAMETERITMO JPERATORS. |
| | | | | | 446 | BUCKING BAR REQUIRED) OF FIRST STEEL RIVET TO 3/16 INCH DIAMETER(TIME SHOWN IS FOR TWO OPERATORS.USE OF BUCKING BAR REQUIRED) |
| | | | | | 296 | OF EACH ADDITIONAL STEEL RIVET TO 3/16 INCH DIAMETER (THO OPERATORS.USE BUCKING BAR) |
| FFC | 800 | MAA | KAL SAC 1 | SNFRIO | 7 683 | RIVET.INSTALL.COLLARED FASTENER.3/16-1/4 INCH DIAMETER.FIRST RIVET STARTS-WITH GET FASTENER(S) INCLUDES-ALL MOTIGNS NECESSARY TO PLACE PIN IN HOLE.GET HAMMER.SEAT PIN.ASIDE HAMMER.GET COLLAR.PLACE ON PIN.GET BUCKING BAR.PLACE TO RIVET.GET AND POSITION GUN.SECURE COLLAR ON PIN.AND ASIDE GUN ENDS-WITH ASIDE BUCKING BAR CONDITIONS-NO TIME ALLOWED FOR SETUP OF GUN |
| FF | D 800 | MAA | KAL SAC2 | SNFRIC | 9 335 | RIVET, INSTALL, COLLARED FASTENER 3/16-1/4 INCH DIAMETER, ADDITIONAL RIVET STARTS-WITH FASTENER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO PLACE PIN IN HOLE, SEAT PIN WITH HAMMER, PLACE COLLAR ON PIN, PLACE BUCKING BAR. TO PIN, POSITION GUN TO PIN, AND SECURE COLLAR ENDS-WITH GUN AND BUCKING BAR IN HAND CONDITIONS-NO TIME INCLUDED TO GET/ASIDE FASTENER AND TOOLS |

| | | | | | | · |
|----------------|-----|----------|----------|--------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DATA SOURCE | | QUAL ITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
| FFO | 800 | MAA | KSMRIH1 | SNFR [09 | 703 | RIVET(HI=SHEAR), INSTALL, FIRST STARTS=WITH GET RIVET INCLUDES=ALL MOTIGNS NECESSARY TO POSITION RIVET IN HOLE, GET HAMMER, SEAT RIVET, ASIDE HAMMER, PLACE COLLAR ON RIVET, GET BUCKING BAR, POSITION TO RIVET, GET RIVET GUN, POSITION ON RIVET, DRIVE RIVET, AND ASIDE GUN ENOS=WITH ASIDE BUCKING BAR CONDITIONS=APPLICABLE TO COLLARED STEEL RIVET 3/32=3/16 INCH DIAMETER, NO TIME ALLOWED FOR SETUP OF RIVET GUN |
| FFO | 800 | МАА | KSMR [H2 | SNFRI10 | 466 | RIVET(HI-SHEAR), INSTALL, ADDITIONAL STARTS-WITH REGRASP OF RIVET IN HAND INCLUDES-ALL MOTIONS NECESSARY TO POSITION RIVET IN HOLE, STRIKE RIVET WITH HAMMER TO SEAT, REGRASP COLLAR, PLACE ON RIVET, POSITION GUN TO RIVET, POSITION BUCKING BAR AND DRIVE RIVET ENDS-WITH RIVET INSTALLED CONDITIONS-DOES NOT INCLUDE GET AND/OR ASIDE RIVET, COLLAR, HAMMER, GUN, AND BUCKING BAR. APPLICABLE TO COLLARED STEEL RIVET 3/32-3/16 INCH DIAMETER |
| FFD | 800 | MAA | KALSAB1 | SNFRIII | 525 | RIVET, INSTALL, BLIND, PULLED, ALL TYPES, FIRST RIVET STARTS-WITH GET RIVET GUN AND RIVETS(S) INCLUDES-ALL MOTIGNS NECESSARY TO PLACE RIVET IN GUN, MOVE RIVET TO HOLE, DRIVE RIVET, ASIDE GUN, GET CUTTERS, CUT STEM OF RIVET, ASIDE CUTTERS, GET FILE, AND FILE BURR OFF RIVET STEM ENDS-WITH ASIDE FILE CONDITIONS-NO TIME ALLOWED FOR SETUP OF RIVET GUN |
| FFD | 800 | MAA | KALSAB2 | SNFRI12 | 445 | RIVET, INSTALL, BLIND, PULLED, ALL TYPES, EACH ADDITIONAL RIVET STARTS-WITH RIVET AND RIVET GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO PLACE RIVET IN GUN, PLACE RIVET IN MOLE, OR IVE RIVET, ASIDE GUN, GET CUTTERS, CUT STEM OF RIVET, ASIDE CUTTERS, GET FILE AND REMOVE BURR ENDS-WITH ASIDE FILE CONDITIONS-MO TIME INCLUDED TO GET/ASIDE FASTENER AND TOOLS |
| FFD | 800 | MAA | KAL SOXX | SNFRKXX | VARIABLE 593 348 | RIVET, KNOCK OUT, COLLARED FASTENER, ALUMINUM STARTS-WITH GET GUN WITH KNOCKER ATTACHED INCLUDES-ALL MOTIONS NECESSARY TO PLACE KNOCKER TO COLLAR, REMOVE COLLAR, ASIDE GUN, GET HAMMER, DRIVE FASTENER FLUSH WITH SURFACE, GET PUNCH, AND DRIVE FASTENER FROM HOLE ENOS-WITH ASIDE TOOLS CONOITIONS-APPLICABLE TO HI-SHEAR RIVETS, HI-LOCK FASTENERS, AND STUMP BOLTS CASE OI FIRST COLLARED FASTENER 02 EACH ADDITIONAL COLLARED FASTENER(DOES |
| | | | • | | | NOT INCLUDE GET/ASIDE TOOLS) |

| | | | DEFENSE | WORK AL | 239112712111 | |
|----------------|-----|---------|----------------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION . |
| NAA | 800 | HUA | ONFRDXX | SNFRRXX | VARIABLE | RIVET.REMOVE.SOLID.DRIVEN STARTS-WITH GET TOOL(S) INCLUDES-ALL MOTIONS NECESSARY TO SET UP TOOL(S).CUT RIVET HEAD OR TAIL.ASIDE CUTTING TOOL.GET TOOLS.AND PUNCH OUT RIVET |
| | | | | | | ENDS-WITH ASIDE TOOL(S) CONDITIONS-APPLICABLE TO ALUMINUM OR MONEL RIVET 1/8-3/16 INCH DIAMETER CASE O1 FIRST RIVET.CUT WITH HAMMER AND CHISEL |
| | | | | | 548 | AND DRIVE RIVET DUT WITH HAMMER AND PUNCH |
| | | | | | 254 | OZ EACH ADDITIONAL RIVET USING HAMMER, CHISEL AND PUNCH |
| | | | | | 999 | OB FIRST RIVET, CUT WITH POWER CHISEL AND DRIVE RIVET OUT WITH HAMMER AND PUNCH |
| | | | | | 195 | O4 EACH ADDITIONAL RIVET USING POWER CHISEL, HAMMER, AND PUNCH |
| | | | | | 990 | OS FIRST RIVET, CUT WITH POWER CHISEL AND DRIVE RIVET OUT WITH POWER DRIFT |
| | | | | - | 217 | 06 EACH ADDITIONAL RIVET USING POWER CHISEL AND POWER DRIFT |
| FFD | 800 | TAA | KSMTPOI | вртмнхх | VARIABLE | METAL, HEAT WITH DIMPLING DIE STARTS-WITH MALE AND FEMALE DIES IN CONTACT WITH METAL |
| | | | | • | | INCLUDES-ALL THE PROCESS TIME NECESSARY TO HEAT METAL ENOUGH TO DIMPLE WITHOUT GRACKING EDGES OF DIMPLE |
| | | | | • | | ENDS-WHEN HEAT IS TURNED OFF CONDITIONS-MAGNES IUM AND TITANIUM USED |
| | | | | | 29 | CASE 01 METAL .031 INCH THICK 02 METAL .050 INCH THICK |
| | | | | | 32 37 | 03 METAL .064 INCH THICK |
| | | • | | | 42 35 | 04 METAL .100 INCH THICK 05 METAL ANY THICKNESS=-031 TO .100 INCH(AVERAGE OF TIMES) |
| FFD | 800 | TAA | KSMTPRI | 9PTR SO1 | 257 | RIVET,SET WITH PNEUMATIC GUN,PROCESS TIME ONLY STARTS-WITH ACTUATION OF RIVET GUN SWITCH INCLUDES-ALL THE TIME NECESSARY TO SET UNE |
| | | | • | | | - RIVET ENDS-WITH RELEASE OF SWITCH |
| | | | | | | CONDITIONS-APPLICABLE TO COLLARED STEEL RIVET 3/32-3/16 INCH DIAMETER |
| FFO | 800 | HAA | KSMJPO1 | SSUDSO | 3359 | DIMPLE MACHINE, SET UP(COLD) STARTS-WITH REACH TO GET ALLEN WRENCH INCLUDES-ALL THE MOTIONS NECESSARY TO GET ALLEN WRENCH AND MALE DIE, LOOSEN AND RUN DUT DIE SET SCREW, REMOVE DIE FROM MACHINE AND ASIDE DIE TO RACK, GET FEMALE DIE, LOOSEN AND |
| | | | | | | DIM OUT SET SCREWAREMOVE AND ASIDE DIE TO |
| | | | | | | RACK, GET PROPER DIE FROM RACK, PLACE IN MACHINE AND RUN IN AND TIGHTEN SET SCREW(MALE AND FEMALE DIE), ACTUATE RAM CLOSED, CHECK DIES FOR |
| | | | | • | | GAP, ACTUATE RAM OPEN, GET WRENCH AND LUGSEN PAM ADJUST MUT. ACTUATE RAM CLOSED, ADJUST GAP, |
| | | | | | | OPEN DIMPLING RAM, GET AND PLACE SCRAP METAL OVER DIE-CLOSE AND OPEN DIMPLING RAM, REMOVE |
| | | | | | | AND ASIDE SCRAP, GET RIVET AND PLACE IN DIMPLE HOLE, CHECK FOR PROPER SETTING, ASIDE RIVET, |
| | | | | | | MAKE FINE ADJUSTMENTS ON DIE GAP. ASIDE WRENCH, GET WRENCH, RUN DOWN AND TIGHTEN JAM NUT. ASIDE WRENCH |
| | | | | | | ENDS-WITH ASIDE WRENCH CONDITIONS-TIME IS ALLOWED FOR CHANGING DIES TO HOLE SIZE AND ADJUSTING FOR METAL THICKNESS |

| DATA Soupce | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|-------------|----------------|--------------------|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FFD | 300 | MAA | KSMJPD2 | SSUGA 01 | | GAP(DIE), ADJUST(DIMPLING MACHINE—COLD) STARTS—WITH REACH TO GET WRENCH INCLUDES—ALL THE MOTIONS NECESSARY TO GET WRENCH AND LOOSEN DIE ADJUSTMENT JAM NUT, CLOSE DIMPLING RAM, ADJUST TO PROPER JAP, OPEN DIMPLING RAM, GET METAL SCRAP AND PLACE OVER MALE DIE, CLOSE RAM, OPEN RAM, REMOVE SCRAP FROM DIE AND ASIDE, GET RIVET AND PLACE IN RIVET HOLE, CHECK FOR PROPER SETTING, MAKE FINE ADJUSTMENTS TO DIE GAP, ASIDE RIVET AND WHENCH, GET WRENCH AND RUN DOWN AND TIGHTEN JAM YUT EYDS—WITH ASIDE WRENCH CONDITIONS—THIS ELEMENT COVERS DIE GAP SETTING |
| ₽F E | 800 | MAA | KSMJPD3 | SSUMS01 | 4624 | MACHINE(HOT DIMPLE), SET UP STARTS+bITH REACH TO GET WRENCH INCLUDES-ALL THE MOTIONS NECESSARY TO GET ALLEN WRENCH, LOOSEN HEATER RETAINING SCREW, REMOVE HEATER FROM DIE, SET UP DIMPLE MACHINE, GET AND PLACE HEATER ON DIE, RUN IN AND TIGHTEN CONTROL, ASIDE WRENCH, TURN HEATER ON AND JFF ENDS-WITH TURN HEATER OFF CONDITIONS-ELEMENT INCLUDES TIME TO CHANGE AND ADJUST DIE SET, REMOVE AND INSTALL HEATER DUR- ING PROCESS-USED WHEN HOLE SIZE IN MACHINE IS NOT CORRECT FOR JOB-SEE ELEMENT 800 SSUDSO1 FOR SET UP DIMPLE MACHINE |
| NAA | 800 | МА А | OTLOC XX | STLDFXX | | DIMPLE(COLD), FORM WITH HAND DIMPLER STARTS-WITH REACH TO VISE HANDLE INCLUDES-ALL MOTIONS NECESSARY TO OPEN VISE, GET MALE DIE, PLACE IN VISE, CLOSE VISE, GET PART, POSITION PART TO MALE DIE, GET FEMALE DIE, POSITION DIE TO PART, GET HAMMER, STRIKE FEMALE DIE FOUR BLOWS WITH HAMMER, PALM HAMMER AND DIE, ASIDE PART, ASIDE DIE AND HAMMER, JPEN VISE, REMCVE AND ASIDE MALE DIE, AND CLOSE VISE ENDS-WITH RELEASE OF VISE HANDLE CONDITIONS-APPLICABLE TO USE OF 3/32"-1/4" DIMPLE IN .016"064" STAINLESS STEEL, .025"064" 61S-0-T4 |
| | | | | | 804 201 1356 | CASE OI FIRST OR SINGLE DIMPLE IN PART TO ONE SQUARE FOOT AREA(ONE DPERATOR) OZ EACH ADDITIONAL DIMPLE IN PART TO ONE STANDARD FOOT(ONE OPERATOR) OS FIRST OR SINGLE DIMPLE IN PART ONE TO NINE SQUARE FEET(TIME SHOWN IS FOR TWO |
| | | | | | 308 | OPERATORS) 04 EACH ADDITIONAL DIMPLE IN PART ONE TO NINE SQUARE FEET(TIME SHOWN IS FOR TWO OPERATORS) |
| NF | 804 | MAF | 3337/38 | МОНРРХХ | 91 102 | PIECES, POSITION TO ASSEMBLE PITTSBURGH LOCK SEAM STARTS-WITH SIMO REACH TO PIECES INCLUDES-ALL MOTIONS NECESSARY TO BRING PIECES TOGETHER, ALIGN, CHECK VISUALLY, AND STRIKE WITH HAND TO ASSEMBLE SEAM ENDS-WITH HAND IN CONTACT WITH SEAM CASE 01 SMALL PIECES, TOTAL WEIGHT TO 10 POUNDS ENW 02 LARGE PIECES, TOTAL WEIGHT 10-60 POUNDS ENW |

| DATA Source | OCCUP- ATION | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----------------|---------|----------------|--------------------|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | MUA | AMRDEXX | SFACHXX | VARIABLE | HOLE, CUT IN ALUMINUM TO .064 INCH THICKNESS, RECTANGULAR ACCESS HOLE STARTS-WITH GET MEASURING DEVICE INCLUDES-ALL MOTIONS NECESSARY TO GET MARKING |
| | | | | | | INSTRUMENT, LAY OUT MOLE, MEASURE AND HARR FOR RADIUS PUNCH, CENTER PUNCH FOR RADIUS, SET UP AND PUNCH OUT CORNER RADIUS WITH TURRET PUNCH, CUT HOLE WITH PERFORMENT OF SHEAR, PLACE MATERIAL IN VISE, AND DEBUFR WITH FILE AND EMERY CLOTH EDGS WITH ACCESS HOLE CUT |
| | | | | | 14330 22210 28580 34110 | CONDITIONS—APPLICABLE TO CUTTING ALUMINUM MATERIAL SUCH AS DOUBLER OR FILLER CASE OI CUT HOLE, PERIMETER TO 16 INCHES O2 CUT HOLE, PERIMETER 16—28 INCHES O3 CUT HOLE, PERIMETER 28—40 INCHES O4 CUT HOLE, PERIMETER 40—52 INCHES |
| NA A | 807 | AUM | AMRDEXX | SFADFXX | Z ZARIABLE | DOUBLER(OR FILLER), FABRICATE, FLAT CIRCULAR STARTS-WITH GET MEASURING DEVICE INCLUDES-ALL MOTIONS NECESSARY TO GET MARKING INSTRUMENT; MEASURE MATERIAL FOR ROUGH CUT; POSITION MATERIAL TO SHEAR, TURN AND WALK ONE PAGE TO SWITCH, TURN SWITCH ON, SHEAR MATERIAL (THO CUTS), AND TURN MACHINE OFF, OR CLAMP MATERIAL AND SHEAR ON MANUAL SHEAR(TWO CUTS); WALK SEMINO MACHINE; PICK UP MATERIAL; LAY OUT FOR CIRCULAR CUT; POSITION MATERIAL TO SEVERLY |
| | | | | • • | | SHEAR.CUT CIRCUMFERENCE OF CIRCULAR OBUBLE?, ASIDE SCRAP.OR SET UP AND CUT CIRCULAR SHAPE ON BANDSAW; DRESS CIRCUMFERENCE ON SANDER; AND FINAL DRESS WITH HAND FILE AND EMERY CLOTH. AS REQUIRED—SPLIT DOUBLER WITH SHEARS JR BANCSAW AND DRESS SPLIT SURFACES. ENDS—WITH DOUBLER FABRICATED CONDITIONS—(1) MATERIAL IS ALUMINUM TO |
| | | | | | | INCH THICKNESS. (2) WALKING TO AND TO AND THE MACHINES NOT INCLUDED EXCEPT AS INDICATED. (3) ROUGH CUT COMPUTED AT 90 PER CENT USE OF POWER SHEAR AND 10 PER CENT USE OF MANUAL SHEAR. (4) FINAL CUT OF CIRCUMFERENCE COMPUTED AT 90 PER CENT USE OF BEVERLY SHEAR AND 10 PER AT 90 PER CENT USE OF BEVERLY SHEAR AND 10 PER AT 90 PER CENT USE OF BEVERLY SHEAR AND 10 PER AT 100 PER AND SAME PER PARTY SHEAR AND 10 PER AND 100 PER PARTY SHEAR AND 100 PER PER PARTY SHEAR AND 100 PER PER PARTY SHEAR AND 100 PER PER PER PARTY SHEAR AND 100 PER PER PER PARTY SHEAR AND 100 PER |
| | | - | | | 9640 | CENT USE OF BANDARD COLLAR OCUBLER TO 4 INCHES DIAMETER OZ FABRICATE CIRCULAR DOUBLER 4-7 INCHES |
| | | | | | 13830 | DIAMETER 03 FABRICATE CIRCULAR DOUBLER 7-13 INCHES |
| | • | | . • | | 19100 | DIAMETER 04 FABRICATE CIRCULAR DOUBLER 10-13 |
| | | | | | 22460 26860 | INCHES DIAMETER OS FABRICATE CIRCULAR DOUBLER 13-16 |
| | | | | | 14140 | INCHES DIAMETER OF FABRICATE AND SPLIT CIRCULAR DUUBLER |
| | | | | | 19240 | TO 4 INCHES DIAMETER OF FABRICATE AND SPLIT CIRCULAR DOUBLER |
| | | | | | 25670 | 4-7 INCHES DIAMETER OR FARRICATE AND SPLIT CIRCULAR DOUBLER |
| | | | | | 30000 | 7-10 INCHES DIAMETER 09 FABRICATE AND SPLIT CIRCULAR UUUBLER |
| | | | | | 35360 | IS CARRICATE AND SPLIT CIRCULAR DUUBLEK |

| DATA Source | | QUALITY | SDURCE CODE | DWMSTDP ELEMENT | | · OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | AUA | AMRDEXX | SFAFFXX | VARIABLE | FILLER(OR DOUBLER), FABRICATE, FLAT RECTANGULAR, TO .064 INCH THICK STARTS-WITH MEASURING DEVICE |
| | | | | | | INCLUDES-ALL MOTIONS NECESSARY TO GET MARKING INSTRUMENT: LAY OUT RECTANGULAR SHAPE ON MATERIAL: TURN AND WALK TO SWITCH, TURN SWITCH |
| | | | | | | ON. SHEAR MATERIAL (TWO CUTS), AND TURN MACHINE OFF, OR CLAMP MATERIAL AND CUT ON MANUAL SHEAR (TWO CUTS); WALK BEHIND MACHINE; PICK UP |
| | | • | | | 3 | MATERIAL:DEBURR EDGES AND RADIUS CORNERS WITH POWER SANDER:AND FINAL DRESS WITH FILE AND |
| | | | | | | EMERY CLOTH. AS REQUIRED—SPLIT FILLER ON SHEAR OR BANDSAW. DEBURR WITH POWER SANDER.AND FINAL DRESS WITH |
| | | | | | | FILE AND EMERY CLOTH. ENDS-WITH FILLER FABRICATED. |
| | | | | | | CONDITIONS—(1) TIME FOR WALKING TO AND FROM MACHINES INCLUDED ONLY AS INDICATED. (2) USE OF SHEARS COMPUTED AT 90 PER CENT FOR POWER |
| | | | | | | AND 10 PER CENT FOR MANUAL SHEARS. (3) SPLITTING FILLERS IS COMPUTED AT AD PER |
| | | | | - | | CENT WITH BANDSAW AND 20 PER CENT WITH SHEARS. (4) FIVE PER CENT OF THE SPLIT FILLERS ARE |
| | | | | | 8520 | DEBURRED BY POWER SANDER. CASE OI FABRICATE RECTANGULAR FILLER WITH |
| | | | | • | 10580 | PERIMETER TO 16 INCHES O2 FABRICATE RECTANGULAR FILLER WITH PERIMETER 16-28 INCHES |
| | | | | • | 13180 | 03 FABRICATE RECTANGULAR FILLER WITH PERIMETER 28-40 INCHES |
| * | | | | | 15440 | 04 FABRICATE RECTANGULAR FILLER WITH PERIMETER 40-52 INCHES |
| | | | | | 17500 19550 | OS FABRICATE RECTANGULAR FILLER WITH PERIMETER 52-64 INCHES |
| | | | | | 21610 | O6 FABRICATE RECTANGULAR FILLER WITH PERIMETER 64-76 INCHES O7 FABRICATE RECTANGULAR FILLER WITH |
| | | | | | 23670 | PERIMETER 76-88 INCHES OB FABRICATE RECTANGULAR FILLER WITH |
| • | | | | | 13090 | PERIMETER 88-100 INCHES 09 FABRICATE AND SPLIT RECTANGULAR FILLER |
| | | | | | 16240 | WITH PERIMETER TO 16 INCHES 10 FABRICATE AND SPLIT RECTANGULAR FILLER WITH PERIMETER 16-28 INCHES |
| | | | | | 20000 | 11 FABRICATE AND SPLIT RECTANGULAR FILLER WITH PERIMETER 28-40 INCHES |
| | | | | | 23360 | 12 FABRICATE AND SPLIT RECTANGULAR FILLER WITH PERIMETER 40-52 INCHES |
| | | | | | 26520 29660 | 13 FABRICATE AND SPLIT RECTANGULAR FILLER WITH PERIMETER 52-64 INCHES 14 FABRICATE AND SPLIT RECTANGULAR FILLER |
| | | • | | • | 32010 | WITH PERIMETER 64-76 INCHES 15 FABRICATE AND SPLIT RECTANGULAR FILLER |
| | | | | | 35960 | WITH PERIMETER 76-88 INCHES 16 FASRICATE AND SPLIT RECTANGULAR FILLER WITH PERIMETER 88-100 INCHES |
| NAA | 807 | MUA A | AMRDEXX | SF AHC X X | VARTABLE | HOLE, CUT IN ALUMINUM TO .364 INCH THICKNESS, CIRCULAR ACCESS HOLE |
| | | | | | | STARTS-WITH GET MEASURING DEVICE INCLUDES-ALL MOTIONS NECESSARY TO GET MARKING |
| | | | | | | INSTRUMENT, LAY OUT HOLE, CENTER PUNCH, SET UP AND PUNCH HOLE WITH TURRET PUNCH, CUT HOLE WITH |
| | | | | | | COMPOUND LEVER SNIPS.GET POWER TOOL, INSTALL ROTARY FILE.FINISH HOLE, AS IDE TOOL, AND DRESS HOLE WITH FILE AND EMERY CLOTH |
| | | | | | 21900 | ENDS-WITH HOLE CUT CASE 01 CUT HOLE, 2-5 INCHES DIAMETER |
| | | | | | 32140 40450 46900 | 02 CUT HOLE,5-8 INCHES DIAMETER 03 CUT HOLE,8-11 INCHES DIAMETER |
| | | | | | 46900 | 04 CUT HOLE, 11-14 INCHES DIAMETER |

| DATA SOURCE | OCCUP- ATION | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----------------|---------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FFD | 807 | MAA | KSMJPFI | HJPTPO1 | 922 | TOOLS, PREPARE FOR JC-BOLT INSTALLATION STARTS-WITH TURN TO TOOL CARRIER OR TOOLBOX INCLUDES-ALL MOTIONS NECESSARY TO GET TRAY FROM CARRIER; GET HOOK GAUGE, GUN, AND JC-BOLT SET FROM CARRIER AND PLACE IN TRAY; GET TRAY; TURN TO WORK AREA; PLACE TRAY IN WORK AREA; GET GUN; GET. SET; INSTALL SET ON GUN; CONNECT AND DISCONNECT AIR HOSE; REMOVE SET FROM GUN; PLACE GUN AND SET IN TRAY; GET TRAY; TURN TO CARRIER OR TOOLBOX; AND PLACE TOOLS AND TRAY IN CARRIER ENOS-WITH RELEASE OF TRAY |
| DNA | 807 | MBA | AMR SJØ1 | SJPCIOL | 1330 | CARTRIDGE(SEALANT), INSTALL IN AND REMOVE FROM GUN STARTS-WITH GET GUN INCLUDES-ALL MOTIONS NECESSARY TO REMOVE BACK OF GUN, GET CARTRIDGE, INSERT IN GUN, REPLACE BACK OF GUN, INSTALL AND CUT TIP, REMOVE BACK OF GUN, REMOVE AND ASIDE CARTRIDGE, GLEAN GUN, AND REPLACE BACK OF GUN ENOS-WITH ASIDE GUN CONDITIONS-APPLICABLE TO AIR OPERATED SEMCO GUN AND TWO OUNCE CARTRIDGE |
| NAA | 807 | MAĀ. | AMRQR XX | MNFGRXX | VARIABLE | GROMMET (AND STUD), REMOVE, DZUS FASTENER, MANUAL MOTIONS ONLY STARTS-WITH GET PORTABLE ORILL INCLUDES-ALL MOTIONS NECESSARY TO GET CUTTER, INSTALL IN DRILL CHUCK, POSITION CUTTER TO GROMMET, ASIDE CUTTER, GET BAR, POSITION UNDER STUD HEAD, GET HAMMER, STRIKE STUD, ASIDE BAR AND STUD.GET CHISEL, POSITION TO GROMMET, DRIVE GROMMET OUT WITH HAMMER AND CHISEL, ASIDE HAMMER AND CHISEL, GET ROTARY FILE, INSTALL IN DRILL CHUCK, AND REMOVE ROTARY FILE ENDS-WITH ASIDE ORILL AND ROTARY FILE CONDITIONS-PROCESS TIME FOR CUTTING AND FILING |
| • | | | | | 2155 712 | A CLOSE COMMET AND STUD |

| DATA Source | | QUALITY | SOURCE | DWMSTDP ELEMENT | THU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|------------|---------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | AUA | ONFSDXX | SNECCXX | VARIABLE | COLLAR, CUT FROM DRAW TYPE SHEAR PIN STARTS-WITH GET TOOL(S) TO CUT COLLAR INCLUDES-ALL MOTIONS NECESSARY TO POSITION TOOL TO COLLAR, CUT COLLAR, AND ASIDE TOOL(S). CASES 01-08 ALSO INCLUDE DRIVE PIN OUT WITH HAMMER AND DRIFT. ENDS-WITH RELEASE OF TOOLS CONDITIONS-ADDITIONAL PIECES DO NOT INCLUDE GET AND ASIDE TOOLS-APPLICABLE TO HUCK PULL TYPE SHEAR PIN OR SIMILAR TO 3/8 INCH DIAMETER, ANY LENGTH |
| | | | | | 616 | CASE OL CUT FIRST COLLAR WITH HUCK GUN MODEL |
| | | | | | 358 | 352,200,0R SIMILAR AND DRIVE OUT PIN OZ CUT EACH ADDITIONAL COULAR WITH HUCK |
| | | | | | 621 | GUN AND DRIVE OUT PIN 03 CUT FIRST COLLAR WITH BOLT CUTTER AND DRIVE OUT PINIBOLT CUTTER EQUIPPED WITH JAWS SPECIALLY DESIGNED TO CUT HUCK COLLAR) |
| | | | | | 317 | 04 CUT EACH ADDITIONAL COLLAR WITH BOLT |
| | | | | | 1081 | CUTTER AND DRIVE DUT PIN 05 CUT FIRST COLLAR WITH RIVET GUN AND |
| | | | | | 204 | CHISEL, DRIVE OUT PINIINCLUDES ATTACH AND REMOVE CHISEL) |
| | | | | | 294 | O6 CUT EACH ADDITIONAL COLLAR WITH RIVET GUN AND CHISEL, AND CRIVE OUT PIN |
| | | | | | 935 | O7 CUT FIRST COLLAR WITH HAMMER AND CHISEL, AND DRIVE PIN OUT |
| | | | | •• | 611 | OB CUT EACH ADDITIONAL COLLAR WITH HAMMER AND CHISEL, AND DRIVE PIN OUT |
| | | | | | 186 | 09 CUT FIRST COLLAR WITH HUCK GUN MODEL 352,200 OR SIMILAR |
| | | | | | 125 | 10 CUT EACH ADDITIONAL COLLAR WITH HUCK |
| | | | | | 171 | 11 CUT FIRST COLLAR WITH BOLT CUTTER WITH JAWS SPECIALLY DESIGNED FOR REMOVAL OF HUCK COLLARS |
| • | | | | | 84 | 12 CUT EACH ADDITIONAL COLLAR WITH BOLT CUTTER |
| | | | • | | 641 | 13 CUT FIRST COLLAR WITH RIVET GUN AND CHISEL(INCLUDES ATTACH AND REMUVE |
| | | | | • | 45 | CHISEL BLADE) 14 CUT EACH ADDITIONAL COLLAR WITH RIVET |
| | | | | | 680 | GUN AND CHISEL 15 CUT FIRST COLLAR WITH HAMMER AND |
| | | | | | 472 | CHISEL 16 CUT EACH ADDITIONAL COLLAR WITH HAMMER |
| | | | | | | AND CHISEL |
| NAA | 807 | MAA | AMRAN17 | SNFF101 | 497 | FASTENER(ANCHORED), INSTALL MISSING FLOATING OR CHANNEL NUT ONLY, ALL TYPES, FIRST PIECE STARTS-WITH GET NUT PLATE ASSEMBLY INCLUDES-ALL MOTIONS NECESSARY TO GET NUT PLATE ASSEMBLY, POSITION FOR NUT REMOVAL, GET DUCK BILL PLIERS, BEND TWO TABS WITH PLIERS, ASIDE PLATE(NUT DROPS TO BENCH), GET NUT, POSITION TO EXISITNG ATTACHED PLATE, HOLD FIRMLY IN PLACE, BEND TABS AROUND PLATE, ASIDE PLIERS, CHECK ALIGNMENT AND FREENESS OF NUT ENDS-WITH RELEASE NUT |
| NAA | 807 | MAA | AMRAN18 | SNFF102 | 454 | FASTENER (ANCHORED), INSTALL MISSING FLOATING OR CHANNEL NUT ONLY, ALL TYPES, ADDITIONAL PIECE STARTS-WITH GET NUT PLATE ASSEMBLY INCLUDES-ALL MOTIONS NECESSARY TO GET NUT PLATE ASSEMBLY, POSITION FOR NUT REMOVAL, USE DUCK BILL PLIERS TO BEND TWO TABS, ASIDE PLATE(NUT DROPS TO BENCH), GET NUT, POSITION TO EXISTING ATTACHED PLATE, HOLD FIRMLY IN PLACE AND BEND TWO TABS OVER PLATE, ASIDE PLIERS, CHECK ALIGNMENT AND FREENESS OF NUT ENDS-WITH RELEASE NUT |

| DATA | OCCUP- ATION | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | UPERATION/ ELEMENT DESCRIPTION |
|-------|-----------------|----------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AAF | 807 | AUA | AMR 4N34 | SNFF103 | 3610 | FASTENER (ANCHORED), INSTALL CAMLOC OR AIRLJC RECEPTACLE, OR DZUS SPRING, 1-MAN OPERATION, FIRST PIECE STARTS-WITH GET CLECO AND CLECO PLIERS INCLUDES-ALL MOTIONS NECESSARY TO INSTALL AND REMCVE CLECOIPLIER OR WING TYPE), HOLD FASTENER IN PLACE, INSTALL AND BUCK RIVET(RIVET GUN OR PORTABLE PNEUMATIC "C" SQUEEZE), MICRJSHAVE RIVET, PLUG IN AND OUT AIR HOSE FOR REAM. REAM HOLE FOR MISALIGNMENT, PLUG IN AND JUT AIR HOSE (DUE TO REAM), INSTALL AND BUCK SECOND RIVET, MICROSHAVE RIVET ENDS-WITH ASIDE MICROSHAVER CONDITIONS-PLUG IN AND OUT FOR REAM, REAM HOLE FOR ALIGNMENT AND PLUG IN AND OUT AIR HOSE TO GUN DUE TO REAM ARE REQUIRED TO PERCENT OF THE TIME. MICROSHAVE RIVETS REQUIRED 75 PERCENT OF THE TIME, MICROSHAVER IS PFAHLER MODEL 33A OR MICRO MILLER MODEL BRM |
| NAA | 307 | AUM | AMP 4 N 3 5 | SNFFI 04 | 1840 | FASTENER (ANCHORED), INSTALL CAMLOC OR AIRLUC RECEPTACLE, OR DZUS SPRING, 1-MAN OPERATION, ADDITIONAL PIECE |
| | | | | | | STARTS-WITH GET CLECO AND CLECU PETERS INCLUDES-ALL MOTIONS NECESSARY TO INSTALL AND REMOVE CLECO(PLIER OR WING TYPE), HULD FASTENER IN PLACE, INSTALL AND BUCK RIVET(RIVET GUY OR |
| | | | | • | | RIVET, PLUG IN AND OUT AIR HOSE FOR REAT, |
| | | | | | | ENDS-WITH ASIDE MICROSHAVER CONDITIONS-PLUG IN AND OUT AIR HOSE FOR REAM, REAM HOLE FOR ALIGNMENT AND PLUG IN AND OUT AIR HOSE TO GUN DUE TO REAM ARE REQUIRED 10 PERCENT OF THE TIME. MICROSHAVE RIVETS |
| | | | | | | REQUIRED 75 PERCENT OF THE TIME. MICKUSHAVER IS PEAHLER MODEL 33A OR MICRO MILLER MODEL 3RM |
| ~ Δ.4 | 807 | MUA | AMR AN 3 | SNFF10 | 5770 | FASTENER (ANCHOPED), INSTALL CAMLOC OR AIRLIC RECEPTACLE, OR DZUS SPRING, 2-MAN OPERATION, FIRST PIECE STARTS-WITH GET CLECO AND CLECO PLIFRS |
| | | | | | | STARTS—BITM GET CLESS NECESSARY TO INSTALL AND INCLUDES—ALL MOTICNS NECESSARY TO INSTALL AND REMOVE CLECO(PLIER OR WING TYPE), HOLD FASTENER IN PLACE, INSTALL AND BUCK RIVET, MICRUSHAVE RIVET, PLUG IN AND TOO OHA ALL AND HOLE FOR MISALIGHMENT, PLUG IN AND TOO OH ALL ALL AND BUCK SECOND RIVET, MICROSHAVE RIVET |
| | | | | | | ENDS-WITH ASIDE MICROSHAVER CONDITIONS-PLUG IN AND OUT AIR HOSE FOR REAM, REAM HOLE, AND PLUG IN AND OUT AIR HOSE TO GUN OUE TO REAM ARE REQUIRED 10 PER- CENT OF THE TIME. MICROSHAVE RIVETS REQUIRED TO REPORT OF THE TIME, MICROSHAVER MODEL |
| | | | | _ | | 33 A OR MICRO MILLER MODEL BRM |

| DATA Source | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MAA | 907 | MUA · | AMRAN37 | SNFF106 | 3250 | FASTENER (ANCHORED), INSTALL CAMLOC OR AIRLIC RECEPTACLE OR OZUS SPRING, 2-MAN OPERATION, ADDITIONAL STARTS-WITH GET CLECO AND CLECO PLIERS INCLUDES-ALL THE MOTIONS NECESSARY TO INSTALL AND REMOVE CLECO(PLIER OR WING TYPE), HULU FASTENER IN PLACE, PLUG IN AND OUT AIR HOSE FOR REAM, REAM HOLE FOR MISALIGNMENT, PLUG IN AND OUT AIR HOSE TO GUN, INSTALL AND BUCK SECOND RIVET, MICROSHAVE RIVET ENDS-WITH ASIDE MICROSHAVER CONDITIONS-PLUG IN AND OUT AIR HOSE FOK REAM, REAM HOLE, AND PLUG IN AND OUT AIR HOSE TO GUN DUE TO REAM ARE REQUIRED 10 PERCENT JF THE TIME. MICROSHAVER MODEL PFAMLER HODEL 33A OR MICRO MILLER MODEL BRM. |
| NAA . | 807 | MUA | CMRANG1 | SNFF107 | 18850 | FASTENER (ANCHORED), INSTALL CHANNEL NUT ASSEMBLY WITH BLIND RIVETS, FIRST OR SINGLE THREE-NUT LENGTH STARTS-WITH GET LENGTH OF CHANNEL INCLUDES-ALL MOTIONS NECESSARY TO CUT CHANNEL TO LENGTH WITH COMPOUND LEVER SNIPS. DEBURR CHANNEL END WITH FILE, MEASURE AND MARK HOLE LOCATIONS, CENTER PUNCH HOLE LOCATIONS, SET UP PORTABLE DRILL, DRILL HOLES, DEBURR HOLES WITH HAND HELD DRILL BIT, INSTALL TEMPORARY SCREWS WITH SCREWDRIVER, SET UP RIVET GUN, INSTALL BLIND RIVETS AND REMOVE TEMPORARY SCREWS ENDS-WITH ASIDE SCREWS AND SCREWDRIVER |
| NAA | 807 | MUA | CMRANXX | SNFFIOR | 4530 | FASTENER (ANCHORED), INSTALL CHANNEL NUT ASSEMBLY WITH BLIND RIVETS, EACH ADDITIONAL THREE-NUT LENGTH STARTS-WITH MEASURE FOR ADDITIONAL HOLES INCLUDES-ALL MOTIONS NECESSARY TO MEASURE AND MARK FOR ADDITIONAL HOLES, CENTER PUNCH, OR ILL AND DEBURR ADDITIONAL HOLES, SECURE WITH SCREW, INSTALL BLIND RIVET AND REMOVE SCREW ENDS-WITH ASIDE SCREW |
| NAA | 807 | MUA | CMRANO3 | SNFF109 | 14970 | FASTENER (ANCHORED), INSTALL CHANNEL NUT ASSEMBLY TO EXISTING HOLES WITH BLIND RIVETS, FIRST OR SINGLE THREE-NUT LENGTH STARTS-WITH GET LENGTH OF CHANNEL INCLUDES-ALL MOTIONS NECESSARY TO CUT CHANNEL TO LENGTH WITH COMPOUND LEVER SNIPS, JEBURR CHANNEL END WITH FILE, INSTALL TWO TENDARY SCREWS WITH SCREWDING TO STALL HOLES FOR RIVETS, COUNTERSING HOLES, I STALL TWO BLIND RIVETS, AND REMOVE TEMPORARY SCREWS ENDS-WITH ASIDE SCREWS AND SCREWSIVER |
| AAM | 807 | MUA | CMRANO4 | SNFF110 | 2880 | FASTEMER(ANCHORED), INSTALL CHANNEL NUT ASSEMBLY TO EXISTING HOLES WITH BLIND RIVETS, EACH ADDITIONAL THREE-NUT LENGTH STARTS-WITH INSTALL ONE TEMPORARY SCREW INCLUDES-ALL MOTIONS NECESSARY TO DRILL AND COUNTERSINK DNE HOLE, INSTALL BLIND RIVET, AND REMOVE TEMPORARY SCREW ENDS-WITH ASIDE SCREW |

OPERATION/ ELEMENT DESCRIPTION OWMSTDP TMU DATA CCCUP- QUALITY SOURCE CODE ELEMENT VALUE SOURCE ATTON FASTENER (ANCHORED), INSTALL NUT PLATE, L-MAN OPERATION, ALL TYPES, FIRST PIECE 5390 SNFFILL AMRAN30 ΝΔΔ 807 AUA STARTS-WITH GET TOOLS
INCLUDES-ALL MOTIONS NECESSARY TO SECURE
FASTENER WITH SCREW, INSTALL RIVET(WITH RIVET
GUN AND BUCKING BAR OR PORTABLE PNEUMATIC "C"
SQUEEZEJ, MICROSHAVE RIVET, INSTALL ADDITIONAL
RIVET, PLUG IN AND OUT AIR HOSE FOR REAM, REAM
HOLE FOR MISALIGNMENT, PLUG IN AND OUT AIR HOSE
DUE TO REAM, MIGROSHAVE SECOND RIVET STARTS-WITH GET TOOLS ENDS-WITH ASIDE MICROSHAVER
CONDITIONS-REAM HOLE FOR MISAL IGNMENT REQUIRED
13 PERCENT OF THE TIME.MICROSHAVE RIVETS
REQUIRED 75 PERCENT OF THE TIME.MICROSHAVER MODEL 33A OR MICRO MILLER MODEL BRM. FASTEMER (ANCHORED), INSTALL NUT PLATE, 1-MAN
OPERATION, ALL TYPES, ADDITIONAL
STARTS-WITH GET SCREW TO SECURE FASTEMER
INCLUDES-ALL MOTIONS NECESSARY TO SECURE
FASTEMER WITH SCREW, INSTALL RIVETS, MICROSHAVE SNFFI12 AMRAN31 3180 MUA NAA 807 RIVETS , AND REAM HOLE TO CORRECT MISALIGNMENT AS NECESSARY CONDITIONS-NO TIME INCLUDED FOR TOOL SETUP.
REAM HOLE FOR MISALIGNMENT REQUIRED 10 PERCENT
OF THE TIME.MICROSHAVE RIVETS REQUIRED 75 ENDS-WITH ASIDE MICROSHAVER PERCENT OF THE TIME MICROSHAVER MODEL 334 OR MICRO MILLER MODEL BRM USED.

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP FLEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| *: △ △ | 807 | MUA | WHE PAXX | SNFFPXX | VARIABLE | FASTENER (ANCHORED), PREPARE HOLE AND INSTALL STARTS-WITH MEASURE FOR HOLE LOCATION INCLUDES-ALL MOTIONS NECESSARY TO MEASURE AND |
| | | | | | | MARK FOR HOLE LOCATION. CENTER PUNCH LOCATION, DRILL HOLE, DEBURR HOLE, SECURE NUT PLATE WITH SCREW. DRILL HOLE, INSTALL FIRST RIVET; OR ILL HOLE, INSTALL ADDITIONAL RIVET; AND REMOVE SCREWENDS WITH ASIDE TOOLS |
| | | | | | 16780 | CASE OI PREPARE HOLE AND INSTALL NUT PLATE, ALL TYPES FIRST PIECE |
| | | | • | | 5140 | OZ PREPARE HOLE AND INSTALL NUT PLATE, ALL TYPES, ADDITIONAL PIECE |
| | | | | | 19690 | O3 PREPARE HOLE AND INSTALL NUT PLATE, ALL TYPES, 2-MAN OPERATION, FIRST PIECE |
| | | | | • | 7300 | 04 PREPARE HOLE AND INSTALL PLATE, ALL TYPES, 2-MAN OPERATION, ADDITIONAL PIECE |
| | | | | | 16480 | OS PREPARE HOLE AND INSTALL CAMLOC JR AIRLOC RÉCEPTACLE DR DZUS SPRING, ALL TYPES, FIRST PIÈCE |
| | | | | | 4550 | J6 PREPARE HOLE AND INSTALL CAMLOC OR AIRLOC RECEPTACLE OR DZUS SPRINGLALL |
| | | | | | 18780 | TYPES.ADDITIONAL PIECE 37 PREPARE HOLE AND INSTALL CAMLOC JR AIRLOC RECEPTACLE OR DZUS SPRING.ALL |
| | | | | | 6220 | TYPES,2-MAN DPERATION,FIRST PIECE DB PREPARE HOLE AND INSTALL CAMLOC OR ATPLOC RECEPTACLE OR DZUS SPRING,ALL |
| | | | | • | 2200 | TYPES, 2-MAN OPERATION, ADDITIONAL OP PREPARE HOLE AND INSTALL FLAT HEAD RIV-NUT, ALL SIZES, FIRST PIECE |
| | | | | • . | 1070 | 10 PREPARE HOLE AND INSTALL FLAT HEAD RIV-NUT, ALL SIZES, ADDITIONAL PIECE |
| | | | | | 4710 | 11 PREPARE HOLE AND INSTALL FLUSH-HEAD RIV-NUT, ALL SIZES, FIRST PIECE |
| | | | *. | | 1190 | 12 PREPARE HOLE AND INSTALL FLUSHMHEAD RIV-NUT, ALL SIZES, ADDITIONAL PIFCE |
| | | | | | 2480 | 13 PREPARE HOLE AND INSTALL FLAT HEAD DILL NUT, ALL SIZES, FIRST PIECE |
| | ٠. | | | | 1250 | 14 PREPARE HOLE AND INSTALL FLAT HEAD DILL NUTFALL SIZES ADDITIONAL PIECE |
| | | | | | 4990 | 15 PREPARE HOLE AND INSTALL FLUSH-HEAD DILL NUT, ALL SIZES, FIRST PIECE |
| | | | | | 1370. | 16 PREPARE HOLE AND INSTALL FLUSH-HE3D DILL NUT, ALL SIZES, AUDITIONAL PIECE |

| | | | | | | • |
|----------------|-----|----------|----------------|--------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DATA Source | | QUAL ITY | SOURCE CODE | OWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
| NAA | 807 | MUA | AMRARXX | SNFFRXX | VARIABLE | FASTENER(ANCHORED), REPLACE STARTS-WITH REACH TO TOOL OR FASTENER INCLUDES-ALL MOTIONS REQUIRED TO REMOVE AND INSTALL VARIOUS TYPES OF ANCHORED FASTENERS |
| | | | | | 7037 | ENDS-WITH REPLACEMENT FASTENER INSTALLED CASE 01 REMOVE AND INSTALL NUT PLATE, 1-MAN OPERATION. ALL TYPES, FIRST PIECE |
| | | | | | 3882 | 02 REMOVE AND INSTALL NUT PLATE, 1-MAN OPERATION, ALL TYPES, ADDITIONAL PIECE |
| | | | | | 9677 | 03 REMOVE AND INSTALL NUT PLATE, ALL |
| | | | | | 5782 | TYPES, 2-MAN OPERATION, FIRST PIECE 04 REMOVE AND INSTALL NUT PLATE, ALL |
| | | | | | | TYPES, 2-MAN OPERATION, ADDITIONAL PIECE |
| | | | | | 5257 | O5 REMOVE AND INSTALL CAMLOC OR AIRLOC RECEPTACLE OR DZUS SPRING.ALL TYPES. 1-MAN OPERATION.FIRST PIECE |
| | | | | | 2542 | O6 REMOVE AND INSTALL CAMLOC OR AIRLOC RECEPTACLE OR DZUS SPRING-ALL TYPES, |
| | | | | | 7417 | 1-MAN OPERATION, ADDITIONAL PIECE O7 REMOVE AND INSTALL CAMLOC OR AIRLOC |
| | | | | | 7417 | RECEPTACLE OR DZUS SPRING ALL TYPES, 2-MAN OPERATION FIRST PIECE |
| | | | | | 3952 | OB REMOVE AND INSTALL CAMLOC OR AIRLOC RECEPTACLE OR DZUS SPRING, ALL TYPES, |
| | | | | | 1150 | 2-MAN CPERATION, ADDITIONAL PIECE OP REMOVE AND INSTALL RIV-NUT, ALL TYPES, |
| | | | | | 1158 | FIRST PIECE 10 REMOVE AND INSTALL RIV-NUT, ALL TYPES, |
| | | | | | 804 | ADDITICNAL PIECE 11 REMOVE AND INSTALL DILL NUT, ALL TYPES |
| | | | | | 1665 | FIRST PIECE 12 REMOVE AND INSTALL DILL NUT, ALL TYPES |
| | | | | | 1456 | ADDITIONAL PIECE 13 REMOVE AND INSTALL FLOATING OR CHANNEL |
| | | | , | | 726 | NUT ONLY, FIRST PIECE 14 REMOVE AND INSTALL FLOATING OR CHANNEL |
| | | | | | 635 | NUT DNLY, ADDITIONAL PIECE 15 REMOVE AND INSTALL CHANNEL NUT |
| | | | • | | 17699 | ASSEMBLY THREE-NUT LENGTH OF CHANNEL. FIRST |
| • | | | • | | 3787 | 16 REMOVE AND INSTALL CHANNEL NUT ASSEMBLY, THREE—NUT LENGTH OF CHANNEL, ADDITIONAL |
| NAA | 807 | MBA | AMRQNXX | SNFGIXX | VARIABLE | GROMMET (CAMLOC), INSTALL WITH SNAP RING |
| | | | | | | STARTS-WITH GET SNAP RING TOOL INCLUDES-ALL MOTIONS NECESSARY TO REMOVE |
| · | | | | | | RUBBER PROTECTIVE KNOB.GET MANDREL.GET SNAP RING.POSITION SNAP RING ON MANDREL.POSITION |
| | | | | | | SNAP RING TOOL OVER MANDREL, GET GROMMET. |
| | | | | • | | POSITION TO HOLE, INSTALL SNAP RING ON GRUMMET, AND PLACE RUBBER PROTECTIVE KNOB ON TOOL |
| | | • | | | | ENDS-WITH ASIDE TOOLS CONDITIONS-APPLICABLE TO 4002 GROMMET SERIES |
| | | | | | | WITH RAG OR 40G26-L SNAP RINGS |
| | | | | | 744 311 | CASE O1 FIRST GROMMET O2 EACH ADDITIONAL GROMMET |
| NAA | 807 | MAA | AHRQRXX | SNFGRXX | VARIABLE | GROMMET (CAMLOC).REMOVE.SECURED WITH SNAP KING STARTS-WITH GET TOOL TO REMOVE SNAP RING INCLUDES-ALL MOTIONS NECESSARY TO REMOVE SNAP RING USING POINTED TOOL AND PLIERS.AND TO REMOVE GROMMET ENDS-WITH ASIDE GROMMET |
| | | | | | 752 | CASE O1 FIRST GROMMET AND SNAP RING |
| | | | | | 672 | 02 EACH ADDITIONAL GROMMET AND SNAP RING |

| DATA | | QUALITY | 30PUGE 3000 | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|------------|-----|---------------------|----------------|--------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | ™& & | AMRQNXX | SNFIGXX | VARIABLE | GROWNET (AND STUD), INSTALL, DZUS FASTENER, USING PNEUMATIC FLOOR DIMPLER STARTS-WITH GET MATERIAL INCLUDES-ALL MOTIONS NECESSARY TO MOVE MATERIAL TO BOTTOM ANVIL OF DIMPLER, GET GROMMET, POSITION GROMMET IN HOLE, POSITION MATERIAL TO BOTTOM ANVIL, GET STUD, POSITION IN GROMMET, ACTUATE MACHINE WITH FOOT PEDAL, AND CHECK SECURITY OF INSTALLATION ENDS-WITH ASIDE MATERIAL |
| | | | | | 315 255 | CASE OI FIRST DZUS FASTENER 02 EACH ADDITIONAL DZUS FASTENER IN SAME PIECE OF MATERIAL |
| NAA | 807 | MAA | SMFNNXX | SNFINXX | VARIABLE | NUT(CHANNEL), INSTALL STARTS-WITH GET CHANNEL NUT ASSEMBLY INCLUDES-ALL MOTIONS NECESSARY TO POSITION CHANNEL, GET DIAGONAL PLIERS, CUT CHANNEL TO LENGTH, ASIDE PLIERS, GET FILE, SMOOTH CUT END, ASIDE FILE, POSITION CHANNEL, INSTALL TWO SCREWS WITH SCREWORIVER, GET DRILL MOTOR, INSTALL DRILL, DRILL TWO HOLES, REMOVE DRILL, INSTALL COUNTERSINK, COUNTERSINK TWO HOLES, REMOVE COUNTERSINK, ASIDE OR ILL MOTOR, GET RIVET GUN, INSTALL SPRING AND SET, INSTALL THO RIVETS, REMOVE SPRING AND SET, INSTALL THO RIVETS, REMOVE SPRING AND SET, FROM RIVET GUN, ASIDE RIVET GUN, AND REMOVE TWO SCREWS ENDS-WITH ASIDE SCREWDRIVER CONDITIONS-APPLICABLE TO DRILLING NO.45-NO.14 DIAMETER HOLES IN .063090 INCH THICKNESS ALUMINUM AND COUNTERSINKING WITH 1/8-5/32 INCH |
| | ٠ | | | | 5298 1078 | SETUP TIME FOR DRILL, COUNTERS INK OR RIVET GUN CASE OI FIRST TWO-NUT LENGTH OF CHANNEL OZ EACH ADDITIONAL ONE-NUT LENGTH OF A CHANNEL (INSTALL AND REMOVE ONE SCREW, DRILL AND COUNTERS INK ONE HOLE, AND INSTALL ONE RIVET) |
| NAA | 807 | MBA | AMR QN XX | SNFISXX | VARIABLE | STUD(AIRLOC), INSTALL, PER STUD STARTS-WITH GET AIRLOC STUD INCLUDES-ALL MOTIONS NECESSARY TO GET PIN, POSITION STUD IN HOLE, POSITION PIN IN STUD SHANK, GET TOOL, AND SECURE PIN IN SHANK ENOS-WITH ASIDE TOOL CASE 01 INSTALL STUD WITH AIRLOC TOOL |
| FFO | 807 | МДД | KSMANA1 | SNFNIXX | 312 VARTABLE | NUT(ANCHOR), INSTALL IN EXISTING HOLES, EASY ACCESS STARTS—WITH GET ANCHOR NUT INCLUDES—ALL MOTIONS NECESSARY TO POSITION ANCHOR NUT TO HOLES, GET CLECO PLIERS, GET AND INSTALL CLECO, ASIDE PLIERS, GET RIVET GUN, GET AND INSTALL SET, GET AND INSTALL SPRING, CONNECT AIR HOSE, GET FIRST RIVET, PLACE RIVET IN HOLE, GET BUCKING BAR AND POSITION TO RIVET, POSITION GUN AND DRIVE RIVET, ASIDE BUCKING BAR, MOVE GUN TO ONE SIDE, INSPECT INSTALLATION, GET CLECD PLIERS, REMOVE CLECO, ASIDE PLIERS AND CLECD, GET SECOND RIVET, PLACE IN HOLE, GET AND PLACE BUCKING BAR, MOVE RIVET GUN TO RIVET, DRIVE RIVET, ASIDE BUCKING BAR, DISCONNECT AIR HOSE, ASIDE RIVET GUN, AND INSPECT INSTALLATION ENOS—WITH ASIDE INSPECTION LIGHT CONDITIONS—APPLICABLE TO 3/32—3/16 INCH DIAMETER SOLID HEAD RIVET CASE OI FIRST ANCHOR NUT |
| | | | | | 1933 | 02 EACH ADDITIONAL ANCHOR NUT |

| DATA SOURCE | | QUAL [TY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ₽€D | 807 | MAA | KSMANA 3 | SNFNI 03 | 4502 | NUT(ANCHOR), INSTALL, DRILL NEW HOLES USING ANCHOR NUT AS DRILL GUIDE, FIRST NUT, FASY ACCESS STARTS-WITH GET ANCHOR NUT INCLUDES-ALL MOTICNS NECESSARY TO POSITION NUT FOR DRILLING, GET ORILL MOTOR, GET AND INSTALL ORILL, CGNNECT AIR HOSE, DRILL THO HOLES, OISCUNNECT AIR HOSE, DISASSEMBLE AND ASIDE DRILL, GET AND INSTALL SCREW, INSTALL THO CLECOS, REMOVE THO CLECOS, COUNTERSINK THU HOLES, INSTALL THO RIVETS, AND REMOVE SCREW ENDS-WITH ASIDE SCREWDRIVER CONDITIONS-APPLICABLE TO DRILLING HOLE TO 3/16 INCH DIAMETER IN ALUMINUM OR MAGGESIUM T), 100 INCH THICKNESS AND INSTALLING 3/32-3/16 INCH DIAMETER SOLID HEAD RIVET |
| FFD | 807 | AAM . | KSMANA4 | SNFNI 04 | 2863 | NUT(ANCHER).INSTALL, EASY ACCESS.ORILL VEW HOLES USING ANCHOR NUT AS DRILL GUIDE, EACH ADDITIONAL NUT |
| | | | | • | | STARTS-WITH GET ANCHOR NUT INCLUDES-ALL MOTIONS NECESSARY TO POSITION NUT FOR DPILLING-DRILL TWO HOLES-GET AND INSTALL HOLDING SCREW-INSTALL AND REMOVE TWO CLEODS, COUNTERSINK TWO HOLES, INSTALL TWO RIVETS AND REMOVE HOLDING SCREW ENDS-WITH ASIDE SCREWORIVER CONDITIONS-APPLICABLE TO DRILLING HOLE TO 3/16 INCH DIAMETER IN ALUMINUM OP MAGNESIUM TO .100 INCH THICKNESS AND INSTALLING 3/32-3/16 INCH DIAMETER SOLID HEAD RIVET |
| NAA | 8C7 | MBA | SMFNN02 | SNFNI 05 | 403.9 | NUT(ANCHOR), INSTALL WITH TWO RIVETS, FLAST NUT (USE DRILL JIG TO LOCATE ATTACH HOLES) STARTS-WITH GET DRILL JIG INCLUDES—ALL MOTIONS NECESSARY TO POSITION JIG IN HOLE, GET DRILL MOTOR, INSTALL DRILL IN CHUCK, DRILL ANCHOR NUT ATTACH HOLE, REPUSE ITON JIG FOR SECOND HOLE, DRILL HOLE, REMOVE ANJ ASIDE JIG, REMOVE DRILL, INSTALL COUNTERSINK, COUNTERSINK TWO HOLES, REMOVE COUNTERSINK, A SIDE DRILL MOTOR, GET ANCHOR NUT, POSITION TO HOLES, INSTALL CLECO WITH PLIERS, SET UP RIVET GUN, INSTALL FIRST RIVET, REMOVE CLECC, INSTALL SECOND RIVET, AND REMOVE SPRING AND SET FROM RIVET GUN ENDS—WITH ASIDE TOOLS CONDITIONS—APPLICABLE TO DRILLING NO.+5=NJ.44 DIAMETER HOLES IN .063=.090 INCH THICKNESS ALUMINUM AND COUNTERSINKING WITH A 1/6=5/32 INCH 100 DEGREE COUNTERSINK, ALUMINUM JR MONEL RIVETS 1/8 = 3/16 INCH DIAMETER |
| NAA | 807 | MBA | SMFNN03 | SNFNI 06 | 1448 | NUTIANCHER) INSTALL WITH TWO RIVETS, ADDITIONAL NUTIUSE DRILL JIG TO LOCATE ATTACH HOLES) STARTS-WITH GET DRILL JIG INCLUDES-ALL MOTICNS NECESSARY TO POSITION JIG INCLUDES-ALL MOTICNS NECESSARY TO POSITION JIG DRILL SECOND HOLE, REMOVE JIG, COUNTERSINK HOLES, DET ANCHOR NUT, POSITION TO HOLES, INSTALL CLEOD, INSTALL FIRST RIVET, REMOVE CLECO, AND INSTALL SECOND RIVET ENDS-WITH RIVET GUN IN HAND CONDITIONS-DOES NOT INCLUDE ANY SETUP TIME FOR DRILL, COUNTERS INK, OR RIVET GUN, APPLICABLE TO DRILLING NO. 45-NO. 14 DIAMETER HOLES IN 063090 INCH THICKNESS ALUMINUM AND COUNTERSINKING WITH 1/8-5/32 INCH 100 DEGREE COUNTERSINK, ALUMINUM OR MONEL RIVETS 1/8 - 3/16 INCH DIAMETER. |

| DATA SOURCE | | YTI JAUQ | SOURCE CODE | DHMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NΓΦ | 807 | MUA | ONFSD[1 | , | 458 | PIN(DRAW TYPE SHEAR), INSTALL STARTS-WITH GET COLLAR INCLUDES-ALL MOTIONS NECESSARY TO GET PIN, INSERT IN HOLE, PLACE COLLAR ON PIN, GET SWAGING TOOL, PLACE FINGER ON HEAD OF PIN, PLACE SWAGING TOOL ON PIN, SWAGE COLLAR, AND EXAMINE INSTALLATION ENDS-WITH ASIDE TOOL CONDITIONS-APPLICABLE TO HUCK PULL TYPE SHEAR PIN OR SIMILAR TO 3/8 INCH DIAMETER, ANY LENGTH, AND HUCK GUN MODEL 352, 200 OR SIMILAR |
| NAA | 807 | MAA | AMR AR 54 | SNFRFXX | 229 181 | FASTENER (ANCHORED), REMOVE WORN OR STRIPPED FLOATING OR CHANNEL NUT ONLY STARTS-WITH GET DUCKBILL PLIERS INCLUDES-ALL MOTIONS NECESSARY TO GET PLIERS, BEND THO TABS; AND GET, REMOVE, AND ASIDE NUT ENDS-WITH ASIDE NUT CASE OI FIRST OR SINGLE NUT OR EACH ADDITIONAL NUT |
| AAH | 807 | MAA | AMRQRXX | SNFRSXX | 342 288 | STUDIAIRLOC), REMOVE PIN WITH AIRLOC TOOL STARTS-WITH GET AIRLOC TOOL INCLUDES-ALL MOTIONS NECESSARY TO POSITION AIRLOC STUD IN TOOL, REMOVE PIN, AS LOE TOOL, AND REMOVE STUD ENDS-WITH AS IDE PIN AND STUD CASE OI FIRST STUD OZ EACH ADDITIONAL STUD |
| NA A | 807 | МДД | AMR ON XX | SNFSIXX | VARIABLE | STUD(CAMLOC), INSTALL WITH CAMLOC PLIERS, NO RETAINING WASHER STARTS-WITH GET CAMLOC STUD ASSEMBLY INCLUDES-ALL MOTIONS NECESSARY TO GET CAMLOC PLIERS, POSITION PLIERS TO STUD, COMPRESS SPRING, POSITION STUD IN GROMMET, AND REMOVE PLIERS FROM STUD ENDS-WITH ASIDE PLIERS CASE O1 FIRST STUD ASSEMBLY O2 EACH ADDITIONAL STUD ASSEMBLY |
| N AA | 807 | MAA | AMR QN 3 2 | SNF S103 | 318 | STUDISTRESS HEAD CAMLOCI, INSTALL, PER STUD STARTS-WITH GET CAMLOC STUD ASSEMBLY INCLUDES-ALL MOTIONS NECESSARY TO POSITION STUD IN HOLE, GET RETAINER RING, POSITION ON STUD, GET HOLLOW DRIVE BAR, POSITION ON RETAINING RING, GET HAMMER, SEAT RETAINING RING, AND VISUALLY INSPECT ASSEMBLY ENDS-WITH ASIDE TOOLS CONDITIONS-APPLICABLE TO 4S STUD AND RETAINER SERIES |
| NA A | 807 | AAM | AMRORXX | SNF SR XX | VARIABLE | STUD(CAMLOC), REMOVE, NO RETAINING WASHER STARTS-WITH GET CAMLOC PLIERS INCLUDES-ALL MOTIONS NECESSARY TO RAISE STUD WITH FINGER AND HOLD, POSITION PLIERS UNDER SPRING CUP, COMPRESS SPRING, AND REMOVE STUD FRCM GROMMET ENDS-WITH ASIDE STUD AND PLIERS CASE OI FIRST STUD |
| AAK | 807 | MAA. | AMRQN33 | SNF WI 01 | 116 | WASHER(SPLIT), INSTALL ON CAMLOC STUD ASSEMBLY STARTS-WITH GET SPLIT WASHER INCLUDES-ALL MOTIONS NECESSARY TO GET PLIERS, ORASP WASHER WITH PLIERS, BEND WASHER TO ENLARGE OPENING, HOLD STUD, PLACE WASHER ON STUD, BEND WASHER TO CLOSE OPENING, AND VISUALLY INSPECT ASSEMBLY ENDS-WITH ASIDE PLIERS CONDITIONS-APPLICABLE TO 2600-SW, 2700-SH, AND 4002-SW WASHER SERIES |

| | OCCUP- ATION | QUALITY | SOURCE CODE | OWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|-----|-----------------|---------|----------------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | МАА | AMRQN34 | SNFW102 | 274 | WASHER(SQLID), INSTALL ON CAMLOC STUD ASSEABLY STARTS—WITH GET LOCKWASHER INCLUDES—ALL MOTIONS NECESSARY TO GET LOCKWASHER TOOL, POSITION LOCKWASHER IN TOOL, HOLD STUD, INSTALL LOCKWASHER, REMOVE TOOL, AND VISUALLY EXAMINE ASSEMBLY ENDS—WITH ASIDE TOOL CONDITIONS—APPLICABLE TO 2600—LW AND 2755—I WASHER SERIES |
| NAA | 807 | MAA. | AMRQR32 | SNFWR01 | 140 | WASHER(SPLIT), REMOVE FROM CAMLOC STUD, PER WASHER STARTS-WITH GET PLIERS INCLUDES-ALL MOTIONS NECESSARY TO MOLD CAMLOC STUD, GET WASHER WITH PLIERS, BEND WASHER TO ENLARGE OPENING, AND ARMOVE WASHER ENDS-WITH ASIDE WASHEP AND PLIERS CONDITIONS-APPLICABLE TO 2600-SW, 2700-SW, AND 4002-SW SERIES WASHERS |
| FFD | 807 | ΤΔΔ | KTŁPTC8 | aptacol | 1591 | ALUMINUM, CUT WITH DISC. ROUTER OR SIMILAR MOUNTED IN PNEUMATIC GUN. PROCESS TIME ONLY STARTS—WITH CUTTER IN POSITION TO CUT INCLUDES—ALL MOTIONS NECESSARY TO CUT ONE LINEAR INCH OF ALUMINUM SHEET OR TUBING .081 TO .125 INCH THICK ENDS—WITH COMPLETION OF CUT CONDITIONS—APPLICABLE TO 3000 RPM PNEUMATIC GUN |
| ŁĘŪ | 807 | TAA | KTLPTCC | BPTACO2 | 1985 | ALUMINUM.CUT WITH SAW MOUNTED IN PMEUMATIC GUN STARTS-WITH SAW IN POSITION FOR CUTTING INCLUDES-ALL MOTIONS NECESSARY TO CUT ONE LINEAR INCH OF ALUMINUM SHEET OR TUBING TU .250 INCH THICK ENDS-WITH CUT COMPLETED CONDITIONS-APPLICABLE TO 3000 RPM PNEUMATIC GUN AND SAW THO INCHES IN DIAMETER WITH 40-64 TEETH OER INCH |
| FFC | 807 | TAA | KSMHR I 2 | 3PT8S01 | ·50 | BOLT(HUCK LOCK).SET WITH PULL TYPE GUN STARTS-WITH ACTUATION OF GUN TRIGGER INCLUDES-ALL THE TIME NECESSARY TO SET DIE HUCK LOCK BOLT ENDS-WITH RELEASE OF TRIGGER |
| FF(| 807 | TAA | KSMTPR 2 | SPTC SO1 | 153 | COLLAR(RIVET), SPLIT WITH PNEUMATIC RIVET GUN. PROCESS TIME ONLY STARTS-WITH ACTUATE RIVET GUN SWITCH INCLUDES-ALL THE TIME NECESSARY TO SPLIT ONE RIVET COLLAR ENDS-WITH RELEASE OF SWITCH |
| FF | 907 | TAA | KPTJ8[3 | 101LT9F | 49 | JJ-BOLT.INSTALL WITH PNEUMATIC TOOL STARTS-WITH ACTUATION OF TRIGGER INCLUDES-ALL THE MACHINE TIME NECESSARY TJ TURN DOWN AND TIGHTEN ONE JO-BOLT ENDS-WITH RELEASE OF TRIGGER |

| DATA SOURCE | | QUALITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|---------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | TUA | SHRSNXX | SSR SAXX | VARIABLE | SEALANT, APPLY WITH PNEUMATIC SEALANT GUN STARTS-WITH GET GUN INCLUDES-ALL MOTIONS NECESSARY TO PLACE GUN IN VISE, DISCONNECT AIR HOSE, UNSCREW SEALANT CHAMBER, ASIDE PNEUMATIC PISTON, GET SCREWORIVER |
| | | | | | | AND PUSH PLUNGER DOWN, GET CAN OF SEALANT, PRY LID OFF, GET PUTTY KNIFE, CUT SEALANT FROM CAN, REPLACE LID ON CAN, GET SEALANT IN HAND, KNEAD SEALANT AND PLACE IN GUN, GET SEALANT CHAMBER, SCREW ON GUN, CLEAN SURFACE, REMOVE SCREW, CHECK HOLE DEPTH WITH SCALE, ADJUST PROBE REACH, INSTALL PROBE, POSITION GUN TO PROBE, CONNECT AIR HOSE, APPLY SEALANT TO FOUR LINEAR INCHES, DISCONNECT AND ASIDE GUN, REMOVE PROBE, |
| | | | • | | | AND INSTALL SCREW ENDS-WITH ASIDE SCREWORIVER CONDITIONS-APPLICABLE TO DOW-CORNING SEALANT |
| | | | | | 29718 | NO.DC-94-011 OR SIMILAR CASE OF GET GUN.FILL.AND APPLY SEALANT TO FOUR |
| | | | | | 17030 | LINEAR INCHES O2 APPLY SEALANT TO FOUR ADDITIONAL LINEAR INCHESTAPPLICATION ONLY) |
| NAA | 807 | MÄA | AMRAN54 | MTFFIXX | VARIABLE | FASTMERIANCHORED), INSTALL RIV-NUT, MANUAL MOTIONS CNLY |
| | | | | | | STARTS-WITH GET SQUEEZE TOOL |
| | | | | <i>:</i> | | INCLUDES-ALL MOTIONS NECESSARY TO GET SQUEEZE TOOL, POSITION TOOL FOR RIV-NUT, GET RIV-NUT, |
| • | | | | | | POSITION TO TOOL AND START THREAD,RUN RIV-NUT DOWN THREAD, BOTTOM RIV-NUT ON THREAD, |
| | | | | | | POSITION RIV-NUT IN HOLE, APPLY PRESSURE TO SEAT MUT, RELEASE HANDLE, REACH TO CRANK |
| | | | | | | KNOB, HOLD TOOL AND UNTHREAD FROM NUT |
| | | | | | | CONDITIONS—INCLUDES FLUSH OR FLAT HEAD TO |
| | | | | | 500 | SIZE 10-32, PROCESS TIME NOT INCLUDED. CASE OL FIRST RIV-NUT |
| | • | • | • | | . 440 | 02 EACH ADDITIONAL RIV-NUT |
| - NAA | 807 | MBA | OTFHMXX | STFBEXX | VARIABLE | BOLT(HI-LOK), INSTALL WITH MANUAL TOOLS STARTS-WITH GET HANDFUL OF BOLTS(FIRST BOLT) |
| | | | | | • | OR UNPALM BOLT (AODITIONAL BOLT) INCLUDES-ALL MOTIONS NECESSARY TO INSERT BOLT |
| | | | | | | IN HOLE,GET HAMMER,DRIVE BOLT THROUGH HOLE, ASIDE HAMMER,GET COLLAR,PLACE COLLAR ON BOLT, TURN COLLAR ON THREADS BY HAND,GET SPECIAL |
| | | | | | | RATCHET OR RATCHET BOX WRENCH AND ALLEN WRENCH.TIGHTEN COLLAR ON BOLT.AND BREAK COLLAR AWAY |
| | | | | | 973 | ENDS-WITH ASIDE TOOLS CASE OI FIRST BOLT, BOLT AND COLLAR, NO INTERFERENCE, NOMINAL REACH AND MOVE |
| | | | | | 757 | DISTANCES-18 INCHES 02 FACH ADDITIONAL BOLT, BOLT AND COLLAR NO INTERFERENCE, NOMINAL REACH AND MOVE |
| | | | | | 1327 | DISTANCES - 18 INCHES 03 FIRST BOLT, BOLT AND COLLAR, SLIGHT INTERFERENCE, NOMINAL REACH AND MOVE |
| | | | | | 1007 | DISTANCES-24 INCHES 04 EACH ADDITIONAL BOLT, BOLT AND COLLAR, SLIGHT INTERFERENCE, NOMINAL REACH AND |
| | | | | | 2471 | MOVE DISTANCES=24 INCHES 05 FIRST BOLT, BOLT AND COLLAR, DIFFICULT ACCESS, NOMINAL REACH AND MOVE |
| | | | | | 2268 | DISTANCES-24 INCHES 06 EACH ADDITIONAL BOLT, BOLT AND COLLAR, |
| | | | | | | DIFFICULT ACCESS, NOMINAL REACH AND MOVE DISTANCES-24 INCHES |

| DATA SOURCE | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FFD | 307 | MAA | KAL SAN1 | STF8[07 | 473 | BOLT(H(-LOK), INSTALL, POWER TOOLS, FIRST STARTS-WITH SIMO GET OF GUN AND BOLT(S) INCLUDES-ALL MOTIONS NECESSARY TO PLACE BOLT IN HOLE, PLACE GUN TO BOLT, INSTALL BOLT, GET |
| ٠ | | • | | | | COLLAR(S), PLACE COLLAR ON PIN AND START IN THREADS, PLACE GUN ON COLLAR, AND TIGHTEN COLLAR ENDS—WITH ASIDE GUN |
| FFD | 907 | MAA | KALSAN2 | STFB108 | 390 | BOLT(HI-LOK), INSTALL, POWER TOOLS, ADDITIONAL STARTS-WITH BOLT AND GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE BOLT TO |
| | | | | | | HOLE, POSITION GUN TO BOLT, INSTALL BOLT, GET COLLAR, POSITION COLLAR ON PIN, START THE EADS, PLACE GUN ON COLLAR, AND TIGHTEN COLLAR ENDS-WITH GUN IN HAND |
| AAV | 807 | MBA | OTFHMRX | STFBRXX | VARIABLE | BOLT(HI-LOK), REMOVE, MANUAL TOOLS STARTS-WITH GET PLIERS(FIRST) OR MOVE PLIERS TO COLLAR(ACDITIONAL) |
| | | • | | | - | INCLUDES-ALL MOTIONS NECESSARY TO ADJUST PLIERS (CHANNEL LOCK OR SLIP JOINT), PLACE PLIERS ON COLLAR, GET ALLEN WRENCH AND PLACE IN |
| • | | | | | | BOLT, TURN COLLAR WITH PLIERS APPROXIMATELY FIVE THREADS, ASIDE PLIERS AND ALLEN WRENCH, UNSCREW COLLAR ONE THREAD BY HAND, ASIDE COLLAR, GET HAMMER AND DRIFT, AND DRIVE BULT OUT |
| | | | | . • | 1744 | ENDS-WITH ASIDE TOOLS CASE OI FIRST BOLT.BOLT AND COLLAR,NO INTERFERENCE,NOMINAL REACH AND MOVE DISTANCES-18 INCHES |
| | | | | | 1476 | OZ EACH ADDITIONAL BOLT, BOLT AND COLLAR, NO INTERFERENCE, NOM INAL REACH AND MOVE DISTANCES-18 INCHES |
| | | | | | 2486 | O3 FIRST BOLT, BOLT AND COLLAR, SLIGHT INTERFERENCE, NOMINAL REACH AND MOVE DISTANCES=24 INCHES |
| | | | | | 2166 3651 | O4 EACH ADDITIONAL BOLT, BOLT AND COLLAR, MOVE DISTANCES-24 INCHES O5 FIRST BOLT, BOLT AND COLLAR, DIFFICULT |
| | | | | | 3289 | ACCESS, NOMINAL REACH AND MOVE DISTANCES=24 INCHES 06 EACH ADDITIONAL BOLT, BOLT AND COLLAR, |
| | | | | | | DIFFICULT ACCESS, NOMINAL REACH AND MOVE DISTANCES = 24 INCHES |
| NAA | 807 | MBA. | OTFHMXX | STFCIXX | VARIABLE | COLLAR(HI-LCK BOLT), INSTALL, MANUAL TOOLS STARTS-WITH GET HANDFUL OF COLLARS(FIRST)OR UNPALM COLLAR(ADDITIONAL) INCLUDES-ALL MOTIONS NECESSARY TO TURN COLLAR |
| | | | | | | ON THREADS BY HAND, GET SPECIAL RATCHET OR RATCHET. BOX END WRENCH AND ALLEN WRENCH, PLACE TOOL(S) TO BOLT AND COLLAR, TIGHTEN COLLAR, AND BREAK AWAY COLLAR |
| | | | | | 706 | ENDS-WITH ASIDE TOOLS CASE OI FIRST COLLAR, NO INTERFERENCE, NOMINAL REACH AND MOVE DISTANCES-18 INCHES |
| | | | | | 602 | OZ EACH ADDITIONAL COLLAR,NO INTER- FERENCE,NOMINAL REACH AND MOVE DISTANCES-18 INCHES |
| | | | | | 930 | 03 FIRST COLLAR, SLIGHT INTERFERENCE, NOMINAL REACH AND MOVE DISTANCES-24 INCHES |
| * | | | | | 756 | 04 EACH ADDITIONAL COLLAR, SLIGHT' INTERFERENCE, NOMINAL REACH AND MOVE DISTANCES-24 INCHES |
| | | | | | 1958 | OS FIRST COLLAR.DIFFICULT ACCESS.NOMINAL REACH AND MOVE DISTANCES-24 INCHES |
| | | | | | 1804 | O6 EACH ADDITIONAL COLLAR, DIFFICULT ACCESS, NOMINAL REACH AND MOVE DISTANCES-24 INCHES |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NEA | 837 | MBA | OTEHMXX | STFCRXX | VARTABLE | COLLAR(HI=LCK BOLT), REMOVE, MANUAL TOOLS STARTS=WITH GET PLIERS(FIRST) OR MOVE PLIERS TO COLLAR(ADDITIONAL) INCLUDES=ALL MOTIONS NECESSARY TO ADJUST PLIERS(CHANNEL LOCK OR SLIP JOINT), PLACE PLIERS ON COLLAR, GET ALLEN BRENCH AN) PLACE IN BOLT, TURN COLLAR WITH PLIERS APPROXIMATELY FIVE THREADS, ASIDE TOOLS, AND UNSCREW COLLAR ONE THREAD BY PAND |
| | | | | | 1317 | ENDS-WITH ASIDE COLLAR CASE OI FIRST COLLAR, NO INTERFERENCE, NOMINAL |
| | | | | | · 1227 | PEACH AND MOVE DISTANCES-18 INCHES OZ EACH ADDITIONAL CULLAR,NO INTERFERENCE,NOMINAL REACH AND MUVE |
| | | | | | 2055 | DISTANCES-18 INCHES 03 FIRST COLLAR, SLIGHT INTERFERENCE, NOMINAL REACH AND MOVE DISTANCES-24 |
| | | | | | 1917 | INCHES 04 EACH ADDITIONAL COLLAR, SLIGHT INTERFERENCE, NOMINAL REACH AND MUVE |
| | | | | (| 3101 | DISTANCES-24 INCHES 35 FIRST COLLAR,DIFFICULT ACCESS,NUMINAL REACH AND MOVE DISTANCES-24 INCHES |
| | | | | | 2937 | O6 EACH APSITIONAL COLLAR, DIFFICULT ACCESS, NOMINAL PEACH AND MOVE DISTANCES=24 INCHES |
| NAA. | 807 | MAA | AMR 4N52 | STF#101 | 883 | FASTENER(ANCHORED), INSTALL DILL NUT WITH TOUL, FIRST PIECE STARTS-WITH GET DILL NUT TOOL INCLUDES-ALL THE MOTIONS NECESSARY TO GET DILL NUT TOCL, MOVE TO APPROXIMATE LOCATION, GET DILL NUT, MOVE NUT TO TOOL, CHECK RATCHET POSITION. |
| | | | ÷ , | | · | MOVE TOOL WITH NUT TO HOLE, PUSH FIRM, ENGAGE RATCHET TO NUT SLOT, REGRASP AND HOLD FIRM, TIGHTEN NUT (SLEEVE), REMOVE TOOL FROM NUT, A SIDE TOOL, GET PLIERS TO NUT, CHECK NUT FOR TIGHTNESS WITH PLIERS, ASIDE PLIERS ENDS—HITH ASIDE PLIERS |
| • | | | | | | CONDITION-ADJUSTMENT OF RATCHET IS REQUIRED 50 PERCENT OF THE TIME.INCLUDES FLUSH OR FLAT HEAD TO SIZE 10-32 |
| NAA . | 807 | MAA | AMRAN53 | STFFI02 | 730 | FASTENER(ANCHORED), INSTALL DILL NUT WITH TOOL, ADDITIONAL PIECE STARTS-WITH GET DILL NUT INCLUDES-ALL MOTICNS NECESSARY TO GET DILL NUT TO TOOL, MOVE TOOL WITH NUT TO HOLE, PUSH FIRM, ENGAGE RATCHET TO NUT SLOT, REGRASP AND HOLD FIRM, TIGHTEN NUT(SLEEVE), MOVE TGOL FROM NUT, CHECK NUT FOR TIGHTNESS USING PLIERS ENDS-WITH ASIDE PLIERS CONDITIONS-INCLUDES FLUSH OR FLAT HEAD TO SIZE 10-32 |
| NAA | | MUA | AMRAN50 | STFF103 | 610 | FASTENER (ANCHORED), INSTALL RIV-NUT, FIRST PIECE STARTS-WITH GET SQUEEZE TOOL INCLUDES-ALL MOTIONS NECESSARY TO GET SQUEEZE TOOL, GET RIV-NUT, SCREW RIV-NUT ON TOOL, POSITION RIV-NUT IN HOLE, SQUEEZE TOOL TO SECURE RIV-NUT, AND REMOVE TOOL FROM RIV-NUT ENDS-WITH ASIDE TOOL CONDITIONS-INCLUDES FLUSH OR FLAT HEAD TO 10-32 |

| DATA SOURCE | | QUALITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|---------|--------------------|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NA A | 807 | MUA | AMRAN51 | STFF104 | 550 | FASTENER(ANCHORED), INSTALL RIY—NUT, ADDITIONAL STARTS—WITH GET RIY—NUT, TOOL IN HAND INCLUDES—ALL MOTIONS NECESSARY TO SCREW RIY—NUT ON TOOL, POSITION RIV—NUT IN HOLE, SQUEEZE TOOL HANDLES TO SECURE RIV—NUT, AND REMOVE TOOL FROM RIV—NUT ENDS—WITH TOOL IN HAND CONDITIONS—INCLUDES FLUSH OR FLAT HEAD TO 10—32 |
| AAF | 807 | MAA | AMRAR52 | STFFRXX | 782 726 | FASTENER(ANCHORED), REMOVE DILL NUT STARTS-WITH GET DILL NUT TOOL INCLUDES-ALL MOTIONS NECESSARY TO GET DILL NUT TOOL, CHECK RATCHET, ADJUST RATCHET IF NECESSARY, POSITION TOOL TO SLOT, LOOSEN NUT SLEEVE, REMOVE TOOL FROM COLLAR, ASIDE TOOL AND COLLAR ENDS-WITH ASIDE TOOL OR COLLAR CONDITION-INCLUDES FLUSH OR FLAT HEAD TO SIZE 10-32. ADJUSTMENT OF RATCHET REQUIRED 50 PERCENT OF THE TIME FOR FIRST NUT. CASE 01 FIRST DILL NUT 02 EACH ADDITIONAL DILL NUT |
| FFD | 807 | MBA | KSMBTXX | STFIBXX | ************************************** | BOLT(H[=TORQUE), INSTALL WITH PNEUMATIC TOOL, PER BOLT STARTS=WITH GET RIVET GAUGE INCLUDES=ALL MOTIONS NECESSARY TO GAUGE HOLE DEPTH.GET BOLT.PLACE IN HOLE, GET HAMMER.SEAT HOLT, ASIDE HAMMER.START COLLAR ON BOLT BY HAND.GET PNEUMATIC TOOL.PLACE TOOL ON BOLT, TIGHTEN BOLT, SHAKE SHEARED COLLAR FROM TOOL, ASIDE TOOL.AND INSPECT INSTALLATION WITH LIGHT CONDITIONS=TIME FOR SET UP OF PNEUMATIC TOOL NOT INCLUDED CASE OI INSTALL BOLT IN UNOBSTRUCTED LOCATION (INSPECTION IS PERFORMED WITH LIGHT AND MIPROR) |
| € F D | 807 | MAA | KSMBTII | STF1803 | 1069 | BOLTIMI-TORQUE), INSTALL WITH HAND TOOLS IN UNOBSTRUCTED LOCATION STARTS-WITH GET RIVET GAUGE INCLUDES-ALL MOTIONS NECESSARY TO GAUGE HOLE TO DETERMINE BOLT LENGTH, GET BOLT, PLACE IN HOLE, GET HAMMER, SEAT BOLT, ASIDE HAMMER, START COLLAR ON BOLT BY HAND, GET ALLEN WRENCH, GET DEN END WRENCH, PLACE ALLEN WRENCH IN BOLT, PLACE END WRENCH ON COLLAR, TIGHTEN CULLAR, ASIDE SHEARED COLLAR, ASIDE TOOLS, AND INSPECT INSTALLATION WITH LIGHT |
| FED | 807 | мад | KSMBTI3 | STF1B04 | 1535 | BOLT (HI-TORQUE), INSTALL WITH HAND TOOLS IN CBSTRUCTED LOCATION STARTS-WITH GET RIVET GAUGE INCLUDES-ALL MOTIONS NECESSARY TO GAUGE HOLE TO DETERMINE BOLT LENGTH, GET BOLT, PLACE IN HOLE, GET HAMMER, SEAT BOLT, ASIDE HAMMER, START COLLAR ON BOLT BY HAND, GET ALLEN ARENCH, GET OPEN FOR WRENCH, PLACE BLIEN HARDON IN BOLT, PLACE FOR WRENCH ON COLLAR, TIGHTEN COLLAR, ASIDE SHEARED COLLAR, ASIDE TOOLS, AND INSPECT INSTALLATION WITH LIGHT AND MIRRUR |

| DATA SOUPCE | | QUAL ITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|----------|---------|--------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | MAA | OTFBJXX | STF1JXX | VARIABLE | JO-BOLT, INSTALL WITH HAND TOOL STARTS-MITH GET JO-BOLT SELECTOR GAUGE INCLUDES-ALL MOTIONS NECESSARY TO GAUGE HOLE DEPTH, ASIDE GAUGE, GET SOCKET, ASSEMBLE AND ADJUST LOCKSET, POSITION BOLT TO LOCKSET, POSITIOM LOCKSET AND BOLT TO HOLE, TIGHTEN UNTIL BOLT SHEARS, MOVE TOOL AND CHECK BOLT, DISASSEMBLE AND ASIDE TOOLS ENOS-MITH ASIDE TOOL CONDITION-JO-BOLT TO 3/16 INCH DIAMETER, NUT OR CCS TYPE CASE OL FIRST JO-BOLT |
| | | | • | | 455 | OZ EACH ADDITIONAL JO-BOLT |
| NAA | 807 | AUM | OTF8JXX | STFJIXX | VARIABLE | JO-BOLT, INSTALL WITH ARO JO-BOLT GUN MODEL 7 OR SIMILAR STARTS-WITH GET JO-BOLT SELECTOR GAUGE INCLUDES-ALL MOTIONS NECESSARY TO GAUGE HOLE DEPTH, ASIDE GAUGE, GET JO-BOLT GUN, GET JO-BOLT, PLACE JO-BOLT IN LOCKSET OF GUN, POSITION GUN AND JO-BOLT TO HOLE, FIGHTEN JO-BOLT, REMOVE GUN, DISCARD SHEARED PORTION OF JO-BOLT, AND CHECK INSTALLATION ENDS-WITH ASIDE GUN CONDITIONS-APPLICABLE TO INSTALLATION OF |
| | | | | | | JO-BOLT TO 3/16 INCH DIAMETER |
| | | | | •• | 461 209 | CASE 01 FIRST JO-BOLT. 02 EACH ADDITIONAL JO-BOLT |
| FFD | 807 | MAA | KSMJB12 | STFJ103 | 631 | JO-BOLT, INSTALL, OBSTRUCTED, USE JO-BOLT SET STARTS-WITH GET GAUGE, GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO DETERMINE GRIP LENGTH WITH HOOK GAUGE, ASIDE GAUGE, GET JO-BOLT, POSITION IN HOLE, GET JO-BOLT SET, POSITION TO JO-BOLT, DRIVE JO-BOLT, SHAKE SHANK FROM SET ENDS-WITH GUN IN HAND |
| FFD | 807 | MUA | KSMJBXX | STFJRXX | 2819 2190 1333 704 | JO-BOLT, REMOVE STARTS-WITH GET DRILL MOTOR INCLUDES-ALL MOTIONS NECESSARY TO GET AND INSTALL DRILL BIT, CONNECT AIR MOSE, MUVE DRILL TO JO-BOLT, DRILL JO-BOLT HEAD, REMOVE DRILL BIT, DISCONNECT AIR MOSE, AS IDE DRILL BIT AND DRILL MOTOR, GET HAMMER, GET PUNCH, PLACE PUNCH TO DRILLED HEAD, DRIVE OUT SHANK, AS IDE HAMMER, GET PLIERS, PULL DRILLED HEAD FROM PUNCH AND AS IDE, AS IDE PLIERS, AS IDE PUNCH, GET SHANK, AND AS IDE TO TRASH ENDS-WITH RELEASE SHANK CASE OI REMOVE FIRST STEEL JO-BOLT 02 REMOVE FACH ADDITIONAL STEEL JO-BOLT 04 REMOVE FACH ADDITIONAL ALUMINUM JO-BOLT |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 807 | MAA | OTFSJXX | STFRJXX | VARTABLE | JO-BOLT, PEMOVE STARTS-WITH GET DRILL MOTOR INCLUDES-ALL MOTIONS NECESSARY TO GET DRILL MOTOR, INSTALL DRILL, POSITION DRILL TO BOLT, |
| | | | | | | DRILL OUT BOLT,GET NUT ON DRILL,REMOVE NUT WITH CARE, ASIDE NUT,GET PLIERS TO NUT,ACTUATE MOTOR TO SPIN OUT NUT, ASIDE NUT AND DRILL;OR |
| | • | | | • * | | GET E-Z OUT, ADJUST AND POSITION TO NUT, SEAT FIRMLY ON NUT, REMOVE NUT, DISENGAGE NUT FROM E-Z OUT, ASIDE NUT AND E-Z OUT |
| | | | | · | | ENDS-WITH ASIDE TOOLS CONDITION-APPLIES TO JO-BOLT TO 3/16 INCH DIAMETER, NUT OR CCS TYPE |
| | | | | • | 1222 | CASE OF REMOVE FIRST JO-BOLT USING DAILL WITH STRAIGHT CHUCK, E-Z OUT NOT REQUIRED |
| | | | | | 617 | OZ REMOVE EACH ADDITIONAL JO-BOLT USING DRILL WITH STRAIGHT CHUCK, E-Z DUT NOT REQUIRED |
| | | | | | 1598 | O3 REMOVE FIRST JO-BOLT USING DRILL WITH STRAIGHT CHUCK-USE OF E-Z JUT REQUIRED |
| | | | | | 657 | 04 REMOVE EACH ADDITIONAL JU-BOLT USING DRILL WITH STRAIGHT CHUCK, USE UF E-Z OUT REQUIRED |
| | | | | | 1423 | OS REMOVE FIRST JO-90LT USING DRILL WITH 90 DEGREE CHUCK, E-Z OUT NOT REJUISED 06 REMOVE EACH ADDITIONAL JO-90LT USING ORILL WITH 90 DEGREE CHUCK, E-Z OUT |
| | | | | • | 1781 | NOT REQUIRED O7 REMOVE FIRST JO-BOLT USING DRILL WITH 90 DEGREE CHUCK.USE OF E-Z OUT |
| | | | | | 1002 | REQUIRED OB REMOVE EACH ADDITIONAL JO-BOLT USING |
| | | | • | | | DRILL WITH 90 DEGREE CHUCK,USE DF E-Z OUT REQUIRED |
| NAA | 807 | MBA. | AMROR XX | STLACXX | VARIABLE . | AREA(DAMAGED),CUT AWAY,ALUMINUM ALLOY TO .U64 INCH.THICKNESS,CIRCULAR AREA STARTS-WITH VISUALLY EXAMINE DAMAGED AREA |
| | | | | | | INCLUDES-ALL MOTIONS NECESSARY TO MEASURE SIZE OF AREA TO BE CUT AWAY, MARK OUTLINE OF PATCH, SET UP AIR POWERED DRILL, DRILL PILOT HOLE, |
| | | | | | | COUNTERBORE FOR ACCESS BY SNIPS.CUT AWAY DAMAGED AREA WITH COMPOUND LEVER SNIPS.SET UP |
| | | | | | | DRILL WITH ROTARY FILE, CUT TO LINE WITH ROTARY FILE, AND FINAL DRESS HOLE WITH HAND FILE AND EMERY CLOTH |
| | | • | | | | ENDS-WITH ASIDE TOOLS CONDITIONS-USE OF DRILL TO PILOT DRILL AND COUNTERBORE COMPUTED AT 30% OCCURRENCE |
| | | | | | 19280 | CASE OI REMOVE EXTERNAL SURFACE DAMAGE, TO 4 |
| | | | | | 31000 | 02 REMOVE EXTERNAL SURFACE DAMAGE, 4-7 INCHES DIAMETER |
| | | | | | 42840 | 03 REMOVE EXTERNAL SURFACE DAMAGE,7-10 INCHES DIAMETER |
| | | | | : | 55170 | 04 REMOVE EXTERNAL SURFACE DAMAGE, 10-13 INCHES DIAMETER |
| | | | | | 67250 | 05 REMOVE EXTERNAL SURFACE DAMAGE, 13-16 INCHES DIAMETER |

| SOURCE | | QUAL ITY | CODE | DWMSTDP | VALUE | OPERATION/ELEMENT DESCRIPTION |
|--------|------|----------|---------|---------|------------|------------------------------------------------------------------------------------------------------------|
| MAA | 807 | TUA | AMRMMXX | STLASXX | VARIABLE | ALUMINUM, SAW WITH JEWELER'S OR SKIN SAW, PER Straight linear inch |
| | | | | | | STARTS-WITH GET SAW |
| | | | Ň | | | INCLUDES-ALL MODIONS NECESSARY TO POSITION SAW TO CUTTING POINT AND CUT ONE STRAIGHT LINEAR |
| | | | | | | INCH |
| | | | | | | ENDS-WITH ASIDE SAW CONDITIONS-MADDITIONAL INCHM CASES INCLUDE CUTTING PROCESS TIME ONLY |
| | | | | | 200 | CASE OI FIRST LINEAR INCH, MATERIAL .032045 |
| | | | | | 90 | OZ EACH ADDITIONAL LINEAR INCH, MATERIAL .032045 INCH THICKNESS |
| | | | | | 230 | 03 FIRST LINEAR INCH, MATERIAL .046064 INCH THICKNESS |
| | | | | | 120 | 04 EACH ADDITIONAL LINEAR INCH, MATERIAL .046064 INCH THICKNESS |
| | · | | | | 290 | 05 FIRST LINEAR INCH, MATERIAL .065100 INCH THICKNESS |
| | | | | | 180 | O6 EACH ADDITIONAL LINEAR INCH-MATERIAL .065100 INCH THICKNESS |
| NAA | 807 | MRA | AMRDRXX | STLCAXX | VARIABLE | AREA(DAMAGED),CUT AWAY,ALUMINUM ALLOY TO .064 |
| | | | | | | STARTS-WITH VISUAL EXAMINATION OF DAMAGED AREA |
| | | | | | | INCLUDES—ALL MOTIONS NECESSARY TO MEASURE AND MARK AREA TO BE CUT, CENTER PUNCH FOUR CORNERS |
| | | | | • | | FOR DRILLING. SET UP AIR POWERED DRILL, PILOT |
| * | | | • | | • | ORILL AND COUNTERBORE CORNERS, CUT AWAY DAMAGED AREA WITH SNIPS, AND FINAL DRESS WITH FILE AND EMERY CLOTH |
| | | | | | | ENDS-WITH ASIDE TOOLS |
| | | | | | 26580 | CASE OI REMOVE EXTERNAL SURFACE DAMAGE TO 16 INCHES PERIMETER |
| | | | · | | 42110 | OZ REMOVE EXTERNAL SURFACE DAMAGE 16-28 INCHES PERIMETER |
| | | | | | 57650 | O3 REMOVE EXTERNAL SURFACE DAMAGE 28-40 INCHES PERIMETER |
| | | | | | 73190 | 04 REMOVE EXTERNAL SURFACE DAMAGE 40-52 INCHES PERIMETER |
| | | | | | 88730 | OS REMOVE EXTERNAL SURFACE DAMAGE 52-64 Inches Perimeter |
| MAA | 807 | MAA | SMRDRXX | STLDRXX | VARTABLE | DENT.REMOVE FROM ALUMINUM TO .064 INCH |
| | | | | | | THICKNESS.PER SQUARE INCH STARTS-WITH GET PART |
| | | | | | | INCLUDES-ALL MOTIONS NECESSARY TO MOVE PART TO |
| | | | | | | WORK AREA,GET WEIGHT AND PLACE ON PART,GET BACK-UP BAR,POSITION TO DENT,GET HAMMER,STRIKE |
| | | • | | | | FOUR BLOWS TO DENT AREA, MAKE VISUAL |
| | | | | | | EXAMINATION AFTER EACH HAMMER BLOW. ASIDE |
| | | | | | | HAMMER.FEEL PART WITH HAND TO CHECK SMOOTHNESS.ASIDE BACK-UP BAR.AND ASIDE WEIGHT |
| | | | | | | ENDS-WITH ASIDE PART |
| | | | | | 801 | CASE O1 FIRST SQUARE INCH OF DENT |
| | | | | | 530 363 | 02 FIRST SQUARE INCH OF ADDITIONAL DENT 03 EACH ADDITIONAL SQUARE INCH OF SAME |
| | | | | | | DENT |
| NF | 8 29 | MAF | 1272/73 | XXZTQLP | VARIABLE | TRAMMEL SET TO SCALE |
| | | | | | | STARTS-WITH HAND ON TRAMMEL INCLUDES-ALL MOTIONS NECESSARY TO MOVE TRAMMEL |
| | | | | | | TO SCALE, POSITION FIRST POINT, LOOSEN LOCK |
| | | | | | | SCREW.MOVE SECOND POINT ALONG TRAMMEL.POSITION POINT TO SCALE.VISUALLY CHECK.AND TIGHTEN LOCK |
| | | | | | | SCREW |
| | | | | | 2 09 | ENDS-WITH MOVE TRAMMEL ASIDE CASE 01 SET 1-MAN TRAMMEL |
| | | | | | 295 | 02 SET 2-MAN TRAMMELITIME VALUE FOR TWO |
| | | | | | | OPERATORS) |

| DATA Source | | QUAL ITY | SOURCE CODE | DWMSTDP ELFMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 809 | MAF | 1078 | MTLDUO1 | 152 | DIVIDERS.USE TO SCRIBE 90-DEGREE ARC STARTS-WITH DIVIDERS IN MAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE POINT OF DIVIDERS TO CENTERPOINT, POSITION SCRIBING POINT, SCRIBE 90-DEGREE ARC, MOVE DIVIDERS AWAY, AND VISUALLY CHECK WORK ENDS-WITH DIVIDERS IN MAND CONDITION-APPLICABLE TO SCRIBING ARC TO 16-INCH RADIUS |
| NF | 809 | MAF | 1112 | 4 TLTU01 | 328 | TRAMMEL, USE TO SCRIBE 90-DEGREE ARC.ONE OPERATOR, 36-INCH RADIUS STARTS-WITH SIDESTEP TO MOVE TRAMMEL TO MURK INCLUDES-ALL MOTIONS NECESSARY TO POSITION POINT TO PUNCH MARK, SIDESTEP TO SCRIBING END OF TRAMMEL, AND SCRIBE ARC ENDS-WITH SIDESTEP TO CENTER POINT |
| AF | 81X | MAM | SWDEAHL | MACAA01 | 55 | AMPERAGE, ADJUST ON AC OR DC WELDING MACHINE STARTS-WITH REACH TO CONTROL INCLUDES-ALL MOTIONS NECESSARY TO GRASP CONTROL, LOCATE SETTING, APPLY PRESSURE, MUVE TO SETTING, CHECK SETTING AND RELEASE CUNTROL ENDS-WITH RELEASE CONTROL CONDITIONS-DIAL MOVED APPROXIMATELY 12 INCHES |
| NO | 81X | MAO | LFAlW | MACCAOL | | CONTROLS (HEAT). ADJUST ON WELDING MACHINE STARTS-WTIH REACH TO FIRST CONTROL INCLUDES-ALL MOTIONS NECESSARY TO TURN TWO CONTROL HANDLES TO NEW SETTINGS ENDS-WITH RELEASE SECOND CONTROL HANDLE CONDITIONS-CONTROL HANDLES TURNED APPROXIMATELY 45 DEGREES |
| NF | 81X | Maf | 2138 | MACKOO1 | 93 | KNOB.OPEN ON ACETYLENE TORCH TIP STARTS-WITH REACH TO TIP HANDLE INCLIDES-ALL MOTIONS NECESSARY TO DETAIN TORCH TIP FROM HANGER, GET KNOB. LOOSEN. AND TURN KNOB TO OPEN VALVE ENOS-WITH RELEASE OF KNOB |
| ΑE | 81X | MAIN | SWDE AG1 | MACHTO1 | 74 | MACHINE (WELDING). TURN ON OR OFF STARTS-WITH BEND TO SWITCH OR BUTTON INCLUDES-ALL MOTIONS NECESSARY TO BEND TO SWITCH OR BUTTON. ACTUATE SWITCH OR BUTTON. AND ARISE ENDS-WITH ARISE FROM BEND |
| AE | 81X | MAW | SWDEAS1 | MACVT01 | 69 | VALVE(ACETYLENE AND OXYGEN), TURN OFF STARTS-WITH REACH TO ACETYLENE VALVE INCLUDES-ALL MOTIONS NECESSARY TO CLOSE ACETYLENE VALVE, REACH TO AND CLOSE OXYGEN VALVE ENDS-WITH RELEASE OF VALVE |
| NF | 81X | MAF | 1256 | MC L SC XX | 717 588 | SLAG. CHIP WITH CHIPPING HAMMER, CHISEL, AND BRUSH STARTS-WITH SIMO REACH TO HAMMER AND CHISEL INCLUDES-ALL MOTICNS NECESSARY CHIP SLAG WITH HAMMER AND CHISEL, ASIDE HAMMER AND CHISEL, GET WIRE BRUSH, AND BRUSH OFF SLAG ENDS-WITH ASIDE BRUSH CONDITIONS-GENERALLY APPLICABLE TO REMOVAL OF SLAG AFTER BURNING OR CUTTING OPERATION CASE OI FIRST LINEAR FOOT OZ EACH ADDITIONAL LINEAR FOOT(WITHOUT GET AND ASIDE TOOLS) |

| DATA SOURCE | | QUALITY- | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 81X | MAF | 1251 | MCLSKXX | VARIABLE | SCALE, KNOCK FROM WELD WITH HAMMER AND BRUSH STARTS-WITH GET HAMMER INCLUDES-ALL MOTIONS NECESSARY TO TAP WELD WITH HAMMER ONCE PER INCH TO LOOSEN SCALE, AS IDE HAMMER, GET BRUSH, AND BRUSH SCALE AWAY ENDS-WITH AS IDE BRUSH |
| | | | | | 416 301 | CASE O1 FIRST LINEAR FOOT OF WELD O2 EACH ADDITIONAL LINEAR FOOT OF WELD |
| ··NO | 81X | MAO | LHW1W/Y | MCLSRXX | VARTABLE | SLAG,REMOVE WITH CHIPPING HAMMER STARTS-WITH GET TOOL INCLUDES-ALL MOTIONS NECESSARY TO POSITION TOOL,STRIKE AND CHIP SLAG,CHECK SURFACE AND MOVE TOOL ASIDE ENDS-WITH RELEASE OF TOOL CONDITIONS-GENERALLY APPLICABLE TO REMOVING SLAG AFTER BURNING OR GOUGING OPERATION |
| | | | | | 136 52 | CASE 01 FIRST OR SINGLE INCH OF SLAG CHIPPED 02 EACH ADDITIONAL INCH OF SLAG CHIPPED |
| NO | 81X | MAO | LHW1M2 | MCLSS01 | 30 | SPATTER, SCRAPE PER INCH OF WELD STARTS-WITH SCRAPER POSITIONED FOR USE INCLUDES-ALL MOTIONS NECESSARY TO SCRAPE SPATTER FROM ONE INCH OF WELD ENDS-WITH ONE INCH OF WELD CLEANED |
| AAK | 81X | MAA | OTLWSXX | MCLJCXX | VARIABLE | TIP, CLEAN WITH SANDPAPER, WELDING GUN STARTS-WITH GET SANDPAPER, TIP IN HAND INCLUDES-ALL MOTIONS NECESSARY TO USE SANDPAPER TO CLEAN WELDING GUN TIP ENDS-WITH ASIDE SANDPAPER |
| | | | | • | 143 80 | CASE O1 ROLLER TIP GUN O2 POINTER TIP GUN |
| NF | 81X | MAF | 1270 | MCLTC03 | 224 | TIP, CLEAN WITH EMERY CLOTH WRAPPED AROUND FILE, SPOT WELDER STARTS-WITH TOOL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO USE EMERY TO CLEAN TWO ELECTRODE TIPS ENOS-WITH FILE AND EMERY IN HAND |
| FFD | 81X | TBA | KWLPTSB | MC LTD01 | 728 | TIPIELECTRODE-WELDERI, DRESS STARTS-WITH REACH TO GET DRESSING BOARD INCLUDES-ALL THE MOTIONS NECESSARY TO GET DRESSING BOARD, DRESS TIP TO A SMOOTH FINISH AND ASIDE BOARD ENDS-WITH ASIDE DRESSING BOARD |
| NO | 81% | MAC | LFAIR1 | MGMPC 01 | 143 | PART, CHECK FOR WARPAGE WITH 12-INCH SCALE STARTS-WITH REACH TO SCALE INCLUDES-ALL MOTIONS NECESSARY TO GET SCALE, BEND, POSITION SCALE TO PART, VISUALLY CHECK PART FOR WARPAGE, ARISE AND ASIDE SCALE ENDS-WITH RELEASE OF SCALE |
| FFD | 81% | MAA | KWL SUAD | 4JPCC01 | 546 | CABLE(ELECTPODE HOLDER), CONNECT/DISCONNECT TO/FROM ARC WELDER STARTS=WITH REACH TO GET HOLDER CABLE [NCLUDES=ALL THE MOTIONS NECESSARY TO GET HOLDER, STOOP TO WELDER, INSERT CABLE INTO WELDER, ARISE, STOOP, GRASP AND REMOVE CABLE, ARISE ENOS=WITH HOLDER IN HAND CONDITIONS=INCLUDES TIME FOR BOTH CONNECT AND DISCONNECT |

| DATA Source | | QUALITY | SDURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ۵F | 81X | маа | 636 | MJPECO1 | 350 | ELECTRODE(TUNGSTEN), CHANGE IN TORCH STARTS—WITH TORCH AND ELECTRODE IN HAND INCLUDES—ALL THE MOTIONS NECESSARY TO LOOSEN ELECTRODE SECURING NUT, SCREW OFF NUT, PALM NUT, REMOVE ELECTRODE, AS IDE TO WORKBENCHINUT AND ELECTRODE), PICK UP NEW ELECTRODE ON WORKBENCH, INSERT ELECTRODE, GET SECUPING NUT FROM BENCH AND INSTALL ON TORCH TIP ENDS-WITH RELEASE OF NUT |
| ΔĘ | 81X | MAW | SWOE AR 1 | MJPFAOL | 94 . | FLAME, ADJUST ON HAND TORCH STARTS-WITH REACH TO KNOB ON OXYGEN VALVE INCLUDES-ALL MOTIONS NECESSARY TO TURN OXYGEN VALVE, TURN ACETYLENE VALVE KNOB, FOCUS EYES, ADJUST OXYGEN VALVE AND CHECK FLAME ENDS-WITH RELEASE VALVE |
| NO | 81X | MAD | LHWIZ | MJPGPOI | 110 | GOGGLES (BURNING), PUT ON AND REMOVE STARTS-WITH REACH TO GOGGLES ON TOP OF HEAD INCLUDES-ALL MOTIONS NECESSARY TO MOVE AND ADJUST GOGGLES OVER EYES; REACH TO GOGGLES AND MOVE THEM TO TOP OF HEAD ENDS-WITH RELEASE GOGGLES CONDITIONS-WELDING TORCH HELD IN ONE HAND WHILE PUTTING ON AND TAKING OFF GOGGLES |
| FFD | 81X | MAA | | JOAH9LK | 954 | HOSESIOXYGEN AND ACETYLENES, ATTACH AND REMOVE TO/FROM TORCH STARTS-WITH REACH TO TOOL INCLUDES-ALL THE MOTIONS NECESSARY TO GET TOOL, GET HOSES, PLACE TO TORCH, TIGHTER NUT TO HOLD HOSE ON TORCH WITH WRENCH, LODSEN NUT, REMOVE HOSES AND ASIDE TORCH ENDS-WITH ASIDE TOOL |
| NF. | 81X | MAF. | 4012/13 | MJPJP01 | 435 | JACKET (WELDERS), PUT ON AND TAKE OFF STARTS-WITH JACKET IN HAND INCLUDES-ALL MOTIONS NECESSARY TO PUT JACKET DN, ZIP UP, UNZIP, AND REMOVE JACKET ENDS-WITH JACKET IN HAND |
| FFN | 81× | маа | KWLSUXX | HJPRCXX | VARIABLE 161 85 | RODIWELDING), CHANGE IN ELECTRODE HOLDER STARTS-WITH REACH TO ELECTRODE HOLDER AND LEAD INCLUDES-ALL THE MOTIONS NECESSARY TO GET AUD HOLDER, GET ROD, INSTALL ROD IN HOLDER(HELD WITH CLAMP), AS IDE HOLDER AFTER USE ENDS-WITH AS IDE HOLDER CASE OI CHANGE FIRST ROD J2 CHANGE EACH ADDITIONAL RODIOJES NOT INCLUDE GET AND AS IDE HOLDER) |
| AF | 81X | MAA | 640 | MJPRRO1 | 93 | REGULATOR, READJUST, TWO TANKS STARTS—WITH REACH TO REGULATOR INCLUDES—ALL THE MOTIONS NECESSARY TO GRASP REGULATOR HANDLE AND TURN, ADJUST, REACH TO SECOND REGULATOR HANDLE, TURN HANDLE TO ADJUST, RELEASE HANDLE ENDS—WITH RELEASE HANDLE CONDITIONS—APPLICABLE TO ADJUSTING PRESSURE REGULATORS ON TWO OXY—ACETYLENE MELLING TANKS |
| FFF | 81X | маа | MJPCE04 | MJPSP01 | 173 | SHIFLD(WELDING), PUT ON AND REMOVE STARTS—WITH REACH TO PROTECTIVE SHIELD INCLUDES—ALL MOTIONS NECESSARY TO GET WELDERS PROTECTIVE SHIELD, PUT SHIELD ON AND LOWER COVER OVER FACE: AND REMOVE AND ASIDE SHIELD ENDS—WITH ASIDE SHIELD CONDITIONS—BORS NOT INCLUDE TIME FOR AUJUSTING HEACHARD |

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION . |
|----------------|-----|---------|----------------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AF | 81X | MAA | 261 | MJPSR01 | | SHIELD(WELDING), RAISE AND LOWER STARTS-WITH REACH TO HODD(ON HEAD) INCLUDES ALL THE MOTIONS NECESSARY TO GRASP AND LOWER HODD(SHIELD) INTO POSITION TO WELD, RELEASE HOOD, REACH, GRASP, RAISE AND RELEASE HOOD ENDS-WITH RELEASE HODD(SHIELD) |
| NF | 81X | MAF | 2685 | MJPTD01 | 251 | TIP(TORCH), DETACH BY HAND STARTS-WITH REACH TO TORCH INCLUDES-ALL MOTIONS NECESSARY TO GET TORCH, SCREW TIP OFF BY HAND, AND PLACE TIP ASIDE FNDS-WITH RELEASE OF TIP |
| NF | 81X | MAF | 3043 | 4JPTD02 | 104 | TIP(ELECTRODE), DETACH FROM SPOTWELDER STARTS-WITH REACH TO TIP, HAMMER IN DITHER HAND INCLUDES-ALL MOTIONS NECESSARY TO TAP ELECTRODE TIP WITH HAMMER TO LOOSEN, AND REMOVE TIP ENDS-WITH TIP AND HAMMER IN HAND |
| NF | 81X | MAF | 3345 | MJPTTOI | 121 | TIP(ELECTRODE), INSTALL ON SPOTWELDER STARTS-WITH TIP AND HAMMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE TIP TO ELECTRODE, POSITION, AND TAP WITH HAMMER ENDS-WITH HAMMER IN HAND |
| FFE | 81X | MAA | GTLTAA1 | MJPŤLO1 | 67 | TORCHIACETYLENE), LIGHT WITH FRICTION TYPE IGNITER STARTS-WITH TORCH IN HAND-GAS VALVE OPEN INCLUDES-ALL MOTIONS NECESSARY TO GET IGNITER, PLACE IGNITER TO TORCH, STRIKE IGNITER ONE TIME, AND ASIDE IGNITER ENDS-WITH RELEASE OF IGNITER. |
| NF | 81X | MAF | 2358 | MJPTRO1 | 119 | TENSION, RELEASE ON OXY-ACETYLENE WELDING REGULATOR STARTS-WITH REACH TO HANDLE INCLIDES-ALL THE MOTIONS NECESSARY TO TURN REGULATOR HANDLE TO RELEASE TENSION, RELEASE HANDLE ENDS-WITH RELEASE HANDLE |
| NF | 81X | MAF | 2357 | 10TV9LM | 321 | VALVEIOXY-ACETYLENE CYLINDER).TURN OFF STARTS-WITH WRENCH IN HAND, STANDING AT CYLINDER INCLUDES-ALL THE MOTIONS NECESSARY TO PUSITION WRENCH ON CYLINDER VALVE, TURN WRENCH FJUR TIMESIEIGHT INCH MOVE)TO TURN YALVE OFF ENDS-WITH VALVE TURNED OFF, WRENCH IN HAND CN VALVE |
| FFD | | TAA | KWLPTSA | | 5206 | WELDER(SPOT), PREPARE(ADJUST HEAT) STARTS-WITH HAND ON CONTROL DIALS INCLUDES-ALL THE MOTIONS NECESSARY TO ADJUST TEMPERATURE AND PRESSURE CONTROLS TO DESIRED JPERATING RANGE ENDS-WITH WELDER READY TO OPERATE-HANDS JA CONTROL CONDITIONS-INCLUDES ALL NECESSARY ADJUSTMENTS AND PREHEAT TIME |
| FFO | 81X | MAA | KWLSUTB | SJPTC01 | 669 | TIPIOXY-ACETYLENE TORCH). CHANGE WITH WRENCH STARTS-WITH REACH TO OPEN TOOL BOX INCLUDES -ALL MOTIONS NECESSARY TO GET WRENCH AND TIP FROM OPEN TOOL BOX. PLACE TIP IN WORK AREA.GET TORCH. REMOVE TIP NUT. ASIDE TIP. GET NEW TIP. PLACE ON TORCH. TIGHTEN TIP NUT. ASIDE TORCH. AND ASIDE WRENCH ENDS-WITH RELEASE OF WRENCH |

| DATA Source | | YTIJAUC | SOURCE | DWMSTDP ELEMENT | TMU VALUF | OPERATION/ELEMENT CESCRIPTION |
|----------------|-------|-------------|---------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MAA | atx | ₩ ₽4 | SHLEVHI | SJOTOXX | VARTABLE | TIP(ELECTRODE), GRIND STARTS-WITH REACH TO BENCH DRAWER STARTS-WITH REACH TO BENCH DRAWER INCLUDES-ALL THE MOTIONS NECESSARY TO DPEN BOWNER, GET BOX OF ELECTRODE TIPS OF DRAWER AND CLOSE DRAWER, TURN DON GROUP TO FROM BOX, POSITIC TO TO MOTION TO THE TOT THE T |
| | | | | | 205 165 | OZ GRIND EACH ADDITIONAL TIP O3 REGRIND WHEN REQUIRED |
| n <u>t</u> | SIX | MAF | SJPTLOI | SJPTL01 | 349 | TORCH(DXY-ACETYLENE), LIGHT AND TURN OFF STARTS-WITH REACH TO TORCH INCLUDES-ALL ROLLITOM NECESSARY TO OBTAIN TORCH FROM HANGER, OPEN ACETYLENE VALVE, GET IGNITER, LIGHT TORCH, AS IDE IGNITER, JPEN DXYGEN VALVE, ADJUST FLAME; AND TURN VALVES OFF ENDS-WITH ASIDE TORCH TO HANGER |
| ۸۵۵ | 8 t x | MUA | OTLWSXX | SNFSWXX | VARIARLE | SPOTIOR SEAM), WELD STARTS-WITH GET GROUND CARLE INCLUDES-ALL MOTIONS NECESSARY TO ATTACH GROUND CABLE, PUT ON GLOVES, GET METAL AND POSITION FOR WELDING, GET WELDING GUN. WELD, ASIDE GUN. AND REMOVE GLOVES ENDS-WITH REMOVE AND ASIDE GROUND CABLE |
| | | | | | 769 | CASE OF WELD FIRST TWO INCH SEAM IN STAINLESS STEEL FOIL TO .004 INCH WITH ROLLER TIP GUN |
| | ٠ | • | • | | 174 ° | 02 EACH ADDITIONAL TWO INCH SEAM IN STAINLESS STEEL FOIL TO .004 INCH WITH ROLLER TIP GUN 03 WELD FIRST TWO SPOTS IN STAINLESS |
| | | | | | 50 | STEEL TO .010 INCH WITH POINTER TIP GUN 04 EACH ADDITIONAL SPOT IN STAINLESS STEEL TO .010 INCH WITH POINTER TIP GUN |
| FFO | 91x | M A A | KWLSPXX | SNFWAXX | VARTABLE | WELD(SPOT), ACCOMPLISH STARTS-WITH REACH TO MAIN SWITCH INCLUDES-ALL THE MOTIONS AND TIME NECESSARY TO TURN ON MAIN SWITCH, PUT ON AND REMOVE APRON. GLOVES(LODSE FIT), FACE SHIELD, REMOVE BOTH ELECTRODES, INSTALL ELECTRODES, OPESS TIP, TYRN MACHINE ON, PREPARE SPOT WELDER (ADJUST HEAT), GET PART, WELD SPOT, AS IDE PART, TURN OFF MACHINE ENDS-WITH REMOVE PROTECTIVE CLOTHING |
| | | | | | 8306 89 | CASE OI SPOT WELD FIRST OR SINGLE SPOT OZ SPOT WELD EACH ADDITIONAL SPOT WITH ONE TO THREE INCH SPACING |
| NAA | 91X | миа | OTLWSXX | SNFWSXX | VARIARLE | SPOT(OR SEAM), WELD ON SCIAKY STATIONARY WELDING MACHINE STARTS-WITH GET PART INCLUDES-WALL MOTIONS NECESSARY TO MOVE PART IN POSITION FOR WELDING, WELD SPOT OR SEAM, AND REMOVE PART ENDS-WITH ASIDE PART |
| | | | | | 212 | CASE OF WELD ONE SPOT ON MID-RANGE REPEAT CYCLE, ALUMINUM OR STEEL TO .390 INCH THICKNESS |
| | | | | | 811 | 02 WELD FIRST TWO INCH SEAM, ALUMINUM 3P STEEL TO .053 INCH THICKNESS. MACHINE SPEED 20 INCHES PER MINUTE |
| | | | | | 167 | 93 EACH ADDITIONAL TWO INCHES OF SEAM, ALUMINUM OR STEEL TO .350 INCH, MACHINE SPEED 20 INCHES PER MINUTE |

| DATA | | QUAL ITY | SOURCE CODE | OWMSTOP ELEMENT | TMU VA LUE | OPERATION/ELEMENT DESCRIPTION |
|-----------|-------|----------|----------------|--------------------|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4 E | 31X | MAW | SWOEAMI | MOHTPO1 | 355 | TANK, PUT ON HAND TRUCK STARTS—BITH REACH TO HAND TRUCK HANDLES INCLUDES—ALL MOTIONS NECESSARY TO GET HAND TRUCK-TILI TRUCK AND WALK THREE PACES TO MOVE TRUCK TO TOPE OF POSITION, RELEASE TRUCK, REACH TO TANK, TIP TANK TO SIDE, MUVE HAND TRUCK UNDER TANK, GET TRUCK HANDLES AND TILT TRUCK WITH LOAD TAKING TWO STEPS TO HALANCE HAND TRUCK ENDS—WITH TANK BALANCED ON HAND TRUCK |
| ΔF | 81X | MAW | SWDEANL | MOHTRO1 | 126 | TANK, REMOVE FROM HAND TRUCK STAPTS-WITH RELEASE HANDLES OF HAND TRUCK INCLUDES-ALL MOTIONS NECESSARY TO TILT TANK, PULL HAND TRUCK FROM UNDER TANK AND SET TANK DOWN ENDS-WITH RELEASE TANK |
| FFO | 8 t X | TAA | KWLPTSC | 8PTSW01 | 68 | SPOT WELD STARTS-WITH MATERIAL ROPORTH HIS STARTS OF COURT OF STARTS OF COURT OF SPOT WITH THE TORS OF COURT OF SPOT WITH THE SPOT OF TORS COURT COURT OF SPOT OF TORS TANK OF SPOT COURT OF SPOT OF STARTS OF STARTS OF SPOT |
| ΔF | 81× | MAA | 604 | MSŲCAOI | 187 | CYCLE DIALS(SPOT WELDING MACHINE), ADJUST STARTS-WITH REACH TO CIAL INCLUDES-ALL THE MOTIONS NECESSARY TO GRASP AND TURN FIRST DIAL, CHECK FOR PROPER SETTING, TURN-HOLD DIAL AND CHECK FOR PROPER SETTING, TURN-HOFF-DIAL AND CHECK FOR PROPER SETTING, TURN IGNITION SWITCH ON, PELEASE SWITCH ENDS-WITH RELEASE IGNITION SWITCH |
| | 81% | MUA | OTLWSXX | SSUMSO1 | 3995 | MACHINE (WELDING), SET UP, SCIAKY OR SIMILAR AND TEST WELD THREE SPOTS STARTS-WITH TURN AND WALK TO LEFT HAND PANEL INCLUDES-ALL MOTIONS NECESSARY TO ADJUST THREE DIALS, RETURN THREE PACES TO WELD POSITION, TURN AND WALK THREE PACES TO RIGHT HAND PANEL, ADJUST AIR PRESSURE, ADJUST ELECTRICAL CUNTACT PRESSURE, RETURN TO WELD POSITION, ACTUATE "RAISE" SWITCH, CLEAN ELECTRODES, ACTUATE "LOWER" SWITCH, CLEAN ELECTRODES, ACTUATE "LOWER" SWITCH, GET AIR HOSE AND BLOW OFF ELECTRODES, ASIDE AIR HOSE, GET TEST STRIPS, WELD THREE SPOTS, VISUALLY CHECK SPOTS, ASIDE STRIPS, GET TEST STRIPS AND WELD—TH BANK, ASIDE STRIPS, GET TEST STRIPS AND WELD—THA BANK, ASIDE STRIP, GET TEST STRIPS AND WELD—THA BANK, GET "TH STRIP", CARRY THREE PACES TO TENSION TESTER, PERFORM TENSION TEST ON EACH OF TWO |
| er er | | | | | | WELDS.AND RETURN TO WELD POSITION ENDS-WITH SETUP AND TESTS CUMPLETE CONDITIONS-ALUMINUM OR STEEL TO .090 INCH THICKNESS |

| OATA Source | | QUALITY | SOURCE | DWMSTDP ELEMENT | TMU VALÜE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-------------|------------|-----------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NAA | 81X | MAA | OTLWSXX | SSUMSO2 | 3461 | MACHINE (WELDING), SET UP, SCIAKY OR SIMILAR AND TEST WELC ONE TWO INCH SEAM STARTS—MITH TURN AND HALK TO LEFT HAND PANEL INCLUDES—ALL MOTIONS NECESSARY TO ADJUST THREE DIALS, RETURN THREE PACES TO WELD POSITION; TURN TO RIGHT SIDE PANEL, ADJUST AIR PRESSURE AND ELECTRICAL CONTACT PRESSURE, TURN AND HALK ONE PACE TO RIGHT HAND PANEL, ADJUST MOTOR SPEED RHEOSTAT, RETURN TO WELD POSITION, CLEAN TOP AND BOTTOM WHEELS WITH SANDPAPER, WIPE WHEELS WITH CLOTH TO REMOVE DUST, TURN, GET TEST STRIPS, TURN, PLACE STRIPS TO WHEELS, WELD TWO INCH SEAM, VISUALLY CHECK SEAM, GET PLIERS, BEND EACH STRIP 90 DEGREES, ASIDE PLIERS, ATTACH CLAMPS, PERFORM SHEAR TEST, AND REMOVE CLAMPS ENDS—WITH ASIDE STRIP |
| NO | 81X | MAO | LHWIF1 | MTPTIOL | 119 | TOOL, INSERT AND REMOVE, AIR HAMMER STARTS-WITH REACH TO TOOL INCLUDES-ALL MOTIONS NECESSARY TO GET TOOL, POSITION AND INSERT IN AIR HAMMER; REACH TO TOOL, DISENGAGE AND ASIDE TOOL ENOS-WITH RELEASE OF TOOL |
| FFD | \$10 | MAA | KWL SUTE | HJPEG01 | 221 | ELECTRODE(HELI-ARC WELDING), GRIND STARTS-WITH REACH TO SWITCH INCLUDES-ALL THE MOTIONS NECESSARY TO TURN ON PEDESTAL GRINDER, GRIND ELECTRODE, INSPECT TIP, TURN OFF GRINDER ENDS-WITH TURN OFF GRINDER |
| FFD | 810. | MAA | KWL SUA A | MJPMS01 | 303 | MACHINE (ARC WELDING), SET UP STARTS-WITH STOOP TO WELDING MACHINE INCLUDES-ALL THE MOTIONS NECESSARY TO STOOP, TURN MACHINE ON, SET RANGE CONTROL DIAL FOR CORRECT HEAT RANGE, GET AND ATTACH GRUUND CLAMP TO WORK AND GROUND, REMOVE AND ASIDE GLAMP, ARISE FROM STOOP ENDS-WITH ARISE FROM STOOP |
| FFO | 810 | MAA | KWL SUAE | 4JPPC01 | 293 | POLARITY (ARC WELDING MACHINE), CHANGE STARTS-WITH BEND TO MACHINE INCLUDES-ALL THE MOTIONS NECESSARY TO REMOVE AND EXCHANGE NEGATIVE AND POSITIVE LEADS FNOS-WITH ARISE FROM BEND |
| FFO | 810 | MAA | KWL SUXX | SJPECXX | 1100 377 | ELECTRODE (HELI-ARC WELDING), CHANGE STARTS-WITH HOLDER IN HAND INCLUDES-ALL THE MITIONS NECESSARY TO GRASP AND REMOVE CAP, ASIDE CAP, GET AND ASIDE COLLET AND ELFCTRODE, PEMOVE AND ASIDE CUP, LOUSEN COLLET HOLDER, PLACE COLLET IN TORCH, PLACE ELECTRODE IN TORCH, SCREW IN CUP AND TIGHTEN, SCREW CAP ON AND PLACE ELECTRODE TO WORK PIECE ENDS-WITH ELECTRODE IN POSITION TO WELD CASE OI REMOVE ELECTRODE OF ANOTHER SIZE WITH ELECTRODE OF ANOTHER SIZE OZ REMOVE ELECTRODE AND REPLACE WITH ELECTRODE OF SAME SIZE |
| OL | 810 | MAF . | SJPRC 01 | SJP9C01 | 354 | ROD(WELDING), CHANGE IN ELECTRODE HOLDER STARTS-WITH BREAK ARC AND MOVE ROD FROM WORK INCLUDES—ALL MOTIONS NECESSARY TO RAISE HOOD, OPEN CLAMP, REMOVE ROD FROM HOLDER, GET ROD, PLACE IN HOLDER, CLOSE CLAMP, MOVE ROD OVER WORK, LOWER HODO, MOVE ROD TO WORK, AND STRIKE ARC ENDS—WITH ROD IN POSITION FOR WELDING |

| DATA Source | | QUAL ITY | SOURCE | DEMSTOP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ΔE | 810 | MAW | SWOEAC 1 | MNFEP01 | , 53 | ELECTRODE, POSITION AND STRIKE ARC STARTS-WITH ELECTRODE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE AND POSITION ELECTRODE, FOCUS EYES AFTER LOWERING HOOD, STRIKE ARC, MOVE AND POSITION ELECTRODE FOR ARC WELD ENDS-WITH ELECTRODE POSITIONED FOR WELD CONDITION-TIME TO LOWER HOOD NOT INCLUDED |
| FFD | 810 | EUA | RWHALOI | MNFWAXX | VARTABLE | <pre>beld.accomplish.arc weld.per inch starts=with rod in welding position.arc started includes=all motions necessary to fuse=weld one linear inch ends=with weld completed.rod positioned to material</pre> |
| | | | | | 467 | CASE OI WELD ONE LINEAR INCH, ALUMINUM OR MAGNESIUM |
| | | | | | 2080 | OZ WELD ONE LINEAR INCH, STAINLESS STEEL, USE .0625 INCH ROD |
| NAA | 810 | MAA | SHLIWXX | SNEHMXX | VARTABLE | WELD(INERT GAS-ARC), MAKE STARTS-WITH REACH TO WELD TORCH INCLUDES-ALL THE MOTIONS NECESSARY TO GET AND POSITION WELD TORCH TO PART, OBTAIN WELD KOD AND POSITION TO PART, FLIP HOOD DOWN WITH NOD OF HEAD, PLACE FOOT ON PEDAL AND DEPRESS, PLACE WELD ROD TO WELD POINT, PLACE TORCH TO WELD ROD AND WELD POINT, RELEASE FOOT PEDAL, ASIDE FOOT, |
| | | | | | | ASIDE ROD TO BENCH-MOVE TORCH FROM PART-RAISE HODD, ASIDE TORCH TO HOLDER ON BENCH ENDS-WITH ASIDE TORCH CONDITIONS-APPLIES TO LINDE HW-18 OR HW-20 WELDERS OR SIMILAR125 INCH THICK STEEL OR ALUMINUM-INERT GAS.METAL ARC |
| | | | | | 1259 | CASE O1 FIRST OR SINGLE INCH-MOVE TURCH AND ROD 16 TIMES TO MAKE WELD 02 EACH ADDITIONAL INCH-MOVE TORCH AND |
| | | | | | 784 578 | ROD 16 TIMES TO MAKE WELD 03 TACK WELD-FIRST OR SINGLE SPOT-MOVE |
| | | | | | 408 | TORCH AND ROD TWO TIMES TO MAKE WELD OF TACK WELD-EACH ADDITIONAL SPOT-MOVE TORCH AND ROD TWO TIMES TO MAKE WELD |
| AF | 810 | OBW | 151831 | MOHABO1 | 193 | ARC, BREAK AND MOVE TO NEXT WELD STARTS-WITH BREAK ARC AND MOVE ROD FROM WORK INCLUDES-ALL MOTIONS NECESSARY TO RAISE HOOD, SIDESTEP TO NEXT WELD, MOVE ROD OVER MURK, LOWER HOOD, MOVE ROD TO WORK, AND SCRATCH SURFACE TO STRIKE ARC |
| | | | | | | ENDS-WITH ROD IN POSITION TO MAKE WELD |
| NO | 811 | MAC | LHW1R1 | MAC VOXX | VARIABLE | VALVES(BLOWPIPE OXYGEN AND ACETYLENE). DPEN AND CLOSE STARTS-WITH REACH TO OXYGEN VALVES INCLUDES-ALL MOTIONS NECESSARY TO SLIGHTLY OPEN OXYGEN VALVE, THEN REACH TO AND FULLY OPEN ACETYLENE VALVE; REACH TO OXYGEN VALVE, CLOSE, REACH TO ACETYLENE VALVE, AND CLOSE |
| | | | | | 74 | ENDS-WITH RELEASE VALVE CASE OI UPEN THO VALVES OZ CLOSE THO VALVES |
| NO | 811 | DAM | LHW102 | MCLHC01 | 751 | HOLESITORCH TIP).CLEAN STARTS-WITH MOVE CLEANER TO TIP INCLUDES-ALL MOTIONS NECESSARY TO POSITION CLEANER IN HOLE.MOVE BACK AND FORTH TO CLEAN HOLE AND REMOVE CLEANER FROM HOLE.SIX TIMES ENDS-WITH DISENGAGE CLEANER FROM SIXTH HOLE |

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| · NO | 811 | MAO | LHW1E2 | MCLHC02 | 62 | HOLE(HIGH PRESSURE TIP).CLEAN STARTS-WITH MOVE TAPERED CLEANER TO HOLE INCLUDES-ALL MOTIONS REQUIRED TO POSITION CLEANER IN HOLE AND ROTATE CLEANER IN HOLE ENDS-WITH CLEANER MOVED FROM HOLE |
| NO | 811 | MAG | LHW1S1 | MJPBL01 | 120 | BLOWPIPE, LIGHT STARTS-WITH REACH TO LIGHTER IN HIP POCKET INCLUDES-ALL MOTIONS NECESSARY TO GET LIGHTER, POSITION IT TO BLOWPIPE TIP, STRIKE LIGHTER, MOVE LIGHTER FROM FLAME, AND RETURN LIGHTER TO POCKET ENDS-WITH RELEASE LIGHTER |
| NAA | 811 | MAA | SWLTJOE | MJPTRO1 | 635 | TIP(ELECTRODE—GAS), REPLACE STARTS—WITH REACH TO GAS CAP ON TORCH INCLIDES—ALL THE MOTIONS NECESSARY TO GRASP AND LOOSEN GAS CAP(THREE TURNS), REPLACE DAP AND GRASP ELECTRODE TIP, DISENGAGE TIP FROM GAS LENS COLLET BODY AND ASIDE TIP, PICK UP PROPER TIP AND INSTALL IN COLLET, GRASP GAS CAP AND TURN DOWN THREE TURNS, TIGHTEN CAP, RELEASE CAP ENDS—WITH RELEASE CAP CONDITIONS—FOR LINDE HW—18 AND HA—20 HELDING TIPS |
| NO | 811 | MAO | CHW1U1 | монвро1 | 45 | BLOWPIPE, POSITION TO METAL STARTS-WITH BLOWPIPE IN PIGHT HAND INCLUDES-ALL MGTIONS NECESSARY TO MOVE BLOW- PIPE TO LEFT HAND AND USE TWO HANDS TO POSITION TIP OF BLOWPIPE TO POINT OF CUT ENDS-WITH BLOWPIPE IN POSITION TO CUT |
| Δ F | 813 | MAA | 608 | MSUTSO1 | 129 | THYRATON CONTROLS (SPOT WELDING MACHINE).SET STARTS-WITH REACH TO FIRST CONTROL INCLUDES-ALL THE MOTIONS NECESSARY TO POSITION POINT AND CHECK READING FOR FIRST CONTROL, SET RANGE SWITCH AND CHECK RANGE, ADJUST PER- CENT CONTROL POINTER.RELEASE CONTROL ENDS-WITH RELEASE PERCENT CONTROL |
| ΔF | 814 | MAA | 8 | SJPPPO1 | 2 80 | PRESSURE, PUMP IN BLOW, TORCH TANK STARTS-4ITH SIMO REACH TO TANK AND PUMP HANDLE INCLUDES-ALL MOTIONS NECESSARY TO LOUSEN VALVE SEAT BY TURNING PUMP HANDLE, MOVE HANDLE JP AND DOWN EIGHT STROKES TO BUILD PRESSURE, AND TIGHTEN VALVE SEAT ENDS-WITH RELEASE OF TORCH AND HANDLE |
| NF | 814 | MAF | 1257 | 47F SAXX | VARIABLE 46 12 | SOLDER, APPLY TO SEAM OR JOINT, SHEET METAL STARTS—WITH SCLDER AND IRON IN HAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE SILUTA AND IRON TO JOINT, MOVE SOLDER AND INJA OVER JOINT TO SPREAD SOLDER, MOVE SOLDER ANAY, AND MOVE IRON AWAY ENDS—WITH SOLDER AND IRON IN HAND CONDITIONS—TIME FOR HEATING IRON AND SOLDER NOT INCLUDED CASE OI FIRST LINEAR INCH 02 EACH ADDITIONAL LINEAR INCH WITHJUT LIFTING IRON AND SOLDER FROM ARRA |
| AF | 816 | MAA | 146 | MACFE01 | . 78 | FEED(FLAME CUTTING MACHINE), ENGAGE TO START AND TURN OFF STARTS-WITH REACH TO SWITCH BUITON INCLUDES—ALL THE MOTIONS NECESSARY TO TORM SWITCH BUTTON ON AND OFF, MOVE CLUTCH LEVE? TO ENGAGE ENDS-WITH TURN OFF SWITCH CONDITIONS—RADIGRAPH TYPE MACHINE |

| OATA SQUPCE | | YTIJAUC | SOURCE | DWMSTDP ELEMENT - | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|------------|--------|----------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 816 | MAA | 3418 | MJPTA01 | 152 | TORCH(DXY-ACETYLENE-CUTTING), ADJUST FOR CUTTING BEVEL STARTS-WITH SIMO REACH TO TIP OF TORCH AND WING NUT |
| | | | | · | | INCLUDES-ALL THE MOTIONS NECESSARY TO GRASP AND MOLD TORCH WITH RIGHT HAND, LOOSEN WING NUT WITH LEFT HAND, PUSH TORCH TIP TO DESIRED DE- GREE, TIGHTEN WING NUT, RELEASE TORCH ENDS-WITH WING NUT TIGHTENED, TORCH RELEASED |
| NF | 816 | M&A | 2577 | MSUBP01 | 145 | BARIRADIUS), PLACE IN AND REMOVE FROM FLAME CUTTING MACHINE STARTS-WITH REACH TO RADIUS BAR INCLUDES-ALL MOTIONS NECESSARY TO GET RADIUS BAR, MOVE TO MACHINE, POSITION IN SLUT; GET RADIUS BAR, REMOVE BAR FROM MACHINE, AND ASIDE BAR ENDS-WITH RELEASE OF BAR |
| ΔF | 816 | MAA | 147 | MSUMPO1 | 91 | MACHINE (FLAME CUTTING), PLACE ON RING STARTS-WITH REACH TO MACHINE INCLUDES-ALL THE MOTIONS NECESSARY TO GRASP THE MACHINE, LIFT AND PLACE MACHINE ON RING, RELEASE MACHINE, GET RADIUS BAR, POSITION RADIUS BAR IN PUNCH MARK, RELEASE MACHINE ENDS-WITH RELEASE MACHINE CONDITIONS-RADIGRAPH TYPE MACHINE |
| NF | 816 | MAA | 3344 | MSURPO1 | 128 | RING(FLAME CUTTING MACHINE), POSITION ON PLATE TO BURN CIRCLES STARTS-WITH RING IN HAND, REACH TO PLATE INCLUDES-ALL THE MOTIONS NECESSARY TO GET PLATE, PLACE PLATE FOR BURNING, RELEASE PLATE AND REACH BACK TO PLATE ENDS-WITH HAND RETURNED TO PLATE CONDITIONS-RADIGRAPH TYPE MACHINE-MOVE PLATE |
| AF | 816 | MAA | 145 | 4SUSA01 | 65 | SPEED DIAL(FLAME CUTTING MACHINE), ADJUST STARTS-WITH REACH TO DIAL INCLUDES-ALL THE MOTIONS NECESSARY TO GRASP AND TURN DIAL TO SPEED LETTER, POSITION DIAL TO LINE, RELEASE DIAL ENOS-WITH RELEASE DIAL CONDITIONS-RADIGRAPH TYPE MACHINE |
| AF | 916 | MAA | 151 | MSUTPO1 | 103 | TORCH ARM(FLAME CUTTING MACHINE), POSITION FOR BURNING CIRCLES OR STRAIGHT LINES STARTS-WITH REACH TO ADJUSTMENT KNOB INCLUDES-ALL THE MOTIONS NECESSARY TO ADJUST ARM TO CHALK LINE, CHECK POSITION OF ARM AND MACHINE BY MOVING IN CIRCLE BY HAND, RELEASE MACHINE ENDS-WITH RELEASE MACHINE CONDITIONS-RADIGRAPH TYPE MACHINE |
| ЧF | 816 | MAA | 1288 | MSUWR01 | - 155 | WHEEL(FLAME CUTTING MACHINE), REMOVE STARTS-WITH REACH(SIMO) TO MACHINE AND WING NUT INCLUDES-ALL MOTIONS NECESSARY TO HOLD MACHINE WITH LEFT AND LOOSEN WING NUT WITH RIGHT HAND, RELEASE MACHINE WITH LEFT HAND AND GRASP LEFT LEVER, MOVE LEVER AND REMOVE WHEEL, LOWER MACHINE, RELEASE WHEEL ASIDE ENDS-WITH RELEASE WHEEL CONDITIONS-RADIGRAPH TYPE MACHINE |

| DATA SOURCE | | QUALITY | | OWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|--------------|---------|---------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AF | 82X | MAA | MOE-201 | MOACIO1 | 586 | COVER(RACEWAY BASE SECTION). INSTALL STARTS-WITH COVER IN HAND INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE THE COVER TO THE BASE SECTION. INSERT LEADING CORNER OF COVER INTO CHANNEL HOLD CORNER IN CHANNEL AND INSERT TRAILING EDGE OF SAME SIDE INTO CHANNEL AND HOLD. RELEASE LEADING CORNER WITH RIGHT HAND AND GRASP AND HOLD CENTER WITH PALM AND THUMB. RELEASE TRAILING CORNER WITH LEFT HAND AND GET SCREWORIVER FROM BELT KIT. INSERT SCREWORIVER BETWEEN COVER AND BASE SECTION OF OPPOSITE SIDE AND HOLD LEVENAGE. RELEASE COVER WITH RIGHT HAND. GET MALLET FROM BELT KIT. HAMMER SECOND EDGE INTO CHANNEL. RETURN MALLET TO BELT KIT. REMOVE AND ASIDE SCREWORIVER ENDS-WITH RETURN SCREWORIVER TO BELT KIT CONDITIONS-BASE SECTION AVERAGE FOUR FEET LONG |
| ΔF | 82X | MAA | MOE-251 | MOALCOL | 64 | LUGITERMINAL), CONNECT TO SWITCH STARTS-WITH SWITCH ASSEMBLY IN HAND(LEFT) INCLUDES-ALL THE MOTIONS NECESSARY TO KEACH RIGHT HAND TO RACEWAY AND GRASP A CONDUCTOR, MOVE CONDUCTOR WITH LUG TERMINAL) AND INSERT IN SWITCH, PUSH CLAMP SCREW WITH THUMB OF LEFT HAND, RELEASE CONDUCTOR ENOS-WITH SWITCH ASSEMBLY IN LEFT HAND |
| AF | 82X | MAA | MDE-3Q1 | 'MOAŠTO1 | 65 | SUCKET(LAMP), INSERT IN REFLECTOR FITTING STARTS-WITH SOCKET IN LEFT HAND, RIGHT HAND HOLDING ASSEMBLY INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE SOCKET TO FITTING AND POSITION WITH RIGHT |
| | · | | | | | HAND, HOLD SOCKET TO FITTING AND REACH TO FITTING WITH LEFT HAND, GPASP AND HOLD FITTING AND SOCKET BETWEEN THUMB AND FOREFINGER, RELEASE HOLD WITH RIGHT HAND, REGRASP SOCKET AND FITTING AND ALIGN AND PRESS TOGETHER WITH BOTH HANDS, RELEASE RIGHT HAND, HOLD WITH LEFT ENDS—WITH LEFT HAND HOLDING ASSEMBLY CONDITIONS—LEECRAFT SOCKET |
| NF | 82X | M&F | 802/804 | MJPFUXX | 217 144 | FISHTAPE (ELECTRICAL), UNWRAP FROM AND WRAP ON REEL, PER FOOT STARTS-WITH REEL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO GET END OF TAPE, PULL OUT SIX-INCH LENGTH, RELEASE TAPE, GET END, AND PULL OUT SIX-INCH LENGTH; AND GET FISHTAPE REEL, AND WRAP TAPE ON REEL ENDS-WITH FISHTAPE IN HAND CASE OI FIRST FOOT 02 EACH ADDITIONAL FOOT |
| NF | 82X | MAF | 847 | MJP0P01 | 187 | OILER, PREPARE FOR FILLING STARTS-WITH REACH TO SLIDE COVER ON OILER INCLUDES-ALL MOTIONS NECESSARY TO MOVE COVER ASIDE, PICK UP FUNNEL, PLACE IN OILER, GET OIL CONTAINER, MOVE CONTAINER INTO POSITION TO POUR, MOVE CONTAINER AWAY, MOVE FUNNEL AWAY, AND REPLACE COVER ENDS-WITH RELEASE OF COVER CONDITIONS-TIME FOR POURING OIL NOT INCLUDED. APPLICABLE TO OILERS SUCH AS THOSE FOUND ON ELECTRIC FANS AND BLOWERS |
| NF | 8 <i>2</i> X | MAF | 2396 | MJPST01 | 161 | SWITCH, TUPN OFF OR ON, BRANCH LIGHTING CIRCUIT STARTS-WITH REACH TO PANEL DOOR INCLUDES-ALL MOTIONS NECESSARY TO OPEN DOOR, LOCATE SWITCH, TURN SWITCH OFF OR ON, AND CLOSE DOOR ENDS-WITH RELEASE OF DOOR CONDITIONS-DOES NOT INCLUDE TIME TO LOOK AT PANEL SCHEMATIC TO DETERMINE SWITCH NUMBER |

| DATA SOURCE | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|--------------|----------------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 82X | MAF | 876 | SNFTA01 | 443 | TAPE.APPLY TO WIRE SPLICE STARTS-WITH REACH TO ROLL OF TAPE INCLUDES-ALL MOTIONS NECESSARY TO OBTAIN A 10-INCH LENGTH OF TAPE FROM ROLL.ASIDE ROLL OF TAPE.POSITION TAPE TO WIRE SPLICE.WRAP SPLICE SIX REVOLUTIONS.AND PRESS TAPE TO SPLICE ENOS-WITH RELEASE OF TAPED SPLICE |
| FFO | 82X | MAA . | KALED10 | SNFTR01 | 157 | TIE(SPOT), REMOVE STARTS-WITH REACH TO GET TOOLS(CUTTER) INCLUDES-ALL THE MOTIONS NECESSARY TO GET CUTTER WITH RIGHT HAND, GRASP WIRE WITH LEFT HAND, CUT LINE WITH CUTTER(TWO CUTS), REMOVE LACING, ASIDE CUTTER AND LACING ENDS-WITH ASIDE CUTTER |
| FFD | 62X | MAA | KALEWAX | SNFWCXX | 1200 138 | WIRE BUNDLE, COIL AND TIE STARTS-WITH REACH TO WIRE BUNDLE INCLUDES-ALL THE MOTIONS NECESSARY TO GET WIRE BUNDLE, COIL WIRE, GET AND UNWIND ONE FOOT OF LACING CORD, TIE COIL OF WIRE BUNDLE WITH THREE KNOTS, CUT LACING, ASIDE CUTTER, ASIDE WIRE BUNDLE COIL ENOS-WITH COIL ASIDE CONDITIONS-USE WHEN WIRE BUNDLE IS COILED AND SECURED TO EXISTING WIRE BUNDLE OR COILED FOR STORAGE-SPOT TIE IN THREE PLACES CASE OI COIL AND TIE FIRST OR ONLY THREE FEET OF WIRE O2 COIL EACH ADDITIONAL THREE FEET OF WIRE |
| FFD | 82X | HAA | KALEAI3 | SNFWT01 | 1838 | WIRE BUNDLE, TAPE AND TIE STARTS-WITH REACH TO ROLL OF TAPE INCLUDES-ALL THE MOTIONS NECESSARY TO GET ROLL OF TAPE, GET END OF TAPE AND UNROLL, CUT TAPE, ASIDE TAPE ROLL AND CUTTER, WRAP TAPE ON WIRE BUNDLE, GET AND UNWIND ONE FOOT OF LACING CORD, TIE TWO KNOTS ON TAPE AROUND WIRE BUNDLE, CUT CORD AND ASIDE CUTTER ENDS-WITH ASIDE CUTTER CONDITIONS-WRAP 24 INCHES OF INSULATING TAPE ON SIX INCHES OF WIRE BUNDLE, TIE IN TWO PLACES |
| NF | 82X | MAF | 828 | MOH8101 | 914 | BOX(JUNCTION), INSTALL ON CONDUIT STARTS-LITH GET LOCKNUT INCLUDES-ALL MOTIONS NECESSARY TO INSTALL LOCKNUT ON END OF CONDUIT(TEN THREADS), GET JUNCTICN BOX, PLACE BOX ON END OF CONDUIT, GET SECOND LOCKNUT, PLACE ON END OF CONDUIT, TURN DOWN SIX THREADS BY HAND, GET SCREWORIVER, GET HAMMER, PLACE SCREWDRIVER TO LOCK NUT INSIDE BOX, STRIKE SCREWDRIVER WITH HAMMER UNTIL NUT IS TIGHT, AND ASIDE SCREWDRIVER AND HAMMER ENDS-WITH RELEASE OF SCREWDRIVER AND HAMMER CONDITION-TIME TO REMOVE KNOCKOUT PLUG FROM JUNCTION BOX NOT INCLUDED |
| NF - | 82X | MAF | 848 | MOHPRO1 | 90 | PAPER, REMOVE FROM CONDUCTOR AFTER OUTER INSULATION HAS BEEN STRIPPED STARTS-WITH REACH TO PAPER INCLUDES-ALL MOTIONS NECESSARY TO UNTWIST AND REMOVE PAPER WRAPPING FROM CONDUCTOR ENDS-WITH ASIDE PAPER |
| NF | 82X | MAF. | 910 | MOH WA 01 | 1 70 | WIRE, ALIGN FOR FORMING IN ELECTRICAL BOX STARTS - WITH REACH TO WIRE INCLUDES - ALL MOTIONS NECESSARY TO APPLY PRESSURE AND MOVE INTO ALIGNMENT IN BOX. ALSO INCLUDES VISUAL CHECK OF ALIGNMENT ENDS - WITH RELEASE OF WIRE |

| DATA SOURCE | | QUAL ITY | SOURCE CODE | OWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-------|----------|----------------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 82X | MAF | 911/913 | МОНW8XX | 99 | WIRE, BEND 90 DEGREES FOR FORMING IN ELECTRICAL BOX STARTS-WITH REACH TO WIRE INCLUDES-ALL MOTIONS NECESSARY TO MAKE 90- DEGREE BEND BY HAND AND TO CHECK ALIGNMENT ENDS-WITH BEND COMPLETED CASE 01 BEND NO-10 WIRE 02 BEND NO-4 TO NO-2 WIRE |
| NF | 82X | MAF | 946 | MOHWROI | 140 | WRAPPING (PAPER), REMOVE FROM COIL OF WIRE STARTS-WITH KNIFE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO BEND TO COIL OF WIRE, CUT PAPER WRAPPING, ASIDE KNIFE TO TOOL POUCH, LIFT COIL ON EDGE, AND UNWRAP PAPER FROM COIL ENDS-WITH ARISE |
| FFD | 82X | MAA | KALEA14 | SOHPPO1 | 1393 | PLUG/RECEPTACLE, PLACE IN PLASTIC BAG STARTS-WITH REACH TO GET BAG INCLUDES-ALL THE MOTIONS NECESSARY TO GET BAG, OPEN AND PLACE PLUG/RECEPTACLE IN BAG, GET LACING CORD AND UNWIND ONE FOOT, TIE BAG IN TWO PLACES, CUT CORD, AS IDE SPOOL AND CUTTER ENDS-WITH ASIDE CUTTER |
| NF | 82X | MAF | 880 | MTLBC01 | 253 | BANDING, CUT ON REEL OF WIRE, CABLE, OR SIMILAR STARTS—WITH REACH TO SCREWDRIVER INCLUDES—ALL MOTIONS NECESSARY TO GET SCREWDRIVER FROM BELT KIT, INSERT SCREWORIVER UNDER BANDING, STRETCH BANDING, RETURN SCREWDRIVER TO KIT, GET PLIERS, CUT BANDING, AND RETURN PLIERS TO BELT KIT ENDS—WITH RELEASE OF PLIERS |
| NF | 82X | MAF | 2660 | MTLCR01 | 175 | CONDUIT, REAM END. ONE INCH DIAMETER, HAND REAMER STARTS-WITH REAMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO PLACE REAMER IN END OF CONDUIT, REAM AND REMOVE REAMER ENDS-WITH REAMER IN HAND |
| NF | 8 2 X | M&F | 800 | MTLFU01 | 68 | FISHTAPE (ELECTRICAL), USE, FEED INTO CONDUIT STARTS—WITH FISHTAPE IN HAND INCLUDES—ALL MOTIONS NECESSARY TO PUSH ONE FOOT OF FISHTAPE INTO CONDUIT ENDS—WITH HAND ON FISHTAPE |
| NF | 82X | MAF | 805 . | MTLFU02 | 48 | FISHTAPE (ELECTRICAL), USE, DISENGAGE TWO TAPES STARTS-WITH SIMO REACH TO TWO FISHTAPES INCLUDES-ALL MOTIONS NECESSARY TO SEPARATE TWO FISHTAPES BY UNHOOKING ENDS-WITH ASIDE FISHTAPES |
| NF | 82X | MAF | 819 | MTLHC01 | 85 | HDLE.CUT IN CARDBOARD CONTAINER WITH KNIFE STARTS-WITH KNIFE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO CUT HOLE APPROXIMATELY FOUR INCHES IN DIAMETER IN CAROBOARD CONTAINER AND ASIDE CARDBOARD DISC ENDS-WITH KNIFE IN HAND CONDITION-APPLICABLE TO OPENING COIL OF ELECTRICAL WIRE OR SIMILAR |
| A.F | 82X | MAF | 254 | MTLHRO1 | . 134 | HICKEY, REPOSITION ON CONDUIT STARTS-WITH STOOP TO CONDUIT INCLUDES-ALL MOTIONS NECESSARY TO ROTATE CONDUIT, POSITION HICKEY TO BEND MARK, AND ARISE ENDS-WITH HAND ON HICKEY HANDLE |

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|---------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 82X | MAF | 839 | MTLLCO1 | 83 | LUG(TERMINAL), CRIMP TO WIRE STARTS-WITH CRIMPING TOOL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO GET TERMINAL LUG WITH CRIMPING TOOL AND CRIMP LUG TO WIRE ENDS-WITH ASIDE TOOL CONDITION-TIME TO PLACE LUG ON WIRE NOT INCLUDED |
| NF | 82X | MAF | 895 | MTLLP01 | 96 | LOOP, PLACE ON TERMINAL AND CLOSE WITH PLIERS STARTS—WITH MOVE LOOP TO TERMINAL, PLIERS IN HAND INCLUDES—ALL MOTIONS NECESSARY TO POSITION LOOP ON TERMINAL AND USE PLIERS TO CLOSE LOOP ON TERMINAL ENDS—WITH PLIERS IN HAND COMDITIONS—TIME FOR INITIAL BENDING OF LOUP NOT INCLUDED.APPLICABLE TO NU.8 OR SMALLER WIRE. |
| NF | 82X | MAF | 871 | MTLSB01 | 95 | SPLICE, BEND PARALLEL TO CONDUCTOR WITH PLIERS STARTS-WITH PLIERS IN HAND INCLUDES-ALL MOTIONS NECESSARY TO BEND TWISTED WIRE SPLICE PARALLEL TO CONDUCTOR ENDS-WITH PLIERS IN HAND CONDITION-APPLICABLE TO NO.8 OR SMALLEK WIRE |
| NF | 82X | MAF | 834 | MTLSF01 | 413 | SPLICE, FORM WITH PLIERS, PIGTAIL SPLICE STARTS—WITH PLIERS IN HAND, WIRES POSITIONED FOR TWISTING INCLUDES—ALL MOTIONS NECESSARY TO PLACE PLIERS ON WIRES AND TWIST TO FORM SPLICE ENDS—WITH PLIERS IN HAND CONDITIONS—APPLICABLE TO SPLICING ELECTRICAL FIXTURE LEADS |
| NF | 82X | MAF | 2699 | MTLTCOL | 343 | THREAD.CUT IN CONDUIT STARTS-WITH THREADER STARTED ON CONDUIT INCLIDES-ALL THE MOTIONS NECESSARY TO MOVE HANDLE.SET RATCHET AND MOVE HANDLE TO CUT ONE THREAD ENDS-WITH ONE THREAD CUT CONDITIONS-MAKE 1/5 REVOLUTION PER STROKE |
| ЧF | 82X | MAF | 921 | MTLWD01 | 192 | WIRE.DISCONNECT FROM FISHTAPE AFTER PULLING STARTS-WITH KNIFE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO CUT TAPE WITH KNIFE.ASIDE KNIFE.REMOVE AND ASIDE TAPE, GET PLIERS.AND CUT WIRE ENDS-WITH ASIDE PLIERS |
| NF | 82X | MAF | 750 | STLCBXX | VARIABLE | CONDUIT.BEND WITH HICKEY STARTS-WITH GET HICKEY INCLUDES-ALL MOTIONS NECESSARY TO STOOP TO CONDUIT.PLACE HICKEY ON CONDUIT.POSITION HICKEY TO BEND POINT.ARISE.PLACE FOOT ON CONDUIT.BEND CONDUIT.REPOSITION HICKEY AS NECESSARY,COMPLETE BEND.STOOP.AND REMOVE HICKEY FROM CONDUIT ENDS-WITH ARISE AND ASIDE HICKEY CASE OF BEND 1/2 INCH RIGID CONDUIT 45 DEGREES |
| | | | | | 726 1092 745 1131 791 1226 1205 | O2 BEND 1/2 INCH RIGID CONDUIT 40 DEGREES O3 BEND 3/4 INCH RIGID CONDUIT 45 DEGREES O4 BEND 3/4 INCH RIGID CONDUIT 45 DEGREES O5 BEND 1 INCH RIGID CONDUIT 45 DEGREES O6 BEND 1 INCH RIGID CONDUIT 45 DEGREES O6 BEND 1 INCH RIGID CONDUIT 90 DEGREES O7 BEND STUB OFFSET IN RIDGID CONDUIT 1 INCH OR LESS IN DIAMETER |

| | | | | • | | |
|----------------|-------|----------|---------|--------------------|-------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DATA SCURCE | | QUAL ITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
| FFD | 82X | мдд | KALEWBX | STLPCXX | VARIABLE | PLUG(COAXIAL), CUT FROM CABLE STARTS-WITH REACH TO CUTTERS INCLUDES-ALL THE MOTIONS NECESSARY TO GET CUTTERS, GET CABLE, POSITION CUTTERS (PLIERS) TO CABLE AND CUT PLUG FROM CABLE, ASIDE PLUG AND CUTTERS |
| | | | | | 195 133 | ENDS-WITH ASIDE PLUG/CUTTERS CASE D1 CUT FIRST OR SINGLE PLUG FROM CABLE 02 CUT EACH ADDITIONAL PLUG FROM CABLE |
| NF | . 82X | MAF | 754 | STLTBXX | VARTABLE | TUBING(ELECTRICAL METALLIC), BEND WITH MANUAL BENDER |
| | | | | | | STARTS-WITH GET BENDER INCLUDES-ALL MOTIONS NECESSARY TO STOUP TO BENDER, PLACE BENDER ON ELECTRICAL METALLIC TUBING (EMT), POSITION BENDER TO BEND POINT, ARISE, PLACE FOOT ON TUBING TO HOLD, BEND TUBING, STOOP, REMOVE BENDER, AND ARISE ENDS-WITH ASIDE BENDER |
| | | | | | 519 541 791 | CASE OI BEND UP TO 1 INCH EMT 45 DEGREES O2 BEND UP TO 1 INCH EMT 90 DEGREES O3 BEND STUB OFFSET IN UP TO 1 INCH EMT (MAKE TWO 45-DEGREE BENDS). |
| NF | 82X | MAF | 860 | MTPAPO1 | 108 | ARM(RAM), PULL TO FREE ANVIL, HYDRAULIC CONDUIT BENDER |
| | | | | . • | | STARTS-WITH BEND AND REACH TO RAM ARM INCLUDES-ALL MOTICNS NECESSARY TO HOLD RAM JACK HOUSING WITH ONE HAND AND PULL RAM ARM WITH OTHER HAND ENDS-WITH RELEASE RAM ARM AND HOUSING AND ARISE |
| NF | 82X | MAF | 758 | MTPCBXX | VARTABLE | CONDUIT.BEND WITH HYDRAULIC BENDER STARTS-WITH STOOP TO CONDUIT BENDER |
| | | | | | | INCLUDES—ALL MOTIONS NECESSARY TO GET HANDLE, PUMP HANDLE TO BEND CONDUIT, SHIFT CONDUIT IN BENDER AS NECESSARY, AND RELEASE HANDLE WHEN BEND IS COMPLETED |
| | | | | | | ENDS-WITH ARISE FROM STOOP CONDITIONS-OOES NOT INCLUDE INSTALLATION IN OR REMOVAL FROM BENDER |
| | | · | | | 1975 2920 2810 4256 5170 8976 12435 14216 28153 | CASE OI REND 1 1/4 INCH CONDUIT 45 DEGREES O2 BEND 1 1/4 INCH CONDUIT 90 DEGREES O3 BEND 1 1/2 INCH CONDUIT 45 DEGREES O4 BEND 1 1/2 INCH CONDUIT 90 DEGREES O5 BEND 2 INCH CONDUIT 90 DEGREES O6 BEND 2 INCH CONDUIT 90 DEGREES O7 BEND 2 1/2 INCH CONDUIT 90 DEGREES O8 BEND 3 INCH CONDUIT 90 DEGREES O9 BEND 4 INCH CONDUIT 90 DEGREES |
| AF | 82X | MAA | MDE-3J | MWH SMO1 | 120 | SPLICE(CENTER), MAKE STARTS-WITH ONE WIRE IN EACH HAND INCLUDES-ALL THE MOTIONS NECESSARY TO PLACE END OF WIRE IN RIGHT HAND TO SPLICE POINT IN WIRE HELD BY LEFT HAND, TWIST END OF AIRE HELD BY RIGHT HAND AROUND OTHER WIRE TO MAKE ELECTRICALLY TIGHT, RELEASE WIRES ENDS-WITH RELEASE WIRE CONDITIONS-OOES NOT INCLUDE TAPING OR SOLDER- ING |

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FFO | 82X | чаа | KALEW39 | SWHSTO1 | 1076 | SPLICE(CCAXIAL CABLE), INSTALL TO SHIELDED WIRE STARTS—WITH REACH TO WIRE INCLUDES—ALL THE MOTIONS NECESSARY ID GET WIRE AND KNIFE, CUT AND STRIP INSULATION, GET AND POSITION BARREL TO WIRE END, PUSH SHIELDING BACK, POSITION INNER BARREL TO WIRE END, GET AND PLACE TAPED SHIELD OVER INNER BARREL WITH HAND, GET OUTER BARREL AND PLACE OVER INNER BARREL WITH HAND, GET PLIERS, POSITION ON BARRELS, ALIGN BARRELS, GET CRIMPERS, CAIMP BARRELS, ASICE CRIMPERS AND WIRE ASSEMBLY ENDS—ASIDE CRIMPERS AND WIRE ASSEMBLY |
| FFD | 82X | M&A | KALEA05 | SWH SMO1 | 2367 | SPLICE(TWO WIRES).MAKE WITH STAKE—ON PLIERS STARTS—WITH REACH TO WIRE INCLUDES—ALL THE MOTIONS NECESSARY TO GET WIRE AND STRIPPERS,STIP ONE END OF TWO WIRES, ASIDE STRIPPERS,GET STAKE—ON PLIERS,GET SPLICE,PLACE SPLICE ON WIRE ENDIONE WIRE),PLACE PLIERS ON SPLICE AND CRIMP,PALM PLIEPS,GET,MEASURE AND CUT SPAGHETTI AND INSTALL OVER SPLICE,GET SECOND WIRE,STRAIGHTEN AND PLACE IN SPLICE, CRIMP SPLICE,PULL WIRES TO CHECK SPLICE,ASIDE CRIMPERS,SLIDE SPAGHETTI OVER SPLICE,UNWIND ONE FOOT OF LACING CORD,TIE KNOT ON EACH SIDE OF SPLICE AND OVER SPAGHETTI,CUT CORD,ASIDE CUTTER FINDS—WITH ASIDE CUTTER CONDITIONS—NON—SHIELDED WIRE |
| FFO | 82X | MAA | KALEDO5 | SWH SR 01 | 1,51 | SPLICE, REMOVE STARTS-WITH REACH TO CUTTER INCLUDES-ALL THE MOTIONS NECESSARY TO GET CUTTER, GRASP WIRE WITH OTHER HAND, MAKE FIRST CJT, MOVE CUTTER TO SECOND POINT AND CUT WIRE, ASIDE CUTTER, RELEASE WIRE ENDS-WITH ASIDE CUTTER |
| NF | 821 | MAF | 853 | MB MC PO 1 . | 1513 | POLE,CLIMB TO LOWER CROSSARM, APPROXIMATELY 30 FEET STARTS-WITH REACH TO POLE INCLUDES-ALL MOTIONS NECESSARY TO CLIMB POLE TO LOWER CROSSARM USING CLIMBING HOOKS ENDS-WITH CLIMB COMPLETED CONDITIONS-NO TIME INCLUDED FOR FASTENING GR UNFASTENING SAFETY BELT |
| NF | 821 | MAF | 852 | 48 MC P 0 2 | 686 | POLE,CLIPB FROM LOWER TO UPPER CROSSARM STARTS-WITH GET HOLD ON POLE INCLUDES-ALL MOTIGNS NECESSARY TO UNHOOK SAFETY BELT,CLEAR BELT FROM POLE,CLIMB THREE STEPS USING CLIMBING HOOKS,STEP ON LOWER CROSSARM,HOOK SAFETY BELT AROUND POLE,CLIMB THREE ADDITIONAL STEPS,AND POSITION SAFETY BELT ENDS-WITH CLIMB COMPLETED |
| NF | 821 | MAF | 850 | M8 MPC 01 | 402 | POSITION, CHANGE HORIZONTALLY ON POLE STARTS-WITH REACH FOR NEW HOLD ON POLE INCLUDES-ALL MOTIONS NECESSARY TO DISENGAGE CLIPBING HOOK, MOVE AROUND POLE, SINK HOOK IN POLE, GET NEW HOLD, AND REPOSITION BELT ENDS-WITH POSITION CHANGED CONDITIONS-APPLICABLE TO MOVING UP TO 180 DEGREES AROUND POLE |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | THU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------------|----------------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 821 | MAF | 2407 | SB MPC 01 | 5843 | POLE, CLIFB TO AND DESCEND FROM LOWER CROSSARM STARTS—WITH BEND TO POLE CLIMBERS INCLUDES—ALL MOTIONS NECESSARY TO PUT ON ROLE CLIMBERS, ARISE PUT ON SAFETY BELT, CLIMB APPROXIMATELY 30 FEET UP POLE, HOOK SAFETY BELT AROUND POLE, REMOVE HANDLINE FROM SAFETY BELT AND HOOK ON CROSSARM; REMOVE HANDLINE, HOOK ON BELT, REMOVE BELT FROM POLE, DESCEND POLE, REMOVE SAFETY BELT, AND REMOVE POLE CLIMBERS ENDS—WITH ASIDE CLIMBERS |
| NF | 821 | MAF ' | 716 | MCL SC 01 | 335 | SHEATHINGILEAD CABLE), CLEAN BY SCRAPING STARTS-WITH SCRAPER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE SCRAPER TO CABLE AND CLEAN THREE SQUARE INCHES ENDS-WITH SHEATHING CLEANED CONDITION-CLEANING IS PREPARATORY TO FLUX APPLICATION FOR SPLICING |
| NF . | 821 | MAF | 2411/12 | MJPSP01 | 546 | SLEEVES (RUBBER LINEMAN'S), PUT ON AND TAKE OFF STARTS-WITH REACH TO STORAGE POUCH INCLUDES-ALL MOTIONS NECESSARY TO UNFASTEN SNAPS ON POUCH, REMOVE SLEEVES FROM POUCH, PLACE SLEEVE STRAP OVER BACK OF NECK, AND PLACE ARMS IN SLEEVES; AND REACH TO FIRST SLEEVE, REMOVE, REACH TO SECOND SLEEVE, REMOVE, ROLL SLEEVES, PLACE SLEEVES IN POUCH, AND CLOSE SNAPS ON POUCH ENDS-WITH RELEASE OF POUCH |
| NF | 821 | MAF | 769 | SNFCI 01 | 1411 | CONNECTOR(SOLDERLESS).INSTALL, SPLIT BOLT TYPE STARTS-WITH REACH TO CONNECTOR INCLUDES-ALL MOTIONS NECESSARY TO REMOVE NUT FROM CONNECTOR, PLACE SPLIT BOLT OVER FIRST WIRE, START NUT ON BOLT, GET SECOND WIRE AND SLIDE INTO CONNECTOR, GET WRENCH FROM BELT KIT, TURN NUT WITH WRENCH, GET SECOND WRENCH FROM BELT KIT, PLACE ON BOLT TO HOLD, TIGHTEN NUT, AND RETURN FACH WRENCH TO BELT KIT ENDS-WITH RELEASE OF SECOND WRENCH |
| NF | 821 | MAF | 701 | 10 TAHOM | 2477 | ANCHOR (AND ROD ASSEMBLY), INSTALL IN HOLE AND EXPAND ANCHOR STARTS-WITH REACH TO ASSEMBLY ON TRUCK INCLUDES-ALL MOTIONS NECESSARY TO REMOVE ASSEMBLY FROM TRUCK, CARRY ASSEMBLY SIX PACES TO HOLE, PLACE ASSEMBLY IN HOLE AND POSITION, RETURN TO TRUCK, GET TAMPING BAR, RETURN TO HOLE, USE TAMPING BAR TO EXPAND ANCHOR, AND RETURN TAMPING BAR TO PACK ON TRUCK ENDS-WITH RELEASE OF BAR CONDITIONS-ASSEMBLY WEIGHS 44 POUNDS.TIME TO BACKFILL AND TAMP HOLE NOT INCLUDED. HOLE IS APPROXIMATELY SEVEN FEET DEEP. |
| NF | 821 | MAF | 933 | MOHBRO1 | 283 | BELTING.REMOVE FROM LEAD SHEATHED CABLE STARTS-WITH REACH TO CUT END OF RELTING INCLUDES-ALL MOTIONS NECESSARY TO UNWRAP EIGHT REVCLUTIONS OF BELTING INSULATION FROM CABLE EMDS-WITH BELTING IN HAND CONDITION-TIME TO CUT BELTING NOT INCLUDED |
| NF | 821 | MAF | 775 | MOHC 001 | 202 | CUTOUT(FUSED). OPEN OR CLOSE ON POLE WITH DISCONNECT STICK STARTS = WITH REACH TO STICK ON HANDLINE INCLUDES = ALL MOTIONS NECESSARY TO GET LOOP ON HANDLINE, LIFT OVER END OF STICK, MOVE STICK TO EYE IN SWITCH, HOOK STICK IN EYE, PULL SAITCH TO OPEN OR PUSH TO CLOSE, MOVE HOOK OUT OF EYE, AND MOVE STICK BACK TO HANDLINE ENDS = WITH RELEASE OF STICK CONDITIONS = TIME FOR CLIMBING AND DESCENDING POLE NOT INCLUDED |

| DATA Source | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION . |
|----------------|-----|----------|----------------|--------------------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 821 | MAF | 2764 | MOHERO1 | 359 | EQUIPMENT, RAISE OR LOWER ON POLE WITH HANDLINE STARTS—WITH REACH TO HANDLINE INCLUDES—ALL MOTIONS NECESSARY TO RAISE OR LOWER EQUIPMENT ATTACHED TO HANDLINE WITH HAND OVER HAND MOTIONS ENDS—WITH EQUIPMENT RAISED OR LOWERED CONDITIONS—NO TIME INCLUDED FOR ATTACHING OR REMOVING EQUIPMENT FROM HANDLINE OR FOR CLIMBING OR DESCENDING POLE.APPLICABLE TO TOOLS, TOOL BAG, MATERIAL, ETC. WITH ENW TO 15 POUNDS RAISED TO OR LOWERED FROM HEIGHT OF |
| NF | 821 | MAF | 934 | MOHFROI | 95 | FILLER, REMOVE AND CUT, LEAD SHEATHED CABLE STARTS-WITH REACH TO FILLER, KNIFE IN MAND INCLUDES-ALL MOTIONS NECESSARY TO PULL FILLER OUT APPROXIMATELY ONE FOOT AND CUT WITH KNIFE ENDS-WITH FILLER AND KNIFE IN HAND |
| NF | 821 | MAF | 820 | МОННІ 01 | 257 | HOOD(RUBBER INSULATOR), INSTALL ON ENERGIZED LINE STARTS-WITH REACH TO INSULATOR HOOD IN BAG INCLUDES-ALL MOTIONS NECESSARY TO GET INSULATOR FROM BAG, CHANGE POSITION ON POLE, SINK CLIMBING HOOK INTO POLE, MOVE HOOD TO INSULATOR, AND PLACE HOOD OVER INSULATOR ENOS-WITH RELEASE OF INSULATOR CONDITION-TIME FOR CLIMBING POLE NOT INCLUDED |
| NF | 821 | MAF | 821 | MOHHP01 | 324 | HOSE (RUBBERJ, PLACE ON ENERGIZED LINE STARTS-WITH REACH TO HOSE IN BAG INCLUDES-ALL MOTIONS NECESSARY TO GET HOSE, CHANGE POSITION ON POLE, SINK CLIMBING HOOK INTO POLE, MOVE HOSE TO WIRE, AND PUSH HOSE DOWN WIRE TO PROVIDE PROTECTION DURING ENSUING WORK ENDS-WITH RELEASE OF HOSE CONDITION-TIME FOR CLIMBING POLE NOT INCLUDED. HOSE APPROXIMATELY FIVE FEET LONG. |
| NF | 821 | MAF | 702 | MTFAA01 | 759 | ANCHOR, ASSEMBLE TO ROD STARTS-WITH REACH TO ANCHOR IN RACK ON TRUCK INCLUDES—ALL MOTIONS NECESSARY TO REMOVE ANCHOR FROM TRUCK, GET ROD, SCREW ANCHOR ONTO ROD, GET WIRE CUTTERS FROM BELT KIT, CUT FOUR TIE WIRES, REPLACE CUTTERS IN BELT ENDS—WITH RELEASE OF CUTTERS CONDITIONS—ANCHOR WEIGHS 28 POUNDS-1"X10" ROD WEIGHS 16 POUNDS |
| NF | 821 | MAF | 856 | 4TLP001 | 157 | PIKE, DRIVE INTO POLE, APPROXIMATELY 20 FEET ABOVE GROUND STARTS-WITH PIKE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO LIFT PIKE, PUSH INTO POLE, AND WEDGE PIKE AGAINST GROUND ENDS-WITH RELEASE OF PIKE CONDITION-PIKE WEIGHS APPROXIMATELY 20 POUNDS |
| NF . | 921 | MAF | 854 | MTLPRO1 | 415 | POLE.ROTATE WITH CANT HOOK STARTS-WITH REACH TO CANT HOOK INCLUDES-ALL MOTIONS NECESSARY TO GET HOOK. OBSERVE POLE TO ESTIMATE AMOUNT OF TURN REQUIRED,ROTATE POLE WITH HOOK.CHECK POSITION. ROTATE POLE,CHECK POSITION.STOOP,REHOVE CANT HOOK FROM POLE.AND ARISE ENDS-WITH ASIDE CANT HOOK CONDITIONS-RESISTANCE TO TURN IS APPROXIMATELY 40 POUNDS ENW. |

| DATA Source | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 821 | MAF | 817 | STLSD01 | 609 | STEP(PDLE), DRIVE INTO POLE WITH HAMMER STARTS-WITH REACH TO POLE STEP INCLUDES-ALL MOTIONS NECESSARY TO GET HAMMER, DRIVE STEP INTO POLE, ASIDE HAMMER, GET WRENCH, AND TURN STEP TO ALIGN ENDS-WITH ASIDE WRENCH |
| FFD | 823 | TAA | KALEA09 | SWHJIOI | 73 06 | JACK/PLUG(INTERPHONE), INSTALL STARTS-WITH REACH TO GET TOOL INCLUDES-ALL THE MOTIONS NECESSARY TO GET SCREWDRIVER AND POSITION TO JACK SLOT. BREAK INNER PART OF JACK LOOSE, DISENGAGE INNER PART FROM SHELL, OPEN VISE, PLACE RECEPTACLE IN VISE AND TIGHTEN, GET AND PLUG IN SOLDERING IRON, ASIDE IRON TO HOLDER, GET EXTENSION CORD AND KNIFF, CUT AND REMOVE OUTER COVERING AT END OF CDRO. ASIDE KNIFF, GET STRIPPERS AND STRIP FOUR MIRES, ASIDE STRIPPERS, GET SOLDERING IRON AND TIN EACH WIRE END, ASIDE IRON AND CORD. GET PLIERS AND GRASP WIRE, MOVE WIRE TO AND PLACE IRCN, SOLDER EACH WIRE IN RECEPTACLE, ASIDE IRON AND REACH (SIMOITO VISE HANDLE AND CABLE. JPEN VISE AND REMOVE CABLE, GET STRING, LOOP STRING ON CABLE AND PULL TIGHT, PLACE KNOT ON HOOK, MOVE SHELL TO RECEPTACLE AND FIT TOGETHER, GET SCREWDRIVER AND TIGHTEN SHELL TO RECEPTA— CLE, ASIDE SCREWDRIVER, JACK/PLUG AND CABLE |
| | | , | | | | CONDITIONS-FOUR-WIRE EXTENSION CORD |
| FFD | 823 | MAA | KALEDO9 | SWHUR01 | 2376 | JACK/PLUG(INTERPHONE).REMOVE STARTS—HITH REACH TO GET JACK AND PLIERS(SIMO) INCLUDES—ALL THE MOTIONS NECESSARY TO GET AND MOVE PLIERS AND JACK TO WORK AREA.GRASP JACK WITH PLIERS.GET SCREWORIVER.LOOSEN SHELL FRCM INNER PART.ASIDE SCREWORIVER.REMOVE INNER PART(RECEPTACLE)FROM SHELL.ASIDE SHELL.PLIERS AND RECEPTACLE.OPEN VISE.PLACE RECEPTACLE IN VISE AND TIGHTEN.GET SOLDERING IRVN.PLACE IN HOLDER.PLUG IN.GET PLIERS.GRASP WIRE WITH PLIERS.GET SOLDERING IRVN.UNSOLDER FOUR WIRES. ASIDE PLIERS AFTER FOURTH WIRES.DISENGAGE WIRES. ASIDE PLIERS AFTER FOURTH WIRE IS DISENGAGED. UNPLUG SOLDERING IRVN.LOOSEN VISE.REMOVE AND ASIDE RECEPTACLE ENDS—WITH ASIDE RECEPTACLE CONDITIONS—FOUR—WIRE EXTENSION CORD |
| AF | 824 | MÄÄ | MDE-3Y | MOALIOI | 103 | LAMP(FLUCRESCENT), INSTALL IN LAMP HOLDER STARTS-WITH LAMP IN HANDS INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE LAMP AND POSITION FIRST END TO LAMP HOLDER, POSITION SECOND END TO HOLDER, MOVE EACH END TO SEAT, TURN LAMP TO LOCK, RELEASE LAMP ENDS-WITH RELEASE LAMP IN HOLDER |
| AF | 824 | MAA | MDE=4M2 | MDAP101 | 72 | PANEL(ELECTRICAL METER), INSTALL STARTS-WITH PANEL IN HAND INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE METER PANEL TO CHASSIS, POSITION PANEL AND ALIGN SCREW HOLES, CHECK ALIGNMENT ENDS-WITH CHECK ALIGNMENT CONDITIONS-4X8 INCH PANEL |
| AF | 824 | MAA | MDE=4M2 | MDAPRO1 | 42 | PANEL(ELECTRICAL METER).REMOVE STARTS-WITH LEFT HAND HOLDING METER PANEL AT CHASSIS INCLUDES-ALL THE MOTIONS NECESSARY TO REACH TO PANEL WITH RIGHT HAND.GRASP AND REMOVE PANEL, RELEASE RIGHT HAND.TURN PANEL WITH LEFT HAND TO EXPOSE WIRING ENDS-WITH WIRING EXPOSED.PANEL IN HAND CONDITIONS-4X8 INCH PANEL |

| DATA S OURCE | | QUAL ITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION . |
|-----------------|-----|--------------|---------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ΔF | 824 | MAA | MDE-3R1 | SDACIOI | 524 | LEADS(LAPPSOCKET), INSERT THROUGH GROMMET STARTS-WITH REACH TO GET LAMP ASSEMBLY INCLUDES-ALL THE MOTIONS NECESSARY TO PICK UP LAMP ASSEMBLY AND TURN WITH RIGHT HAND, REACH TO FIRST WIRE LEAD WITH LEFT HAND, MOVE WIRE TO GROMMET AND INSERT LEAD THROUGH GROMMET, RELEASE WIRE, TURN LAMP ASSEMBLY 90 DEGREES AND REACH TO WIRE END THROUGH GROMMET, GRASP END AND PULL WIRE THROUGH GROMMET WITH CARE, RELEASE WIRE, TURN LAMP 90 DEGREES, REACH TO END OF SECOND WIRE, MOVE WIRE TO GROMMET AND INSERT IN GROMMET, RELEASE WIRE, TURN LAMP 90 DEGREES, GRASP END OF SECOND WIRE AND PULL THROUGH GROMMET WITH CARE, INSPECT GROMMET SEATING, AS IDE LAMP ASSEMBLY ENDS-WITH LAMP AS IDE CONDITIONS-INCANDESCENT LAMP-RUBBER GROMMET |
| ŇF | 824 | MAF | 712 | MOHC [0] | 132 | CABLE, INSERT END IN BOX CONNECTOR STARTS-WITH REACH TO END OF CABLE INCLUDES-ALL MOTIONS NECESSARY TO POSITION END OF CABLE TO CONNECTOR, GET END OF CABLE WITH OTHER HAND, AND PULL CABLE INTO BOX ENDS-WITH RELEASE OF CABLE CONDITION-APPLICABLE TO BX, ROMEX, OR SIMILAR |
| A F | 824 | MAA . | MDE=40 | | 50 | WIRE.INSERT THROUGH CLIP IN RACEMAY STARTS-WITH WIRE IN HAND INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE WIRE THROUGH CLIP WITH RIGHT HAND.GRASP END WITH LEFT HAND AND PULL WIRE THROUGH RACEMAY. GUIDE WIRE WITH RIGHT HAND ENDS-WITH WIRE THROUGH RACEWAY(10 INCHES)AND HELD BY BOTH HANDS |
| FFD | 825 | MAA | KALEA17 | SCPCIO1 | - 1781 | CLAMP, INSTALL ON WIRE BUNDLE AND SECURE TO BULKHEAD STARTS-WITH REACH TO GET CLAMP INCLUDES-ALL THE MOTIONS NECESSARY TO GET CLAMP, MOVE TO PLIERS AND GRASP, TWIST PLIERS TO SHAPE CLAMP, AS IDE PLIERS, OPEN CLAMP, GET WIRE BUNDLE, PLACE CLAMP ON BUNDLE, CLUSE CLAMP, GET PLIERS AND FORM CLAMP ON BUNDLE, AS IDE PLIERS AND GET SCREWORIVER AND PLACE IN CLAMP HOLE, PLACE CLAMP AND WIRE BUNDLE TO HOLE, PUT SCREW IN HOLE, PUT ON NUT, GET WRENCH AND TIGHTEN NUT, AS IDE TOOLS, CHECK CLAMP FOR SECURITY ENDS-WITH CLAMP CHECKED, TOOLS AS IDE CONDITIONS-SECURE BUNDLE TO BULKHEAD AND SIMILAR |
| FFO | 825 | MAA | KALED17 | SCPCR01 | 1173 | CLAMP(EC?), REMOVE FROM WIRE BUNDLE STARTS-WITH REACH TO SCREWDRIVER INCLUDES-ALL THE MOTIONS NECESSARY TO GET SCREWDRIVER, PALM, GET WRENCH, PLACE SCREW DRIVER IN SCREW SLOT AND WRENCH ON NUT, LOOSEN SCREW, REMOVE NUT, ASIDE SCREWDRIVER AND WRENCH, GET PLIERS, SQUEEZE SCREW FROM CLAMP, PALM PLIERS, REMCVE SCREW FROM CLAMP, PALM SCREW, GRASP AND SPREAD CLAMP, REMOVE CLAMP FROM WIRE BUNDLE, ASIDE CLAMP, SCREW AND PLIERS (SIMO) ENDS-WITH CLAMP, SCREW AND PLIERS ASIDE |

| DATA | 000118= | QUALITY | SOURCE | DWMSTDP | TMU | OPERATION/ELEMENT DESCRIPTION |
|--------|------------|---------|---------|-----------|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SOURCE | | | CODE | ELEMENT | VALUE | |
| FFO | 925 | MΑA | KALED18 | SCPCR02 | 1026 | CLAMP, REMOVE FROM BULKHEAD STARTS = WITH REACH TO TOOLS INCLUDES = ALL THE MOTIONS NECESSARY TO GET SCREWORIVER AND WRENCH, LOOSEN SCREW AND WUT HOLDING CLAMP TO BULKHEAD, ASIDE TOOLS, REMOVE AND ASIDE NUT, PULL CLAMP AND CABLE AWAY FROM BULKHEAD, REMOVE SCREW FROM CLAMP HOLE, PUT NUT BACK ON SCREW, RUN DOWN WITH FINGERS ENDS = WITH NUT ON SCREW CONDITIONS = APPLIES ONLY TO CLAMPS REMOVED FOR ACCESS AND LEFT ON WIRE BUNDLE |
| FFD | 925 | МАА | KALEA18 | SC PWC 01 | 1274 | WIRE BUNDLE, CLAMP TO BULKHEAD STARTS-WITH REACH TO CLAMP AND NUT(SIMO) INCLUDES-ALL THE MOTIONS NECESSARY TO REMOVE SCREW AND NUT FROM CLAMP, POSITION CLAMP ALREADY ON BUNDLE TO MOUNTING HOLE, INSERT SCREW AND PUT NUT ON SCREW, GET WEENCH AND SCREWDRIVER, PUN DOWN AND TIGHTEN NUT, PALM TOOLS, CHECK CLAMP FOR SECURITY, ASIDE TOOLS CONDITIONS-APPLIES ONLY TO CLAMPS REMOVED FOR ACCESS AND LEFT ON WIRE BUNDLE |
| FFO. | \$25 | M&& | KALEW33 | SWHWRO1 | 1596 | WIRE/WIRE BUNDLE, ROUTE IN AIRCRAFT STARTS-WITH REACH TO WIRE/WIRE BUNDLE INCLUDES-ALL THE MOTIONS NECESSARY TO GET WIRE OR WIRE BUNDLE, MOVE TO WORK AREA AND PUSH END INTO POSITION, BEND WIRE TO POSITION, INSERT WIRE/WIRE BUNDLE THROUGH OBSTRUCTION, GRASP END OF MIRE/WIRE BUNDLE, FEEL FOR END, GRASP AND PULL THROUGH LOOP, BEND WIRE, PULL WIRE/WIRE BUNDLE THROUGH OBSTRUCTION, GET AND UNWIRE ONE FOOT OF LACING CORD, TIE WIRE/WIRE BUNDLE IN TWO SPOTS, CUT CORD, ASIDE CUTTER ENDS-WITH KNOT TIED(TWO), CUTTER ASIDE CONDITIONS-PER FOOT ROUTED-USE WHEN ROUTING A BUNDLE OR WHEN ROUTING A WIRE ALONG EXISTING BUNDLE |
| FFO | 8 2 5 | MAA | KALEW43 | SWHWTOL | 1296 | WIRE BUNDLE, TIE TO TOMBSTONE STARTS-WITH REACH TO LACING CORD INCLUDES-ALL THE MOTIONS NECESSARY TO GET LACING CORD, UNWIND DNE FOOT, SECURE WIKE BUNDLE TO TOMBSTONE AND TIE IN TWO PLACES, CUT LACING CORD AND ASIDE CUTTER ENDS-WITH ASIDE CUTTER, TIE FINAL KNOT |
| NF | 8 29 | MAF | 809 | MOHFIXX | 70 115 180 | FUSE(ELECTRICAL), INSTALL STARTS-WITH FUSE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO INSTALL FUSE IN HOLDER ENDS-WITH RELEASE OF FUSE CASE 01 CARTRIDGE TYPE FUSE, FERRULE CONTACT, 3-60 AMPERE 02 CARTRIDGE TYPE FUSE, KNIFE BLADE CONTACT, 61-600 AMPERE 03 PLUG TYPE FUSE, 15-30 AMPERE |
| NF | 829 | MAF | 3266 | HOH SRO1 | 144 | STARTER (FLUORESCENT), REPLACE IN FIXTURE STARTS-WITH REACH TO STARTER INCLUDES-ALL MOTICNS NECESSARY TO REMOVE STARTER, TRANSFER STARTER TO OTHER HAND, GET NEW STARTER HELD IN OTHER HAND, AND INSTALL STARTER ENDS-WITH RELEASE OF STARTER CONDITIONS-NO TIME INCLUDED FOR TESTING STARTER.STARTER IN UNRESTRICTED LOCATION. |

| DATA Source | | QUAL ITY | SOURCE CODE | OWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|------------|----------------|--------------------|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 829 | M&F | 705/6/7 | STLBRXX | VARIABLE 1340 1587 1826 | BULB, REPLACE WITH BULB CHANGER STARTS-WITH CHANGER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO LIFT CHANGER TO BULB, POSITICN ON BULB, REMOVE BULB FROM SOCKET, LOWER CHANGER, REMOVE BULB FROM CHANGER, STOCP, GET NEW BULB FROM CARTON, PLACE OLD BULB IN CARTON, ARISE, PLACE BULB IN CHANGER, LIFT BULB AND CHANGER TO SOCKET, SCREW BULB IN SOCKET, AND LOWER CHANGER FROM BULB ENDS-WITH BULB-CHANGER IN HAND CONDITIONS-APPLICABLE TO CHANGING OVERHEAD INCANDESCENT BULB TO 750 WATTS CASE OI CHANGE BULB WITH 18-FOOT CHANGER OZ CHANGE BULB WITH 18-FOOT CHANGER OZ CHANGE BULB WITH 27-FOOT CHANGER |
| NF | 844 | MAF | 1303 | MACMOO1 | 5 93 | MIXTURE (CRY AGGREGATE), DUMP INTO MIXER FROM HOPPER STARTS-WITH REACH TO DUMP HANDLE INCLUDES-ALL MOTIONS NECESSARY TO MOVE DUMP HANDLE TO OPEN HOPPER, GET VIBRATOR HANDLE, VIBRATE HOPPER BY HAND TO EMPTY CONTENTS, AND CLOSE HOPPER ENDS-WITH RELEASE OF HANDLE CONDITIONS-APPLICABLE TO DUMPING 3 1/2 CUBIC FEET OF MIXED DRY AGGREGATE |
| NF | 844 | MAF | 1362 | SOHCA01 | 462 | CHUTE(EXTENSION).ATTACH TO TRANSIT MIXER STARTS-WITH REACH TO EXTENSION INCLUDES-ALL MOTIONS NECESSARY TO REMOVE EXTENSION FROM STORAGE ON TRUCK, TURN, WALK 10 PACES TO REAR OF TRUCK, AND ATTACH EXTENSION CHUTE TO MIXER ENDS-WITH RELEASE OF EXTENSION CONDITIONS-EXTENSION WEIGHS APPROXIMATELY 40 POUNDS |
| NF | 844 | MAF | 1368/70 | HTLCC01 | 3699 | CONCRETE, CHIP WITH CHISEL AND HAMMER, SEVEN CORIC INCHES STARTS-WITH CHISEL AND HAMMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO STRIKE CHISEL WITH HAMMER TO REMOVE SEVEN CUBIC INCHES OF CONCRETE AND USE CHISEL TO PUSH AWAY DEBRIS ENDS-WITH TOOLS IN HAND |
| NF | 844 | MAF | 1415 | MTPHEO1 | 273 | HANDLES (GUIDE), EXTEND OR RETRACT, CONCRETE SAM STARTS-WITH REACH TO HANDLE LOCK KNOB INCLUDES-ALL MOTIONS NECESSARY TO LOOSEN LOCK KNOB, PULL HANDLE OUT, TIGHTEN LOCK KNOB, SIDESTEP TO OTHER HANDLE, LOSEN LOCK KNOB, PULL HANDLE OUT, AND TIGHTEN LOCK KNOB ENDS-WITH RELEASE OF KNOB |
| NF | 844 | MAF | 1412 | MTPHP01 | 272' | HAMMER(PREUMATIC), POSITION FOR DRILLING AND REMOVE AFTER DRILLING STARTS-WITH BEND TO HAMMER INCLUDES-ALL MOTICNS NECESSARY TO PICK UP HAMMER AND MOVE TO SPOT FOR DRILLING; AND TO REMOVE HAMMER AND ASIDE AT FLOOR LEVEL ENDS-WITH ARISE FROM BEND CONDITIONS-HAMMER WEIGHS APPROXIMATELY 90 POUNDS |
| NF | 844 | MAF | 1497 | MTPSAOL | 177 | SPEED.ADJUST ON SELF-PROPELLING UNIT OF CONCRETE SAW STARTS-WITH RELEASE OF HANDLES OF SAW INCLUDES-ALL MOTIONS NECESSARY TO TAKE ONE STEP DACKWARD, STUDP, TURN KNOB THREE REVOLUTIONS, ARISE, AND WALK ONE PACE FORWARD ENDS-WITH GRASP HANDLES |

| | | | | | | • |
|-----------------|-----|---------|----------------|--------------------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DAT A SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
| NF | 844 | MAF | 1498/99 | MTPUE01 | 342 | UNIT(SELF-PROPELLING), ENGAGE AND DISENGAGE, CONCRETE SAW STARTS-WITH REACH TO HANDLES INCLUDES-ALL MOTIONS NECESSARY TO HOLD HANDLES AND ACTUATE LEVER WITH FOOT MOTION TO ENGAGE UNIT; AND TO HOLD HANDLES AND ACTUATE LEVER WITH FOOT MOTION TO DISENGAGE UNIT ENDS-WITH HAND ON HANDLES |
| NAA | 845 | MAA | JPAADXX | MPAPSXX | VARIABLE | PAINT, SPRAY ON AIRCRAFT SURFACE, PER TEN SQUARE FEET STARTS-WITH SPRAY GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO SPRAY TEN SQUARE FEET (FOUR PASSES PER SQUARE FOOT), MOVE HOSE, AND MOVE TO ADJACENT AREA FOR PAINTING ENDS-WITH OPERATOR READY TO PAINT ADJACENT AREA |
| | | | | | 998 | CASE OI SPRAY TEN SQUARE FEET WITH EPUXY PAINT OR ACRYLIC LACQUER, SPRAY WITH FOUR INCH FAN |
| | | | | | 593 | - 02 SPRAY TEN SQUARE FEET WITH EPOXY OR ACRYLIC PRIMER, SPRAY WITH SIX-INCH FAN |
| NAA | 845 | HUA | JPAASRA | SPAAIOL | 26690 | ARROW(RESCUE), INSTALL ON AIRCRAFT STARTS-WITH REACH TO GET MEASURING DEVICE INCLUDES—ALL THE MOTIONS NECESSARY TO MARK POSITION TO PLACE TEMPLATE, TEMPORARY TAPE TEMPLATE TO AIRCRAFT, MASK OUTLINE TWO TIMES, PAINT YELLOW AND RESCUE BLACK, TWO COATS EACH, REMOVE MASK, USE WORKSTAND ONE TIME TO PAINT AND ONE TIME TO MASK ENDS—WITH DESCENT FROM WORKSTAND, ASIDE PAINT AND TEMPLATES CONDITIONS—ARROW TO 24 INCHES.FOUR STEP ASCENT/DESCENT OF WORKSTAND. |
| NAA | 845 | MUA | AMZAAQL | SPAII01 | 80610 | INSIGNIA (NATIONAL-STAR), INSTALL ON AIRCRAFT STARTS-WITH REACH TO GET MEASURING DEVICE INCLUDES—ALL THE MOTIOMS NECESSARY TO MARK LOCATION OF STAR, GET STAR AND POSITION ON AIRCRAFT, APPLY TEMPORARY TAPE TO HOLD TEMPLATE ONCE FOR EACH COLOR, MASK DINCE FOR EACH COLOR AND REMOVE, PAINT THREE COLORS, TWO COATS EACH, WAIT ONE MINUTE BETWEEN COATS, ATTACH AND REMOVE BARRIER PAPER, USE WORK STAND DINCE PER COLOR, ONCE PER MASK AND ONCE PER UMMASK ENDS—WITH DESCENT FROM WORKSTAND, ASIDE PAINT AND TEMPLATE CONDITIONS—PAINT EIGHT SQUARE FEET WITH SPRAY GUN.30—40 INCH INSIGNIA.FOUR STEP ASCENT/DESCENT OF WORKSTAND. |
| ŊF | 853 | MAF | 2278 | SOH WR 01 | 200 | WRAPPING (PAPER), REMOVE FROM 100-POUNC BUNDLE OF ASPHALT STARTS-WITH GET BUNDLE OF ASPHALT INCLUDES-ALL MOTICNS NECESSARY TO PLACE BUNDLE OF ASPHALT ON SIDE GET AXE, CUT PAPER WAAPPING ON ASPHALT, ASIDE AXE, AND TEAR PAPER TO EXPOSE ASPHALT ENDS-WITH RELEASE OF PAPER |
| NF | 853 | MAF | 997 | HTLMS01 | 776 | MIX(HOT BITUMINOUS), SPREAD WITH RAKE, PER SQUARE YARD STARTS-WITH RAKE IN HAND INCLUDES-ALL MOTICNS NECESSARY TO MOVE RAKE BACK AND FORTH THROUGH MIX TO SPREAD ENDS-WITH RAKE IN HAND |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VAL UE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|------|---------|----------------|--------------------|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 853 | MAF | 2279 | STLAB01 | 350 | ASPMALT, BREAK INTO PIECES WITH AXE, 100-POUNO BUNDLE STARTS-WITH REACH TO AXE INCLUDES-ALL MOTIONS NECESSARY TO USE AXE TO BREAK ASPMALT INTO PIECES FOR FEEDING INTO ASPMALT KETTLE ENDS-WITH ASIDE AXE |
| MF | 86X | MAF | 2081/82 | MACSL 01 | 992 | SCAFFOLD (PORTABLE), LOCK AND UNLOCK WHEELS STARTS-WITH TURN TO WHEEL INCLUDES-ALL MOTICNS NECESSARY TO WALK TWO PACES, TURN TO WHEEL, USE FOOT TO ACTUATE LEVER TO LOCK WHEEL: TURN, WALK THO PACES, STOOP, GET LEVER, PULL TO RELEASE WHEEL, AND ARISE.NOTE- THIS MOTION SEQUENCE IS REPEATED FOR EACH OF FOUR WHEELS. ENDS-WITH WHEELS UNLOCKED CONDITIONS-NO TIME INCLUDED FOR MOVING SCAFFOLD |
| NF | 86 X | MAF | 1397 | MITEMOI | 922 | FRAMEIDOOR), MEASURE AND CENTER IN OPENING STARTS-WITH RULE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MEASURE UNE SIDE OF DOORWAY, TURN TO OTHER SIDE OF DOORWAY, MEASURE, BEND, MEASURE BOTTOM OF DOORWAY, ARISE, TURN TO OTHER SIDE OF DOORWAY, GET HAMMER, TAP FRAME SIX TIMES TO CENTER, BEND, MEASURE DOORWAY, TAP FRAME SIX TIMES TO CENTER, MEASURE, ARISE, MEASURE TOP OF DOORWAY AND ASIDE HAMMER AND RULE ENDS-WITH RELEASE OF TOOLS CONDITIONS-ODES NOT INCLUDE TIME FOR INSTALLING WEDGES TO HOLD DOOR FRAME IN PLACE. APPLICABLE TO INSTALLATION OF STEEL DOOR FRAME IN BRICK OR MASONRY WALL. |
| NF | 86X | MAF | 1396 | SI TFC 01 | 1041 | FRAME(DODR), CHECK FOR VERTICAL ALIGNMENT WITH LEVEL STARTS—WITH REACH TO LEVEL INCLUDES—ALL MOTIONS NECESSARY TO GET LEVEL, POSITION LEVEL TO FRONT OF FRAME, CHECK READING, POSITION LEVEL TO SIDE OF FRAME, CHECK READING, TURN TO OTHER SIDE OF DOORWAY, POSITION LEVEL TO REAR OF FRAME, CHECK READING, POSITION LEVEL TO SIDE OF FRAME, CHECK READING, POSITION LEVEL TO FRONT OF FRAME, CHECK READING, AND ASICE LEVEL ENDS—WITH RELEASE OF LEVEL CONDITION—NO TIME INCLUDED FOR CORRECTING ALIGNMENT OF DOOR FRAME, APPLICABLE TO INSTALLATION OF STEEL DOOR FRAME IN BRICK OR MASGNRY WALL |
| ŊF | 86X | MAF | 23 | IOOBQLK | 112 | BLOCK(SANDING), OBTAIN AND ATTACH SANDPAPER STARTS-WITH REACH TO BLOCK INCLUDES-ALL MOTIONS NECESSARY TO GET BLOCK, GET SANDPAPER, AND WRAP PAPER AROUND BLOCK ENDS-WITH BLOCK IN HAND CONDITION-NO TIME INCLUDED FOR TEARING SANDPAPER |
| NF | 86X | MAF | 2578 | SJPBC01 | 380 | BELT, CHANGE ON HAND HELD SANDING MACHINE STARTS-WITH REACH TO SANDING MACHINE INCLUDES-ALL MOTIONS NECESSARY TO TURN JACHINE ON SIDE, RELEASE BELT, REMOVE BELT FROM ROLLERS, ASIDE BELT, GET NEW BELT, POSITION BELT JVER ROLLERS, MOVE HANDLE TO TIGHTEN BELT, TURN MACHINE UPRIGHT, AND ADJUST BELT TENSIUN ENOS-WITH RELEASE OF MACHINE |

| DATA SOURCE | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TPU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|--------------|---------|----------------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ٧F | 86X | MAF | 34 | MMHORO1 | 886 | OBJECT, RAISE AND LOWER WITH MANUALLY OPERATED HOIST, AVERAGE 28-FCOT HEIGHT STARTS-WITH REACH TO HOIST ROPE INCLUDES-ALL MOTIONS NECESSARY TO RAISE OBJECT AN AVERAGE OF 28 FEET(OPERATOR STEPS SACK SEVEN PACES WHILE RAISING), AND TO STEP FORWARD SEVEN PACES TO LOWER OBJECT ENOS-WITH RELEASE OF HOIST ROPE CONDITION-RESISTANCE TO RAISING HOIST IS 45 POUNDS ENW.TIME TO ATTACH OR REMOVE OBJECT NOT INCLUDED. |
| NF | 86X | MAF | 1301 | MNFAAOL | 367 | ADMESIVE, APPLY TO FLOOR WITH SERRATED TROWEL, PER SQUARE FOOT STARTS—WITH TROWEL IN MAND INCLUDES—ALL MOTIONS NECESSARY TO MOVE TROWEL TO CONTAINER OF ADMESIVE, OBTAIN ADMESIVE ON TROWEL, AND SPREAD ADMESIVE ON FLOOR ENDS—WITH TROWEL IN MAND |
| NF | 86X | MAF | 1325 | MNFBIOL | 876 | BRACE(BOTTOM), INSTALL IN METAL DOOR FRAME STARTS-WITH BRACE, RIVETS, AND EXPANDER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO KNEEL ON BOTH KNEES, ASIDE BRACE, ASIDE RIVET EXPANDER, PLACE FOUR RIVETS THROUGH HOLES IN FRAME, GET BRACE, PLACE OVER RIVETS, GET EXPANDER FOUN TIMES, EXPAND RIVETS, AND ASIDE EXPANDER ENDS-WITH ARISE CONDITION-TWO RIVETS INSTALLED IN EACH END JF BRACE |
| V F | 8 6 X | MAF | 1326 | SNFB101 | 380 | BRACE(CENTER), INSTALL IN METAL DOOR FRAME STARTS-WITH GET WEDGE INCLUDES-ALL MOTIONS NECESSARY TO GET BRACE, TURN TO DOOR FRAME, POSITION BRACE, POSITION WEDGE TO HOLD BRACE, GET HAMMER, AND TAP WEDGE TO TIGHTEN BRACE ENDS-WITH ASIDE HAMMER |
| NF | 86X | MAF | 1398 | SNFWIOI | 251 | WEDGE, INSTALL TO HOLD DOOR FRAME IN PLACE STARTS-WITH GET TWO WEDGES(O":E IN EACH HAND) INCLUDES-ALL MOTIONS NECESSARY TO MOVE WEDGES TO FRAME, INSERT BY HAND, GET HAMMER, TAP EACH WEDGE TWO TIMES, AND ASIDE HAMMER ENDS-BITH RELEASE OF HAMMER CONDITIONS-DOES NOT INCLUDE THE INSTALLATION OF WEDGES TO LEVEL FRAME |
| NF | 96X | MAF | 1399 | SNF WI OZ | 458 | WEDGE, INSTALL TO RAISE AND LEVEL DOOR FRAME STARTS-WITH GET WEDGE INCLUDES-ALL MOTIONS NECESSARY TO KNEEL ON BOTH KNEES, INSERT WEDGE BY HAND, GET HAMMER, STRIKE WEDGE FOUR TIMES, GET SECOND MEDGE, INSERT BY HAND, STRIKE WEDGE FOUR BLOWS WITH HAMMER, AND ASIDE HAMMER ENDS-WITH ARISE |
| NF | 86X | MAF | 2946 | 40HCD01 | 256 | CUTTER(GASKET). OBTAIN FROM CASE AND PUT AWAY STARTS-WITH GET CASE INCLUDES-ALL MOTIONS NECESSARY TO OPEN CASE. REMOVE CUTTER FROM CASE. GET CUTTER, REPLACE IN CASE, AND CLOSE CASE ENOS-WITH ASIDE CASE |
| NF | 86X | MAF | 84 | MOHFUO1 | | FELT(ROOFING), UNROLL 15 FEET STARTS-WITH KNEEL TO ROLL OF FELT INCLUDES-ALL MOTIONS NECESSARY TO ALIGN FELT FOR UNROLLING, START UNROLLING, ARISE, AND WALK AND KICK ROLL OF FELT TO UNROLL A 15-FOOT LENGTH ENDS-WITH FELT UNROLLED CONDITIONS-ROLL OF FELT PREVIOUSLY OBTAINED AND PLACED IN APPROXIMATE POSITION |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUF | OPERATION/ ELEMENT DESCRIPTION |
|----------------|------|---------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 86X | MAF | 3311 | MOHGRO1 | 245 | GASKET, REMOVE FROM CUTTING BOARD AND ASIDE SCRAP STARTS-WITH GET HAMMER INCLUDES-ALL MOTIONS NECESSARY TO REMOVE TWO PINS WITH CLAW HAMMER, ASIDE HAMMER, AND ASIDE GASKET ENDS-WITH ASIDE SCRAP MATERIAL |
| NF | 86X | MAF | 1404 | SOHAF01 | 296 | FRAME(AND ANCHORS), ADJUST IN OPENING, METAL DOOR FRAME STARTS-WITH REACH TO DOOR FRAME INCLUDES-ALL MOTIONS NECESSARY TO MOVE FRAME SLIGHTLY TO ADJUST, SIDESTEP AND STOOP TO LOWER ANCHOR, POSITION AND CHECK VISUALLY, ARISE, POSITION AND CHECK MIDDLE ANCHOR, AND POSITION AND CHECK TOP ANCHOR ENDS-WITH FRAME AND ANCHORS ADJUSTED |
| NF | 86X | MAF | 1400 | SOHFA01 | 1613 | FRAME(METAL DOOR), ASSEMBLE STARTS-WITH KNEEL ON BOTH KNEES, HAMMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO ASIDE HAMMER, GET ONE SIDE FRAME AND MOVE NEAK TOP, GET TOP AND PREPOSITION TO SIDE, GET SIDE FRAME AND POSITION TO INSERT LUGS IN HOLES, GET HAMMER, STRIKE TOP TO SEAT, BEND LUGS OVER WITH HAMMER, ASIDE HAMMER, BEND OVER FRAME, INSPECT WORK, AND ARISE FROM BEND, NOTE-THIS MOTION SEQUENCE IS REPEATED FOR SECOND SIDE FRAME. ENDS-WITH ARISE FROM KNEELING POSITION CONDITIONS-ODES NOT INCLUDE TIME TO GET AND PLACE COMPONENT PARTS |
| NF | 86 X | MAF | 3435 | MTLBA01 | 411 | BLADEIGASKET CUTTER), ADJUST WITH CLAMPING SCREWS STARTS-WITH CUTTER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO GET SCREWDRIVER, LCOSEN TWO CLAMPING SCRE-S, ADJUST BLADE HEIGHT, TIGHTEN SCREWS, AND ASIDE CUTTER ENDS-WITH ASIDE SCREWORIVER |
| NF | 86X | MAF | 1688 | MTLBU01 | 538 | BOB(PLUMB), USE STARTS-WITH PLUMB BOB IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE PLUMB BOB TO ATTACHING POINT, WRAP CORD TO ATTACH, LOWER PLUMB BOB, POSITION CORD ON MARK, ADJUST CORD LENGTH, STOOP TO PLUMB BOB, STOP PLUMB BOB FROM SWINGING, ARISE, AND REMOVE PLUMB BOB ENDS-WITH PLUMB BOB IN HAND |
| NF | 86X | MAF | 3436 | MTLCAGI | 176 | CUTTER(GASKET), ADJUST TO SIZE FOR RING GASKET STARTS-WITH REACH TO CUTTER INCLUDES-ALL MOTIONS NECESSARY TO GET CUTTER, LOOSEN THUMB SCREW, POSITION SIZE INDICATOR, AND TIGHTEN THUMB SCREW ENDS-WITH CUTTER IN HAND |
| NF | 86X | MAF | 3737 | MTEC PO1 | 173 | CUTTER(GASKET), POSITION TO BOARD AND REMOVE STARTS-WITH REACH FOR GASKET CUTTER INCLUDES-ALL MOTICNS NECESSARY TO MOVE PIVOT PIN TO CENTER MARK ON GASKET MATERIAL, PRESS PIN INTO MATERIAL, AND POSITION IN CENTER HOLE; AND DISENGAGE PIVOT PIN AND MOVE CUTTER ASIDE ENDS-WITH RELEASE OF CUTTER |
| NF | 86X | MAF | 113 | MTLGL01 | 125 | GUN(CAULKING).LOAD WITH CARTRIDGE STARTS-WITH GET CAULKING GUN INCLUDES-ALL MOTIONS NECESSARY TO TURN AND MOVE HANDLE BACK, GET CARTRIDGE, POSITION IN GUN,TURN HANDLE, AND ACTUATE TRIGGER TO BRING PLUNGER TO END OF CARTRIDGE ENDS-WITH RELEASE OF TRIGGER CONDITION-APPLICABLE TO HALF CYLINDER, CARTRIDGE TYPE CAULKING GUN |

| | OCCUP- ATION | | SOURCE CODE | OWMSTOP ELEMENT | THU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----|-----------------|-----|----------------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 86X | MAF | 340/341 | MTPTCOL | 578 | TOOL, CONNECT TO AND DISCONNECT FROM EXTENSION CORD LYING ON FLOOR STARTS-WITH LOOK TO END OF TOOL CORD INCLUDES-ALL MOTIONS NECESSARY TO WALK FOUR PACES, BEND TO END OF TOOL CORD, GET CORD, ARISE, WALK FOUR PACES TO END OF EXTENSION CORD, BEND, GET END OF EXTENSION CORD, PLUG TOOL INTO EXTENSION CORD, PLACE CORD ON FLOOR, AND ARISE; AND LOOK FOR CORD CONNECTION, WALK FOUR PACES, BEND, GET CORD, SEPARATE TOOL CORD FROM EXTENSION, AND ASIDE CORD ENDS |
| AE | 860 | MAN | FCHEAP1 | 10H89LM | 75 | ENDS-WITH ARISE FROM BEND BOARD.HOLD FOR SAWING STARTS-WITH REACH TO BOARD INCLUDES-ALL THE HOTIONS NECESSARY TO REACH TO BOARD:MOVE BOARD TO POSITION.PUT KNEE ON BOARD:REMOVE-KNEE FROM BOARD AND RELEASE BOARD ENDS-WITH RELEASE BOARD CONDITIONS-NO TIME INCLUDED FOR SAWING |
| NF | 860 | MAF | 336/337 | 10189LM | . 234 | BIT, INSTALL IN AND REMOVE FROM BRACE STARTS-WITH REACH TO BIT; BRACE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO PICK UP BIT, POSITION IN CHUCK, AND TIGHTEN CHUCK; AND LOOSEN CHUCK, AND REMOVE BIT ENDS-WITH ASIDE BRACE AND BIT |
| AE | 860 | MAW | FCHEAL1 | . SOI B9LM, | 173 | BIT, INSTALL IN AND REMOVE FROM HAND DRILL STARTS-WITH MOVE BIT TO CHUCK INCLUDES-ALL MOTIONS NECESSARY TO POSITION ORILL INTO CHUCK, TIGHTEN CHUCK: LOOSEN AND RELEASE CHUCK ENDS-WITH RELEASE CHUCK |
| AE | 860 | MAW | FCHEA82 | EQ189LM | 102 | BIT, INSTALL IN AND REMOVE FROM SPIRAL DRILL STARTS-WITH GET HOLD OF CHUCK INCLIDES-ALL MOTIONS NECESSARY TO OPEN SPRING CHUCK, INSERT DRILL IN CHUCK, LOCK CHUCK AND MOVE DRILL READY FOR USE:MOVE DRILL AND OPEN CHUCK, REMOVE DRILL AND RELEASE CHUCK SPRING ENDS-WITH RELEASE SPRING |
| NF | 860 | MAF | 117 | МОНСАО1 | 111 | CARTRIDGE, ASSEMBLE TO STUD STARTS—WITH GET STUD INCLUDES—ALL MOTIONS NECESSARY TO GET CARTRIDGE AND ASSEMBLE TO STUD ENDS—WITH ASIDE ASSEMBLY |
| AF | 960 | MAW | FCHEAW | 1 MOHNGOI | 65 | NAILS.GET FROM BOX STARTS-WITH REACH TO BOX OF NAILS INCLIDES-ALL MOTIONS NECESSARY TO GET A HANDFUL OF NAILS ENDS-WITH MOVE HAND AWAY FROM BOX |
| NF | 360 | MAF | 328 | MOHPLO | 1 704 | PARTITION (ASSEMBLED).LIFT FROM FLOOR AND POSITION TO MARKS STARTS-WITH KNEEL TO GET PARTITION INCLUDES-ALL MOTIONS NECESSARY TO GRASP TOP PLATE, ARISE FROM FLOOR WITH PARTITION.LIFT PARTITION TO VERTICAL POSITION, AND POSITION PARTITION TO MARKS AT BOTTOM AND TOP ENDS-WITH HANDS ON PARTITION CONDITION—APPLICABLE TO PARTITION WITH ENW TO 160 POUNDS.TIME VALUE IS TOTAL FOR TWO OPERATORS |

| OATA Source | | QUAL ITY | SOURCE CODE | DWMSTOP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 860 | MAF | 194 | 40HPH01 | 277 | PLATE(FOUNDATION), MAKE LEVEL WITH SHIMS STARTS-WITH KNEEL TO PLATE INCLUDES-ALL MOTIONS NECESSARY TO RAISE PLATE, GET TWO SHIMS, AND INSERT SHIMS UNDER PLATE ENOS-WITH ARISE CONDITION-TIME TO GET AND POSITION PLATE NOT INCLUDED |
| NF | 860 | MAF | 195 | MGHPP01 | . 441 | PLATE(FOUNDATION), POSITION TO BOLTS SET IN CONCRETE STARTS-WITH PLATE IN HANDS INCLUDES-ALL THE MOTIONS NECESSARY TO BEND TO FOUNDATION AND POSITION PLATE ON BOLTS ENDS-WITH ARISE FROM BEND CONDITIONS-APPLICABLE TO INSTALLATION OF 2" X 4" OR 2" X 6" PLATE 12 FEET LONG WITH BOLT HOLES ON 4-FOOT CENTERS, TIME VALUE IS FOR TWO OPERATORS. |
| AE | 860 | MAIn | FCHEAGL | MTLBPO1 | 69 | BIT(AND BRACE), POSITION FOR DRILLING AND REMOVE STARTS-WITH MOVE DRILL TO MARK INCLUDES-ALL THE MOTIONS NECESSARY TO POSITION DRILL BIT TO MARK, PUSH POINT OF BIT INTO WOOD; DISENGAGE BIT FROM HOLE AND MOVE BRACE FROM WORK AREA ENDS-WITH BRACE IN HANDS, MOVED FROM HOLE CONDITIONS-DOES NOT INCLUDE TIME FOR DRILLING HOLE OR TURNING BRACE TO REMOVE BRACE. APPLICABLE TO BRACE AND BIT OR HAND ORILL. |
| NF | 860 | MAF | 252 | MTLBSXX | 105 | BOARD, SAW IN MITER BOX STARTS—WITH BOARD IN HAND INCLUDES—ALL MOTIONS NECESSARY TO GET SAW HANDLE, LIFT SAW, POSITION BOARD IN BOX, POSITION SAW TO BOARD, AND MAKE ONE FORWARD AND JNE RETURN STROKE WITH SAW ENDS—WITH RELEASE OF SAW HANDLE; BOARD IN BOX CASE 01 POSITION BOARD AND MAKE ONE STROKE (FORWARD AND RETURN) WITH SAW 02 EACH ADDITIONAL STROKE WITH SAW |
| ΔE | 860 | MAW | FCHE 4Z1 | MTLDP01 | 37 | DRILL(SPIRAL), POSITION TO MARK AND REMOVE STARTS-WITH MOVE TOOL TO MARK INCLUDES-ALL THE MOTIONS NECESSARY TO MOVE ORILL, POSITION TO MARK; DISENGAGE DRILL FROM HOLE ENDS-WITH DRILL DISENGAGED FROM HOLE |
| 4 € | 860 | WAW | FCHEAA2 | MTLHD01 | 23 | HOLE, DRILL WITH SPIRAL DRILL, PER STROKE STARTS - WITH DRILL IN POSITION FOR USE INCLUDES - ALL MOTIONS NECESSARY TO PUSH SPIRAL DRILL DCWN AND RETURN ENDS - WITH END OF RETURN STROKE |
| ŊF | 860 | MAF | 322 | MTLLSO1 | 281 | LINE, STRIKE WITH CHALK LINE STARTS—WITH LINE HELD NEAR REFERENCE POINTS BY TWO OPERATORS INCLUDES—ALL MOTIONS NECESSARY TO MOVE LINE TO REFERENCE POINTS, HOLD, GET CHALK LINE, RAISE VERTICALLY, AND RELEASE CORD TO STRIKE LIVE ENDS—WITH LINE ON SURFACE CONDITION—TIME VALUE IS TOTAL FOR TWO OPERATORS |
| A E | 860 | MAW | FCHE4X1 | MTLNP01 | 59 | NAIL.POSITION AND START TO ORIVE WITH HAMMER STARTS-WITH MOVE MAIL FROM PALM TO FINGERS INCLUDES-ALL MOTIONS NECESSARY TO GET MAIL FROM PALM, MOVE, POSITION AND HOLD MAIL, MOVE HAMMER AND TAP MAIL TO STARTIONE BLOW! ENOS-WITH MAIL STARTED INTO BOARD |

| | | - | | | | |
|----------------|------------------|----------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DATA SOURCE | OCCUP- AT ION | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
| NF | 860 | MAF | 263 | MTLNSXX | VARTABLE . | NAIL, START IN BOARD STARTS-WITH SIMD GET NAILS FROM POCKET AND HAMMER FROM LOOP INCLUDES-ALL MOTIONS NECESSARY TO POSITION NAIL, AND STRIKE NAIL TWO BLOWS WITH HAMMER TO START IN BOARD ENDS-WITH HAMMER IN HAND CONDITION-APPLICABLE TO PRE-NAILING FASCIA STRIPS, ETC. CASE OI FIRST NAIL OZ EACH ADDITIONAL NAIL (POSITION AND |
| | | • | | | 72 | STRIKE NAIL ONLY) |
| AE | 860 | MAW | FCHEAB 1 | MTLPAGI. | 192 - | PLANE(HAND), ADJUST STARTS-WITH PLANE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO TURN PLANE, CHECK FOR BLADE HEIGHT, AUJUST BLADE HEIGHT BY TURNING ADJUSTING KNOB, MOVE LEVER TO AUJUST LEVEL, TURN PLANE OVER AND MOVE TOWARDS WORK ENDS-WITH PLANE IN HANDS, READY TO POSITION TO BOARD CONDITIONS-PLANE WEIGHS APPROXIMATELY 10 POUNDS |
| AF | 860 | MAW | | STLDHXX | VARIABLE | HOLE.DRILL WITH SPIRAL DRILL(ONE INCH HOLE) STARTS-WITH GET DRILL INCLUDES-ALL MOTIONS NECESSARY TO GET DRILL. GET AND INSTALL DRILL BIT.POSITIUN DRILL TO MARK AND DRILL HOLE.REMOVE BIT FROM DRILL AND ASIDE DRILL AND BIT:OR MOVE TO ADDITIONAL MARK |
| | | | | | | AND DRILL HOLE ENDS—WITH ASIDE DRILL OR REMOVE DRILL FROM HOLE CONDITIONS—APPROXIMATELY FIVE STROKES REQUIRED |
| | | | · . | | 385 152 | TO DRILL HOLE CASE OI DRILL FIRST HOLE ONE INCH DEEP WITH SPIRAL DRILL ADDITIONAL HOLE ONE INCH DEEP |
| AE | 860 | MAW | FC HNL XX | ST L NR X) | VARIABLE | NAIL, REMOVE WITH HAMMER STARTS-WITH GET HAMMER INCLUDES-ALL MOTIONS NECESSARY TO GET HAMMEK, POSITION CLAMS TO NAIL, PULL NAIL OUT, KEMOVE NAIL FROM HAMMER CLAWS AND ASIDE NAIL AND HAMMER; OR MOVE HAMMER TO NEXT NAIL, REMOVE AND ASIDE NAIL ENDS-WITH ASIDE HAMMER OR NAILS CASE OI REMOVE FIRST NAIL OZ REMOVE ADDITIONAL NAIL |
| NF | 860 | MAF | 116 | MT PG OO | 1 99 | GUN(POWDER ACTUATED). OPEN AND CLOSE STARTS-WITH REACH TO GUN INCLUDES-ALL MOTIONS NECESSARY TO GET GUN, PRESS LEVER DOWN. OPEN GUN STOCK. PRESS LEVER DOWN.CLOSE GUN STOCK. AND MOVE LEVER TO LOCK ENDS-WITH RELEASE OF LEVER, GUN IN HAND |
| ŊF | 8 60 | MAF | 115 | MTPGPO | 1 221 | GUN(POWDER ACTUATED), POSITION AND FIRE JNE BOLT OR STUD STARTS-WITH STUD GUN IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE GUN TO POSITION, AND FIRE GUN ENDS-WITH ASIDE GUN |
| DN | iF 860 | MAF | STPSIO | 1 STPSIC | 01 494 | STUD, INSTALL WITH POWDER ACTUATED GUN STARTS-WTIH REACH FOR STUD INCLUDES-ALL MOTIONS NECESSARY TO GET STUD, GET CARTRIDGE, ASSEMBLE STUD AND CARTRIDGE, GET GUN, OPEN GUN, INSTALL CARTRIDGE AND STUD ASSEMBLY, CLOSE GUN, POSITION GUN, FIRE STUD, AND ASIDE GUN ENOS-WITH RELEASE OF GUN |

| DATA Scurce | | YTI JAUQ | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|------|--------------|----------------|--------------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ٧F | 961 | MAF | 1436 | MNF MA 01 | 82 | MORTAR, APPLY TO ONE END AND ONE SIDE OF BRICK STARTS=WITH TROWEL AND BRICK IN HAND INCLUDES=ALL MOTIONS NECESSARY TO APPLY MORTAR TO END OF BRICK, TURN BRICK, AND APPLY MORTAR TO SIDE OF BRICK ENDS=WITH TROWEL AND BRICK IN HAND COMDITIONS=TIME TO OBTAIN MORTAR ON TROWEL NOT INCLUDED |
| NF : | 861 | M&F | 1443 | MNFMAO2 | 244 | MURTAR, APPLY ON THREE BRICK LENGTHS: FURROW AND CUT JOINT STARTS == ITH TROWEL LOADED WITH MORTAR IN HAND INCLUDES = ALL MOTIONS NECESSARY TO THROW MORTAR ON THREE BRICKS, FURROW JOINT, AND CUT JOINT WITH TROWEL IN HAND |
| ٧F | 861 | MAF | 1506 | MNFM403 | | MORTAR, APPLY TO ONE END OF BRICK STARTS-WITH BRICK AND TROWEL FILLED WITH MORTAR IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE TROWEL TO BRICK AND PRESS MORTAR ON ONE END ENDS-WITH BRICK AND TROWEL IN HAND |
| ΉF | 861 | MAF | 1331/32 | ж х саном | 198 229 | BRICK(FIRE), DIP IN ADHESIVE STARTS-WITH FIRE BRICK IN HAND INCLUDES-ALL MOTIONS NECESSARY ID SIDESTEP AND STOCP TO ADMESIVE PANJOIP BRICK IN ADHESIVE, REMOVE, AND SHAKE TO GEMOVE EXCESS ENDS-WITH ARISE AND TURN TO INSTALLATION POINT CASE OI DIP TWO SIDES OF BRICK 02 DIP THREE SIDES OF BRICK |
| NF | 95-1 | MAF | 1329 | MOH8/101 | 169 | BRICK. DRTAIN AND WET, PREPARATORY TO INSTALLATION STARTS-WITH TURN TO PILE OF BRICKS INCLUDES-ALL MOTIONS NECESSARY TO BEND. GET BRICK. MOVE BRICK IN AND OUT OF CONTAINER OF WATER, ARISE, AND TURN TO WALL ENDS-WITH BRICK IN HAND |
| NF | 961 | MAF | 1337 | монв ро 1 | 280 | RRICKIFIRE), PLACE AND TAP INTO POSITION STARTS-WITH BRICK AND TROWEL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE BRICK TO WALL AND POSITION: TAP END, SIDE, AND TUP OF BRICK HITH DRUEL ENDS-WITH BRICK IN PLACE CONDITIONS-APPLICABLE TO REPAIR WORK ONLY |
| ٧F | 861 | MAF | 1310 | МОНВ SC1 | 591 | BED(MORTAR SETTING), SMOOTH PRIDE TO LEVELING, PER FOUR SQUARE FEET STARTS-WITH KNEEL CN BOTH KNEES INCLUDES-ALL MOTICNS NECESSARY TO GET BJARD, PLACE TO MORTAR, AND MOVE BOARD SIDEWAYS TO SMOOTH MIX, AND ASIDE BOARD ENDS-WITH ARISE |
| ΝF | 961 | M <u>A</u> F | 1338 | монвто1 | 475 | BRICK(JAMB FIRE), TAP INTO POSITION ON OUTSIDE CORNER STARTS-WITH BRICK AND TROWEL IN HAND INCLUDES-ALL MOTICNS NECESSARY TO MOVE BRICK INTO POSITION: TAP END, SIDE, AND TOP OF BRICK WITH TROWEL: CHECK ALIGNMENT, TAP BRICK AS NECESSARY AND RECHECK ALIGNMENT ENDS-WITH TROWEL IN HAND CONDITIONS-APPLICABLE TO REPAIR FORK ONLY |

| DATA Source | | QUALITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 861 | MAF | 1512 | ЧОНВТО2 | 673 | BRICK, TAP INTO POSITION FOR TIE-IN STARTS-WITH BRICK IN ONE HAND, HAMMER IN OTHER HAND INCLUDES-ALL MOTIONS NECESSARY TO GET BRICK WITH BOTH HANDS (HAMMER PALMED); POSITION BRICK IN MORTAR: TAP END, SIDE, AND TOP OF BRICK TO SEAT; CHECK VISUALLY: TAP END, SIDE, AND TOP OF BRICK SECOND TIME; AND CHECK VISUALLY ENDS-MITH HAMMER IN HAND CONDITIONS-BRICK WEIGHS APPROXIMATELY 15 |
| NF | 861 | MAF | 1508 | SOHBOO1 | 429 | POUNDS.APPLICABLE TO REPAIR WORK ONLY BAG(CEMENT).DATAIN AND DEN STARTS—WITH WALK TWO DATS TO CEMENT STORAGE STARTS—WITH WALK TO CEMENT STORAGE INCLUDES—ALL MOTIONS TO BEND TO BAG OF CEMENT, PICK UP CEMENT, TUNNALK TWO DACES TO HIS ING LOCATION-SET CEMENT OWN ARISE, AND PULL TAB TO OPEN BAG ENDS—WITH ASIDE TAB |
| NF | 861 | MAF | 1306/07 | SOHBRO1 | 574 | BACKING(PAPER). REMOVE FROM TILE FIELD. 13"x26" STARTS-WITH GET RAG OR SPONGE INCLUDES-ALL MOTIONS NECESSARY TO DIP RAG OR SPONGE IN CONTAINER OF WATER. SQUEEZE TO REMOVE EXCESS, WIPE FIELD OF TILE. ASIDE SPONGE. GET EDGE OF PAPER BACKING. PULL PAPER OFF, SWEEP DEBRIS WITH HAND, AND ASIDE DEBRIS ENDS-WITH RELEASE OF DEBRIS |
| NF | 861 | MAF | 1408 | SOHGPOL | 333 | GROUT.POUR AND WORK INTO CRACKS OF FLOUR TILE. PER SQUARE FOOT STARTS-WITH REACH FOR PAIL OF GROUT INCLUDES-ALL MOTIONS NECESSARY TO MOVE PAIL INTO POSITION, INVERT, POUR GROUT OVER TILE, SET PAIL ASIDE, GET BRUSH, BRUSH GROUT, AND ASIDE 9RUSH ENDS-WITH RELEASE OF BRUSH CONDITIONS-PAIL OF GROUT WEIGHS TO 10 POUNDS |
| NF | 861 | MAF | 1486 | SOHTPO1 | 417 | TILE, POSITION AND LEVEL TO ADJOINING TILE STARTS-WITH REACH TO TILE INCLIDES-ALL MCTIONS NECESSARY TO GET TILE, POSITION, GET BLOCK, PLACE ON TILE, TAP WITH PALM, REMOVE BLOCK, INSPECT VISUALLY, MOVE BLOCK TO TILE, TAP WITH PALM, REMOVE BLOCK, INSPECT, AND ASIDE BLOCK ENDS-WITH RELEASE OF BLOCK CONDITIONS-APPLICABLE TO REPLACEMENT OF TILE |
| ŅF | 861 | MAF | 1327 | MTL8801 | 331 | BRICK, BREAK WITH TROWEL TO FIT STARTS-WITH TURN TO PILE OF BRICKS INCLUDES-ALL MOTIONS NECESSARY TO BEND, PICK UP BRICK, ARISE, TURN TO WALL, POSITION BRICK IT MEASURE, MARK BRICK WITH TROWEL, MOVE BRICK TO FRONT OF BODY, STRIKE WITH TROWEL TO BREAK, AND MOVE BRICK TO WALL TO CHECK FIT ENDS-WITH BRICK IN MANO |
| NF. | 861 | MAF | 1465 | MTLBC01 | 660 | BAG.CUT.CEMENT OR SIMILAR USING TROWEL STARTS-WITH BEND TO BAG OF CEMENT INCLUDES-ALL MOTIONS NECESSARY TO PICK UP BAG OF CEMENT.LIFT TO POSITION.GET TROWEL.STRIKE BAG TO CUT IN HALF.LIFT BAG TO FULD.AND CUT REMAINDER OF BAG WITH TROWEL TO SEPARATE HALVES ENDS-WITH ASIDE TROWEL AND ARISE |
| NF | 861 | MAF | 1309 | MTLBSOI | 357 | BED(MORTAR SETTING), SCREED, PER TWO SQUARE FEET STARTS-WITH SCREED IN HAND INCLUDES-ALL MOTICNS NECESSARY TO SCREED TWO SQUARE FEET OF MORTAR SETTING BED ENDS-WITH SCREED IN HAND |

| DATA SOURCE | | YTIJAUÇ | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ ELEMENT DESCRIPTION |
|----------------|-----|---------|--------|--------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 861 | MAF | 1510 | MTLCBO1 | 190 | BRICK, CHIP OUT WITH CHISEL AND HAMMER, PER CUBIC INCH STARTS-WITH CHISEL AND HAMMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE CHISEL TO BRICK, MOVE HAMMER TO CHISEL, AND CHIP OUT ONE CUBIC INCH OF BRICK(SIX HAMMER BLOWS) ENDS-WITH CHISEL AND HAMMER IN HAND CONDITIONS-NO TIME ALLOWED FOR REPOSITIONING CHISEL |
| NF . | 861 | MAF | 1426 | MTLJCOL | 246 | JOINT(MORTAR), CUT OFF, BOTTOM AND ONE END, THREE BRICKS, WITH TROWEL IN HAND STARTS-WITH TROWEL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO CUT OFF ONE HORIZONTAL JOINT(THREE BRICKS LONG), SHAKE MORTAR FROM TROWEL TO MORTAR PAN, CUT OFF THREE VERTICAL JOINTS(ONE BRICK HIGH), AND SHAKE MORTAR INTO PAN ENOS-WITH TROWEL IN HAND |
| NF | 861 | MAF | 1427 | MTLJCOZ | 117 | JJINT(MORTAR), CUT OFF, BOTTOM AND ONE END, ONE BRICK, WITH TROWEL STARTS-WITH TROWEL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO CUT OFF ONE HORIZONTAL AND ONE VERTICAL JOINT(ONE BRICK ONLY) AND SHAKE MORTAR FROM TROWEL INTO MORTAR PAN ENDS-WITH TROWEL IN HAND |
| NF | 861 | MAF | 1429 | MTLJP01 | 208 | JJINT(MORTAR), POINT UP HORIZONTAL AND VERTICAL 8"X16" BLOCK STARTS-WITH POINTING TOOL IN HAND INCLUDES-ALL MCTIONS NECESSARY TO POINT UP ONE VERTICAL AND ONE HORIZONTAL JOINT OF ONE BLOCK ENOS-WITH TOOL IN HAND |
| NF | 861 | M&F | 1429 | MTLJSO1 | 195 | JOINTIMORTAR), STRIKE, VERTICAL AND HORIZONTAL, ONE BLOCK, WITH TROWEL STARTS-WITH TROWEL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE TROWEL TO VERTICAL JOINT, STRIKE JOINT, SHAKE MORTAR FRCM TROWEL, STRIKE HORIZONTAL JOINT, AND SHAKE MORTAR FROM TROWEL ENDS-WITH TROWEL IN HAND |
| NF | 861 | MAF | 1492 | MTLTFOL | 132 | TROWEL, FILL WITH MORTAR STARTS-WITH TROWEL IN HAND INCLUDES-ALL MOTIONS NECESSARY TO TURN AND BEND TO MORTAR PAN, DIP TROWEL IN MORTAR, LIFT LOADED TROWEL, ARISE, AND TURN TO WORK ENDS-WITH TROWEL FILLED WITH MORTAR IN HAND |
| NF | 862 | MAF | 3320 | SEMTPOL | 252 | TOOLIGE AMING), POSITION AND RETURN, TOLEDO 999 PIPE MACHINE OR SIMILAR STARTS-WITH REACH TO REAMER INCLUDES-ALL MOTIONS NECESSARY TO SWING REAMER DOWN TO CUTTING POSITION, MOVE REAMER TO ARING REAMER TO PIPE END, MOVE REAMER TOTO PIPE, MOVE CARRIAGE AWAY, AND RAISE REAMER ENDS-WITH RELEASE OF REAMER CONDITIONS-DOES NOT INCLUDE TIME FOR REAMING |
| NF | 862 | MA'F | 602 | MNF ST XX | 90 43 | STAPLE, INSTALL IN PIPE COVER STARTS================================== |

| DATA Source | | QUALITY | SOURCE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|---------|--------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 862 | MAF | 3733 | MOHCGXX | VARIABLE | COVER(PIPE).GET AND POSITION ON PIPE, LENGTH OF COVER—THREE FEET STARTS—WITH GET COVER INCLUDES—ALL MOTIONS NECESSARY TO OPEN COVER, SLIDE OVER PIPE, AND POSITION ENDS—MITH RELEASE OF COVER |
| | | • | | | 119 188 314 | CASE UI SMALL PIPE, TO TWO INCHES DIAMETER 02 MEDIUM PIPE, TWO SIX INCHES DIAMETER 03 LARGE PIPE, GREATER THAN SIX INCHES DIAMETER |
| NF | 862 | MAF | 556 | MOHC 001 | 288 | CLOTH, OBTAIN FROM ROLL STARTS—WITH REACH TO CLOTH ON ROLL INCLUDES—ALL MOTIGNS NECESSARY TO UNROLL TO 16 INCHES OF CLOTH, GET KNIFE, SLIT CLUTH, ASIDE KNIFE, AND TEAR CLOTH TO SEPARATE FROM ROLL ENDS—HITH RELEASE OF CLOTH CONDITIONS—CLOTH IS 36 INCHES WIDE.APPLICABLE TO CBTAINING MUSLIN OR SIMILAR FOR WRAPPING PIPES AND FITTINGS |
| NF | 862 | MAF | 557 | MOHC SO1 | 134 | CLOTH, SMCOTH AFTER WRAPPING AROUND PIPE FITTING STARTS-WITH REACH TO CLOTH INCLUDES-ALL MOTIONS NECESSARY TO STRAIGHTEN AND SMOOTH CLOTH WRAPPING WITH HANDS ENDS-WITH RELEASE OF CLOTH CONDITIONS-APPLICABLE TO SMOOTHING CLOTH WRAPPED AROUND FITTING FOR INSULATION |
| NF | 862 | MAF | 654 | MOHEWO1 | 310 | FITTING. BRAP WITH WIREICHICKEN WIRE OR SIMILAR) STARTS-WITH REACH TO WIRE INCLUDES-ALL MOTIONS NECESSARY TO WRAP AIRE AROUND PIPE FITTING ENDS-WITH RELEASE OF WIRE |
| NF | 862 | MAF | 3738 | 40HG101 | 97 | GASKET, INSERT BETWEEN FLANGE JOINTS TO TWO-INCH INSIDE DIAMETER STARTS-WITH REACH TO GASKET INCLUDES-ALL MOTIONS NECESSARY TO GET GASKET, POSITION BETWEEN FLANGES, ALIGN GASKET TO MOLE, AND PRESS GASKET INTO PLACE ENDS-WITH RELEASE OF GASKET |
| NF | 862 | MAF | 3309 | I O AL HOP | 332 | JOINT(FLANGE).ALIGN STARTS-WITH REACH TO FLANGE INCLUDES-ALL MCTIONS NECESSARY TO BEING FLANGE TOGETHER.ALIGN APPROXIMATELY, GET PIN. INSERT IN BOLT HOLE.ALIGN FLANGES, AND REMOVE PIN ENDS-WITH ASIDE PIN CONDITIONS-TIME FOR INSTALLATION OF BULTS NUT INCLUDED.APPLICABLE TO PIPE TWO-SIX INCHES INSIDE DIAMETER. |
| NF | 862 | MAF | 3310. | SOALHOM | e 171 [°] | JOINT(FLANGE), ALIGN WITH PIN STARTS-WITH GET PIN INCLUDES-ALL MOTIONS NECESSARY TO IMSERT PIN IHROUGH POLT HOLES IN TWO FLANGES TO BRING FLANGES INTO ALIGNMENT ENDS-WITH ASIDE PIN CONDITIONS-TIME FOR INSTALLATION OF BOLTS NOT INCLUDED |
| NF | 862 | MAF | 542/3/4 | 40HE00 | ı 823 | LAMPWICK, OBTAIN AND WRAP ON THREADS OF PIPE STARTS-WITH REACH TO ROLL OF LAMPWICK INCLUDES-ALL MOTIONS NECESSARY TO GET ROLL OF LAMPWICK, UNROLL SIX-FOOT SECTION, BREAK SECTION FROM ROLL, ASIDE ROLL, SEPARATE STRANDS OF LAMPWICK, AND WRAP STRAND ON THREADS OF PIPE ENDS-WITH RELEASE OF LAMPWICK |

| DATA Source | | QUAL ITY | SOURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|----------|----------------|--------------------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 862 | MAF | 1682 | MOHPPO1 | 264 | PIPE, POSITION IN THREADING MACHINE AND REMOVE, TO FOUR-FOOT LENGTH STARTS-WITH PIPE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE END OF PIPE TO CHUCK, POSITION, MOVE PIPE INTO CHUCK, TURN, STEP TO OTHER SIDE OF CHUCK, PULL PIPE END THROUGH CHUCK, AND POSITION PIPE IN CHUCK; AND SIDESTEP TO END OF MACHINE, GET PIPE, AND SLIDE FROM CHUCK ENDS-WITH PIPE IN HAND CONDITIONS-APPLICABLE TO 1/4"-2" INSIDE DIAMETER PIPE, MACHINE TIME NOT INCLUDED. |
| NF | 862 | MAF | 1684 | MOHPPOZ | 442 | PIPE.POSITION IN THREADING MACHINE AND REMOVE, 4-20 FEET IN LENGTH STARTS-WITH PIPE IN HAND INCLUDES-ALL MOTIONS NECESSARY TO MOVE END OF PIPE TO V-ROLLER.POSITION ON ROLLER.SIDESTEP TO CHUCK.MOVE END OF PIPE TO CHUCK, TURN. WALK TO OTHER SIDE OF CHUCK.AND PULL END OF PIPE THROUGH CHUCK:AND TURN.WALK TO REAR OF MACHINE.GET PIPE.AND REMOVE FROM CHUCK ENDS-WITH PIPE IN HAND CONDITIONS APPLICABLE TO 1/4"-2" INSIDE DIAMETER PIPE.MACHINE TIME NOT INCLUDED |
| NF | 862 | MAF | 3313 | МОНРРОЗ | 359 | PIPE, POSITION IN THREADING MACHINE CHUCK AND REMOVE, TO FOUR FOOT LENGTH STARTS—WITH PIPE IN MANO INCLUDES—ALL MOTIONS NECESSARY TO MOVE PIPE TO CHUCK WHILE WALKING THO PACES, POSITION END OF PIPE TO CHUCK, AND PUSH PIPE THROUGH CHUCK TO CARRIAGE CYLINDER: AND TURN AND WALK TO END OF MACHINE, AND SLIDE PIPE FROM MACHINE ENOS—WITH PIPE IN HANDS CONDITIONS—APPLICABLE TO PIPE FOUR TO SIX INCHES DIAMETER LOADED IN HEAVY DUTY PIPE MACHINE.NO TIME INCLUDED FOR POSITIONING OR SECURING PIPE IN MACHINE. |
| NF | 862 | MAF | 599/600 | MOHSA 01 | 1757 | SNAKE, ATTACH TO AND REMOVE FROM PIPE, PREPATORY TO LEAD POUR STARTS-WITH REACH TO SNAKE INCLUDES-ALL MOTIONS NECESSARY TO GET SNAKE AND WRAP AROUND PIPE, SECURE SNAKE WITH CLAMP, GET YARN AND POSITION TO PIPE AND CLAMP, PUSH SNAKE AGAINST PIPE, GET HAMMER, POUND SNAKE TO ALIGN SNARE, PLACE HAMMER ASIDE, INSPECT JOINT, REMOVE CLAMP, REMOVE SNAKE, ASIDE SNAKE, AND INSPECT JOINT ENDS-WITH COMPLETION OF INSPECTION |
| NF | 862 | MAF | 60 l | MOHSPOI | 331 | STAND(PIPE).POSITION UNDER PIPE STARTS—MITH REACH TO PIPE BY FIRST OPERATOR INCLUDES—ALL MOTIONS NECESSARY FOR FIRST OPERATOR TO LIFT PIPE WHILE SECOND OPERATOR REACHES TO PIPE STAND, MOVES STAND TO ACES AND POSITION UNDER PIPE, AND FIRST OPERATOR TO LOWER PIPE TO STAND END—MITH OPER POSITIONED ON STAND CONDITION—TIME VALUE IS TOTAL FOR TWO OPERATORS |
| NF | 862 | MAF | 626 | MOHTBO1 | 167 | TUBING.BEND TO MATCH FITTING STARTS-WITH REACH TO TUBE INCLUDES-ALL MOTIONS NECESSARY TO APPLY PRESSURE.BEND TUBING TO ALIGN TO FITTING.AND VISUALLY CHECK RESULTS ENDS-WITH TUBING ALIGNED TO FITTING CONDITIONS-APPLICABLE TO COPPER TUBING 1/4-3 INCHES DIAMETER |

| DATA Source | | QUALITY | SCURCE CODE | DWMSTDP ELEMENT | TMU VALUE | OPERATION/ SLEMENT DESCRIPTION |
|----------------|------------|----------|----------------|--------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 862 | MAF | 636 | MOHTUO1 | 430 | TUBING, UNROLL FROM COIL STARTS-WITH REACH TO ROLL OF TUBING INCLUDES-ALL MOTIONS NECESSARY TO UNROLL AND STRAIGHTEN THREE FEET OF TUBING FROM ROLL FNDS-WITH TUBING UNROLLED CONDITIONS-APPLICABLE TO COPPER TUBING 1/4-3 INCHES IN DIAMETER |
| NF . | R62 | MAF | 3440 | MSUOPO1 | 253 | DIE(THREADING). POSITION TO PIPE AND RETRACT. T)LEDO MODEL 999 OR SIMILAR PIPE MACHINE STARTS-WITH REACH TO CARRIAJE INCLUDES-ALL MOTIONS NECESSARY TO MOVE CARRIAGE 24 INCHES TO END OF PIPE AND POSITION PIPE TO DIE FOR THREADING; AND OPEN DIE AND RETRACT CARRIAGE ENDS-WITH RELEASE OF CARRIAGE |
| ŊF | 862 | MAF | 3432 | MSUSA01 | 235 | SPEED, ADJUST ON HEAVY DUTY PIPE MACHINE, THREE LEVERS STARTS-WITH TURN FROM MACHINE INCLUDES-ALL MOTIONS NECESSARY TO WALK ONE PACE TO SPEED LEVERS, CHECK SPEED CHART, MJVE EACH OF THREE LEVERS TO ADJUST SPEED, AND TURN FROM LEVERS ENDS-WITH WALK ONE PACE TO MACHINE |
| ЧF | 862 | MAF | 3433 | MSUSCO1 | 133 | SIZE(DIE).CHANGE ON HEAVY DUTY PIPE MACHINE STARTS-WITH LOOK TO MARK ON MACHINE INCLUDES-ALL MOTIONS NECESSARY TO GET LEVER AND POSITION TO CORRECT SETTING ENOS-WITH RELEASE LEVER |
| NF | 862 | MAF - | 3434 | MSUWT01 | 418 | WHEEL.TIGHTEN OR LOOSEN TO ADJUST REAR GUIDE CLAMPS.HEAVY OUTY PIPE MACHINE STARTS-WITH WALK FOUR PACES TO REAR OF MACHINE INCLUDES-ALL MOTIONS NECESSARY TO SIDESTEP TO WHEEL.TURN WHEEL TO TIGHTEN OR LOOSEN, AND 'SIDESTEP FROM WHEEL ENDS-WITH WALK FOUR PACES TO OPERATING POSITION CONDITIONS-RESISTANCE TO TURNING WHEEL UP TO 60 POUNDS ENW |
| NF | 862 | MAF | 2570/71 | SSUDIOI | 500 | DIE(THREADING), INSTALL AND REMOVE, PIPE THREADING MACHINE STARTS-WITH BEND TO STORAGE SHELF UNDER MACHINE INCLUDES-ALL MOTIONS NECESSARY TO IDENTIFY THE DESIRED DIE, REMOVE FROM SLOTTED SHELF, ARISE, POSITION DIE ON SPUDS, AND CLOSE LEVER TO SECURE DIE; AND OPEN LEVER, REMOVE DIE, BEND, AND PLACE DIE IN SLOT ON SHELF ENDS-WITH ARISE FROM BEND |
| NF | 862 | MAF | 576 | MTFPP01 | 194 | PIPE, POSITION AND ENGAGE THREADS (PIPE SUSPENDED ON HOIST) STARTS-WITH REACH TO END OF PIPE INCLUDES—ALL MOTIONS NECESSARY TO MOVE END OF PIPE TO FITTING, POSITION, GET PIPE WITH BOTH HANDS, AND TURN PIPE TO ENGAGE THREADS ENDS—WITH RELEASE OF PIPE |
| NF | 962 | MAF | 634 | HTFTA01 | 270 | TUBING. ASSEMBLE TO THREADED FITTINGS(BOTH ENDS OF TUBING) STARTS-MITH REACH TO TUBE INCLUDES-ALL MOTIONS NECESSARY TO PICK UP TUBE.MOVE ONE END TO FITTING. HOLD. GET NUT AND ENGAGE ON THREADS. GET OTHER END OF TUBE, MOVE TO FITTING. AND ENGAGE NUT ON THREADS ENDS-WITH RELEASE OF TUBE CONDITIONS-OOES NOT INCLUDE TIME TO TURN NUT DOWN OR TO TIGHTEN NUT |

| - | | QUALITY | SOURCE | DWMSTDP | TMU | OPERATION/ELEMENT DESCRIPTION |
|--------|-------|---------|---------|----------------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SOURCE | 21104 | • | CODE | ELEMENT | VALUE | · |
| NF | 862 | MAF | 611 | MTLCCXX | VARIABLE. | COVER(PIPE).CUT WITH HACK SAW STARTS-WITH ONE HAND ON PIPE COVER.SAW IN OTHER HAND POSITIONED FOR CUTTING INCLUDES-ALL MOTIONS NECESSARY TO SAW THROUGH PIPE COVER AND ASIDE SCRAP |
| | | | | | 991 | ENDS-WITH RELEASE OF SCRAP CASE OI PIPE COVER FOR PIPE DIAMETER TWO INCHES OR LESS |
| | | | | | 1235 | O2 PIPE COVER FOR PIPE DIAMETER TWO-SIX INCHES |
| | | | | | 1540 | 03 PIPE COVER FOR PIPE DIAMETER GREATER THAN SIX INCHES |
| NF | 862 | MAF | 3268 | MTL0801 | 617 | DIE, BACK OFF THREADING TOOL, HAND-HELD PIPE DIE STARTS-WITH MOVE HANDLE FORWARD INCLUDES-ALL THE MOTIONS NEGESSARY TO MOVE HANDLE FORWARD 10 TIMES, SET RATCHET 10 TIMES AND MOVE HANDLE BACK 10 TIMES |
| | | | | . - | | ENDS-with MOVE HANDLE BACK CONDITIONS-RATCHET IN REVERSE-MATERIAL IN VISE AND HANDLE MOVED 36 INCHES EACH MOVE |
| 4 F | 862 | MAA | 104 | MTLDP01 | 116 | DIE, POSITION TO PIPE AND START FIRST THREAD, HAND-HELD PIPE DIE STARTS-HITH CUTTING TOOL IN HAND AND PIPE IN VISE |
| | | , | | .• | | INCLUDES-ALL THE MOTIONS NECESSARY TO POSITION TOOL TO PIPE, SEAT TOOL ON PIPE, APPLY PRESSURE AND MOVE HANDLE FORWARD, SET RATCHET, MOVE HANGLE WITH 30 POUNDS RESISTANCE ENOS-WITH MOVE HANDLE |
| NF | 862 | MAF | 536/537 | MTEJTXX | VARIABLE | JOINT(FLANGE).TIGHTEN OR LOOSEN, PRELIMINARY STARTS-WITH POSITION WRENCH ON FLANGE INCLUDES-ALL MOTIONS NECESSARY TO POSITION PINS IN HOLES IN FLANGE, TIGHTEN OR LUDSEN, MOVE WRENCH FROM HOLES, AND MOVE WRENCH BACK FOR NEXT TURN ENDS-WITH WRENCH IN HAND |
| | | | | | . 673 | CASE OI PIN WRENCH WITH DOUBLE PIN (APPROXIMATELY 4 REVOLUTIONS) |
| | | | | | 998 | <pre>02 FACE TYPE SPANNER WRENCH (APPROXIMATELY 3 REVOLUTIONS)</pre> |
| ŊF | 862 | MAF | 571 | MTLPC01 | 3830 | PIPE+CUT WITH PIPE CUITER STARTS-WITH CUTTER POSITIONED ON PIPE INCLUDES-ALL MOTIONS NECESSARY TO MAKE 18 REVOLUTIONS WITH CUTTER TO CUT PIPE ENDS-WITH PIPE SEPARATED |
| ЧF | 862 | MAF | 627 | MTETBXX | VARIABLE | TUBING. BEND WITH TUBING BENDER STARTS-WITH GET BENDING DEVICE INCLUDES-ALL MOTIONS NECESSARY TO POSITIUN DEVICE ON TUBING. MAKE BEND TO 90 DEGREES. AND REMOVE DEVICE ENDS-WITH ASIDE BENDING DEVICE CONDITIONS-APPLICABLE TO COPPER TUBING 1/4-3 INCHES OUTSIDE DIAMETER |
| | | | | | - 405 498 | CASE OI BEND TIBE WITH BENDING SPRING DZ BEND TUBE WITH TUBE BENDER |
| NF | 862 | MAF | 620/621 | MTLTCXX | VARIABLE | TUBING.CUT OFF WITH HAND CUTTER STARTS-WITH REACH TO TUBING CUTTER INCLUDES-ALL MOTIONS NECESSARY TO POSITION CUTTER ON TUBE.ADJUST TO TUBE.CUT TUBE.BREAK OFF END OF TUBE.AND REMOVE CUTTER ENDS-WITH ASIDE CUTTER |
| | | | | | 723 1528 | CASE 01 CUT TUBING TO 3/4 INCH DIAMETER 02 CUT TUBING 7/8 - 3 INCHES DIAMETER |

| DATA SOURCE | | QUAL TTY | SOURCE CODE | DWMSTDP FLEMENT | TM() VALUE | SPERATION/ ELEMENT. DESCRIPTION |
|----------------|-----|-------------|----------------|--------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NF | 862 | мағ | 632 | STLTFOL | 1284 | TUBING, FLARE END STAPTS-WITH GET FLARING BLOCK INCLUDES-ALL MOTIONS NECESSARY TO OPEN FLARING BLOCK, GET TUBE, PLACE FLARING BLOCK UN TUBE, TIGHTEN BLOCKITWO NUTS), ATTACH FLARING TOOL, FLARE END OF TUBE, REMOVE FLARING TOOL, REMOVE BLOCK, AND ASIDE TUBE ENDS-WITH ASIDE FLARING BLOCK CONDITIONS-APPLICABLE TO COPPER TUBING 1/4-3 INCHES OUTSIDE DIAMETER |
| NF | 862 | MAF | 633 | STLTROI | 450 | TUBING.REAM END WITH HAND REAMER STARTS-WITH GET REAMER INCLUDES-ALL MOTIONS NECESSARY TO POSITION REAMER TO TUBE,REAM TUBE,AND REMOVE REAMER ENDS-WITH ASIDE REAMER CONDITIONS-APPLICABLE TO COPPER TUBING 1/4-3 INCHES CUTSIDE DIAMETER |
| NF | 862 | MUF | 878 | 4VSV001 | 266 | VISE(PIPE), OPEN OR CLOSE AND TIGHTEN STARTS-WITH REACH TO VISE INCLUDES-ALL MCTIONS NECESSARY TO PULL VISE HANDLE TO LOOSEN, SPIN HANDLE TO RELEASE VISE ROD, OPEN VISE ROD, AND OPEN UPPER JAW ENDS-WITH RELEASE OF UPPER JAW CONDITION-REVERSE MOTION PATTERN, SAME TIME, REQUIRED TO CLOSE VISE, NO TIME ALLOWED FUR MOVING OR POSITIONING PIPE |
| NF | 363 | ₩∆ F | 3728 | 40HSP01 | 208 | SHINGLE (ASBESTOS). POSITION TO WALL STARTS=WITH SHINGLE IN HAND INCLUDES—ALL MOTIONS NECESSARY TO GRASP SHINGLE WITH BOTH HANDS. WOVE SHINGLE TO WALL. ALTIGN. PUSH NEW SHINGLE UNDER SHINGLE ON WALL. GET HAMMER FROM HAMMER LOOP. AND TAP SHINGLE IN PLACE ENDS—WITH HAMMER IN HAND CONDITION—APPLICABLE TO THE REPLACEMENT OF BROKEN SHINGLES |
| 4 F | 863 | MAF | 247 | MOHSRO1 | 485 | SHINGLE (BROKEN), REMOVE FROM WALL, ASBESTUS SHINGLE STARTS-WITH HAMMER IN HAND INCLUDES-ALL MOTIONS NECESSARY TO USE HAMMER TO BREAK SHINGLE FOR REMOVAL AND REMOVE PIECES OF SHINGLE ENDS-WITH ASIDE PIECES OF SHINGLE |
| ٧F | 863 | MAF | 243 | MTL SC 01 | 146 | SHINGLE, CUT WITH SHINGLE CUTTER, ASBESTOS SHINGLE STARTS-WITH REACH TO CUTTER HANDLE INCLUDES-ALL MOTIONS NECESSARY TO RAISE MANDLE TO OPEN CUTTER, ALIGN SHINGLE TO CUTTER, AND CUT SHINGLE ENDS-WITH COMPLETION OF CUT CONDITION-DOES NOT INCLUDE TIME TO GET AND ASIDE SHINGLE |
| 4F | 863 | MAF | 246 | MTLSPXX | VARIABLE 89 | SHINGLE, PUNCH HOLE WITH MANUAL PUNCH, ASBESTOS SHINGLE STARTS-WITH SHINGLE IN ONE HAND AND OTHER HAND ON PUNCH HANDLE INCLUDES-ALL MOTIONS NECESSARY TO RAISE HANDLE, POSITION SHINGLE TO PUNCH, LOWER HANDLE TO PUNCH HOLE, RAISE HANDLE, REMOVE SHINGLE, AND LOWER HANDLE ENDS-WITH SHINGLE IN HAND CASE OI FIRST HOLE OZ EACH ADDITIONAL HOLE |

| DATA Spurce | | YTIJAUG | SOURCE CODE | OWMSTDP ELEMENT | T MU VA LUF | OPERATION/ELEMENT DESCRIPTION |
|----------------|----------|---------|----------------|--------------------|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ∨ F | 964 - | WAF | 183 | SÚPSC 01 | 2233 | SANDPAPER, CHANGE ON DRUM SANDER STARTS—WITH GET WRENCH INCLUDES—ALL MOTIONS NECESSARY TO KNEEL, UNLUCK PAPER ON DRUM, REMOVE AND ASIDE USED PAPER, PICK UP NEW PAPER, PLACE ONE END OF PAPER IN CRUM SLOT, FOLD PAPER AND ROTATE CRUM, INSERT SECOND END OF PAPER IN SLOT, CREASE PAPER AITH WKENCH, INSERT FILLER, LOCK PAPER ON DRUM WITH ARENCH, AND ARISE ENDS—WITH ASIDE WRENCH CONDITIONS—TIME TO OBTAIN SANDPAPER NUT INCLUDED |
| VF | 864 | MAF | 86 | 40HFM01 | 162 | FELT, MOVE ASIDE FOR ADMESTVE APPLICATION STARTS-WITH WALK THREE PACES TO END OF FELT INCLUDES-ALL MOTICNS NECESSARY TO STOUPLICK UP END OF FELT, ARISE AND WALK BACKHARD TO MOVE FELT ASIDE ENDS-WITH RELEASE OF FELT CONDITIONS-APPLICABLE TO INSTALLATION OF FELT UN WOOD FLOOR |
| ٧F | 864 | MAF | 87 | MOHFMOZ | 263 | FELT, MOVE INTO POSITION AFTER ADHESIVE APPLICATION STARTS-WITH STOOP TO PICK UP FELT INCLUDES-ALL MOTICNS NECESSARY TO PICK UP END OF FELT STRIP, WALK THREE PACES TO BRING FELT OVER ADHESIVE, KNEEL, POSITION FELT, AND PRESS FELT INTO PLACE ENDS-WITH ARISE FROM KNEELING POSITION CONDITION-TIME TO APPLY ADHESIVE NCT INCLUDED. APPLICABLE TO INSTALLATION OF FELT STRIP ON WHOOD FLOOR |
| ЧF, | 864 | MAF | 81 | MTPSLOL | 4,9 | SANDER(DRUM), LOWER TO OR RAISE FROM FLOOK STARTS-WITH HANDS ON MACHINE HANDLE INCLUDES-ALL MOTIONS NECESSARY TO RELEASE MACHINE HANDLE, GET RELEASE LEVER, MOYE LEVER TO RELEASE DRUM, LOWER DRUM, RELEASE LEVER, AND REACH TO MACHINE HANDLE ENDS-WITH HANDS ON MACHINE HANDLE |
| 4 F | 865 | MÆF | 198 | MNFP101 | 265 | POINT(GLAZIER'S), INSTALL, PER POINT STARTS-HITH REACH TO GLAZIER'S POINT INCLUDES-ALL MOTIONS NECESSARY TO GET POINT, POSITION POINT, GET CHISEL, PRESS POINT IN, ASIDE CHISEL, GET HAMMER, AND TAP POINT ENDS-WITH ASIDE HAMMER |
| MF | 965 | МДР | 105 | MOHGPOI | 98 | GLASS.PLACE IN AND REMOVE FROM WINDOW FJR TRIAL INSTALLATION STARTS-WITH GLASS IN HAND INCLUDES-ALL MOTIONS NECESSARY TO HOLD GLASS BY SIDES.POSITION BOTTOM CORNERS IN SASH, GRASP PANE TOP. MOVE PANE IN TASA ORDER PANE FROM SASH ENDS-WITH PANE IN HAND CONDITION-APPLICABLE TO INSTALLATION OF WINDOW PANES 24X24-36X36 INCHES |
| NE | 865 | MAF | | MOHGPO2 | 138 | GLASS, PLACE IN WINDOW FOR FINAL INSTALLATION STARTS—WITH GLASS IN HAND INCLUDES—ALL MOTIONS NECESSARY TO HOLD GLASS PAME BY SIDES, PLACE BOTTOM CORNERS IN SASH, GRASP PANE NEAR TOP, MOVE PANE INTO SASH, AND PRESS PANE IN PUTTY ENOS—WITH RELEASE OF GLASS CONDITION—APPLICABLE TO INSTALLATION OF WINDOW PANES 24X24—36X36 INCHES |

| | | | • | | | |
|----------------|-----|---------|---------|--------------------|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DATA SOURCE | | QUALITY | SOURCE | OWMSTDP ELEMENT | TMU VA LUE | OPERATION/ELEMENT DESCRIPTION |
| NF | 866 | MAF | 3389 | MNFFNOL | 68 | FELTIRODFING).NAIL WITH ROOFING NAILS.PER NAIL STARTS-WITH NAIL AND HAMMEN IN HAND INCLUDES-ALL MOITON SEASON ROOFING NOITON MAIL AND DRIVE WITH THREE HAMMEN BLUWS ENDS-WITH AMMER IN HAND |
| ONF | 866 | MAF | MOHAA01 | MOHA401 | 439 | ASPHALT, APPLY FLOOD COAT FROM POUR CAN STARTS-WITH BEND TO FILLED POUR CAN INCLUDES-ALL MOTIONS NECESSARY TO PICK UP POUR CAN FILLED WITH ASPHALT, GET CAN WITH OTHER HAND, TILT CAN, AND POUR WITH SHEEPING MOTIONS WHILE SIDESTEPPING OVER AREA TO BE COATED ENDS-WITH ARISE FROM BEND, EMPTY CAN IN HAND CONDITIONS-FILLED CAN WEIGHS APPROXIMATELY 40 POUNDS, TIME TO WALK TO AND FROM ASPHALT CART NOT INCLUDED. |
| ¥F ↓ | 866 | MAF | 41 | МОНАЕО1 | 271 | ASPHALT. EMPTY FROM BUCKET TO "LO-BOY" CAAT STARTS-WITH REACH TO BUCKET SUSPENDED ON HOIST INCLUDES—ALL MOTIONS NECESSARY TO PULL BUCKET TO CART. RAISE AND TILT BUCKET TO EMPTY IN CART. LOWER BUCKET, AND PLACE BUCKET IN POSITION TO BE LOWERED ENDS—WITH RELEASE OF BUCKET CONDITIONS—PROCESS TIME TO POUR ASPHALT NOT INCLUDED. BUCKET IS NOT DISCONNECTED FROM HOIST |
| DNF | 866 | MAF | 241 | ,40H4MXX | VARIABLE | ASPHALT, MOP ON SURFACE FROM WHEELED BUCKET STARTS-WITH GET MOP FROM BUCKET INCLUDES-ALL MOTIONS NECESSARY TO GET ASPHALT ON MOP, MOP ASPHALT ON ROOF, AND METURN HUP TO BUCKET |
| | | | | | | ENDS-WITH RELEASE OF MOP |
| | | | | | 410 548 | CASE DI FIRST AREA 2.5 X 5 FEET DE EACH ADDITIONAL AREA 2.5 X 5 FEET (REQUIRES MOVING WHEELED BUCKET TO NEXT AREA) |
| ONF | 866 | MAF | MOH8F01 | монвео1 | 212 | BUCKET, FILL WITH HOT ASPHALT FROM KETTLE STARTS-WITH BUCKET IN HAND INCLUDES-ALL MOTIONS NECESSARY TO BEND. PLACE BUCKET UNDER KETTLE SPOUT, DEN SPOUT, CLOSE SPOUT, LIFT BUCKET FROM SPOUT, AND ARISE ENDS-WITH BUCKET OF ASPHALT IN HAND CONDITIONS-PROCESS TIME FOR BUCKET TO FILL NOT INCLUDED. FILLED BUCKET WEIGHS TO 40 POUNDS. |
| 4 F | 856 | MAF | 35 | чонвяс1 | | BUCKET (EMPTY), REMOVE FROM HOIST AND ATTACH FULL BUCKET AT GROUND LEVEL STARTS-WITH FULL BUCKET IN HAND INCLUDES-ALL MOTIONS NECESSARY TO BEND, SET AUCKET BY HOIST, GET HOIST ROPE, CPEN HALYARD CLASP, MOVE CLASP OFF EMPTY BUCKET, PUT CLASP OFF HANCLE OF FULL BUCKET, MOVE FULL BUCKET IN POSITION FOR HOISTING, AND MOVE SMPTY BUCKET ASIDE ENDS-WITH ARISE, EMPTY BUCKET IN HAND CONDITIONS-APPLICABLE TO HANDLING BUCKETS OFF HOT ASPHALT OR SIMILAR WITH UP TO 45 POUNDS ENW. |
| DNF | 866 | МДР | 89 | MTLFCXX | VARIABLE | The second secon |
| | | | | | 85 | MOVE TO NEXT CUT AND CUT FELT) |

| PATA Source | | YTIJAUC | SOURCE CADE | DWMSTDP ELEMENT | VALUE | OPERATION/ELEMENT DESCRIPTION |
|----------------|-----|---------|----------------|--------------------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ΝF | 866 | M&F | 110 | MTLGSOL | 261 | GRAVEL, SPRFAD WITH SHOVEL, PER SHOVELFUL STARTS-WITH SHOVEL IN HANDS INCLUDES-ALL MOTIONS NECESSARY TO BEND, GET SHOVELFUL OF GRAVEL FROM PILE, ARISE, TURN, AND SWING SHOVEL EIGHT TIMES BACK AND FORTH ID THINLY SPREAD GRAVEL ENDS-WITH SHOVEL IN HANDS CONDITIONS-APPLICABLE TO SPREADING GRAVEL OVER |